NOKIA

Nokia 106

User Guide

Issue 2018-11-19 en-US

About this user guide

Important: For important information on the safe use of your device and battery, read “For your safety” and “Product Safety” info in the printed user guide, or at www.nokia.com/support before you take the device into use. To find out how to get started with your new device, read the printed user guide.

© 2018 HMD Global Oy. All rights reserved.

Table of Contents

About this user guide 2
Get started 5
Keys and parts 5
Set up and switch on your phone 6
Charge your phone 8
Lock or unlock the keys 8
Basics 10
Get the most out of the two SIM cards 10
Explore your phone 10
Change the volume 14
Write text 15
Calls, contacts, and messages 17
Calls 17
Contacts 17
Send and receive messages 18
Personalize your phone 20
Change your ring or message tone 20
Change the look of your home screen 20
Profiles 21
Settings for Go to 21
Radio 23
Find and save radio stations 23
Listen to radio 23
Clock, calendar, and calculator 24
Set the time and date manually 24
Alarm clock 24
Calendar 24
Calculator 25
Copy and remove content 26
Remove private content from your phone 26
Settings 27

© 2018 HMD Global Oy. All rights reserved.


Call settings 27
Phone settings 27
Enhancements 27
Security settings 28
Message settings 28
Restore factory settings 28
Product and safety information 30
For your safety 30
Emergency calls 33
Take care of your device 33
Recycle 34
Crossed-out wheelie bin symbol 35
Battery and charger information 35
Small children 36
Medical devices 36
Implanted medical devices 37
Hearing 37
Protect your device from harmful content 37
Vehicles 38
Potentially explosive environments 38
Certification information (SAR) 39
About Digital Rights Management 40
Copyrights and other notices 40

© 2018 HMD Global Oy. All rights reserved.

Get started

Keys and parts

YOUR PHONE



This user guide applies to the following model: TA-1114

The keys and parts of your phone are:

1. Left selection key
2. Scroll key. Press to access your apps and select items.
3. Earpiece
6. Headset connector
7. Antenna area
8. Back cover opening slot
9. Right selection key

© 2018 HMD Global Oy. All rights reserved.

4. USB connector
5. Flashlight
10. Microphone

Avoid touching the antenna area while the antenna is in use. Contact with antennas affects the communication quality and may reduce battery life due to higher power level during operation.

Do not connect to products that create an output signal, as this may damage the device. Do not connect any voltage source to the audio connector. If you connect an external device or headset, other than those approved for use with this device, to the audio connector, pay special attention to volume levels.
Parts of the device are magnetic. Metallic materials may be attracted to the device. Do not place credit cards or other magnetic storage media near the device, because info stored on them may be erased.

Some of the accessories mentioned in this user guide, such as charger, headset, or data cable, may be sold separately.

Note: You can set the phone to ask for a security code. The pre-set code is 12345. Change it to protect your privacy and personal data. Note, however, that when you change the code, you need to remember the new code, as HMD Global is not able to open or bypass it.

Set up and switch on your phone

Learn how to insert the SIM card, memory card, and battery, and how to switch on your phone.




MINI SIM

Important: This device is designed to be used with a mini SIM card (see figure) only. Use of incompatible SIM cards may damage the card or the device, and may corrupt data stored on the card. Please consult your mobile operator for the use of a SIM card that has a micro-UICC cutout.

© 2018 HMD Global Oy. All rights reserved.

Note: Switch the device off and disconnect the charger and any other device before removing any covers. Avoid touching electronic components while changing any covers. Always store and use the device with any covers attached.

SET UP YOUR PHONE



1. Put your fingernail in the small slot at the bottom of the phone, lift and remove the cover.
2. If the battery is in the phone, lift it out.
3. Slide the SIM card into the slot with the contact area face down.
4. Slide the second SIM into the SIM2 slot. Both SIM cards are available at the same time when the device is not being used, but while one SIM card is active, for example, making a call, the other may be unavailable.
5. Line up the battery contacts, and put the battery in.
6. Put back the back cover.

SWITCH ON YOUR PHONE

Press and hold the ⏻ key.

© 2018 HMD Global Oy. All rights reserved.

REMOVE THE SIM CARD

Open the back cover, remove the battery, and slide the SIM out.

Charge your phone

Your battery has been partially charged at the factory, but you may need to recharge it before you can use your phone.

CHARGE THE BATTERY

1. Plug the charger into a wall outlet.
2. Connect the charger to the phone. When done, unplug the charger from the phone, then from the wall outlet.

If the battery is completely discharged, it may take several minutes before the charging indicator is displayed.



Tip: You can use USB charging when a wall outlet is not available. Data can be transferred while charging the device. The efficiency of USB charging power varies significantly, and it may take a long time for charging to start and the device to start functioning. Make sure your computer is switched on.

Lock or unlock the keys

LOCK THE KEYPAD

To avoid accidentally pressing the keys, use keypad lock. Select Go to > Lock keypad .

© 2018 HMD Global Oy. All rights reserved.

UNLOCK THE KEYPAD

Press , and select Unlock .

© 2018 HMD Global Oy. All rights reserved.

Basics

Get the most out of the two SIM cards

Your phone can use two SIM cards, and you can use them for different purposes.

SELECT WHICH SIM CARD TO USE

1. Select Menu > ⚙ > Dual SIM settings .
2. To choose which SIM to use for calls, select Default SIM for calls , and select Ask every time , or SIM1 , or SIM2 .
3. To choose which SIM to use for messages, select Default SIM for msgs , and select Ask every time , or SIM1 , or SIM2 .

You can set which SIM you want to use in standby mode, too, and assign a name to both SIMs.

© 2018 HMD Global Oy. All rights reserved.

Explore your phone


SEE THE APPS AND FEATURES OF YOUR PHONE



Select Menu .

© 2018 HMD Global Oy. All rights reserved.

GO TO AN APP OR FEATURE



Press the scroll key up, down, left, or right.

OPEN AN APP OR SELECT A FEATURE



Select Select .

© 2018 HMD Global Oy. All rights reserved.

GO BACK TO THE PREVIOUS VIEW



Select Exit or Back.

GO BACK TO THE HOME SCREEN



Press the end key.

© 2018 HMD Global Oy. All rights reserved.

SWITCH ON THE FLASHLIGHT



On the idle screen, quickly scroll up twice to switch on the flashligt.

To switch off the flashlight, scroll up once.

Do not shine the light in anyone’s eyes.

© 2018 HMD Global Oy. All rights reserved.

Change the volume

TURN THE VOLUME UP OR DOWN



Trouble hearing your phone ringing in noisy environments, or calls too loud? You can change the volume to your liking.

Scroll right or left to change the volume during a call or when listening to the radio.

Write text

WRITE USING THE KEYPAD

Writing with the keypad is easy and fun.

Press a key repeatedly until the letter is shown.

To type in a space press 0.

To type in a special character or punctuation mark, press *.

© 2018 HMD Global Oy. All rights reserved.

To switch between character cases, press # repeatedly.

To type in a number, press and hold a number key.

© 2018 HMD Global Oy. All rights reserved.

Calls, contacts, and messages

Calls

MAKE A CALL

Learn how to make a call with your new phone.

1. Type in the phone number. To type in the + character, used for international calls, press * twice.

2. Press . If asked, select which SIM to use.

3. To end the call, press .

ANSWER A CALL

Press .

Tip: If you are in a situation where you cannot answer the phone and you need to silence it quickly, select Silence .

Contacts

ADD A CONTACT

Save and organize your friends' phone numbers.

© 2018 HMD Global Oy. All rights reserved.

1. Select Menu > > Add contact .
2. Select where you want to save it, on Phone or SIM card
3. Write the name, and type in the number.
4. Select OK .



Tip: To save a phone number in the dialer, type in the number, and select Opt. > Save .

SAVE A CONTACT FROM CALL LOG

You can save contacts from call log.

1. Select Menu > > Received calls or Missed calls , depending on from where you want to save the contact.
2. Highlight the number you want to save, select Opt. > Save , and select where you want to save the contact.
3. Add the contact's name, check that the phone number is correct, and select OK .

CALL A CONTACT

You can call a contact directly from the contacts list.

1. Select Menu > > Names and scroll to a contact you want to call.
2. Select the contact and press the call key.

Send and receive messages

WRITE AND SEND MESSAGES

1. Select Menu > > Create message .
2. Write a message on the message field.
3. Select Opt. > Send , to add a recipient. You can enter a phone number or add a recipient by selecting Search to open Contacts .
4. Select OK .

© 2018 HMD Global Oy. All rights reserved.

WRITING OPTIONS

You can find different options for writing a message under Opt. when you are in the message field. You can, for example, insert symbols, and save or discard messages.

You can also turn on the predictive text (dictionary) under Opt. .

MESSAGE OPTIONS

When you have received messages in your phone, open a message and select Options .
Scroll to Use number , and select Opt. > Call to call the sender. You can delete conversations, and add the sender to a screened list.

© 2018 HMD Global Oy. All rights reserved.

Personalize your phone

Change your ring or message tone

You can choose a new ringtone or message tone.

CHANGE YOUR RINGTONE

1. Select Menu > ⚙ > Tone settings .
2. Choose Ringing tone .
3. Scroll to a ringtone.
4. Press OK .



Tip: Is your ringtone too loud or too silent? Select Ringing volume and scroll left or right.

CHANGE YOUR MESSAGE TONES

1. Select Menu > ⚙ > Tone settings .
2. Scroll to a Message alert tone .
3. Select the tone you want to use and select OK .

Change the look of your home screen

Change the look of your home screen with display settings.

CHOOSE A NEW WALLPAPER

You can change the background of your home screen with Wallpaper setting.

© 2018 HMD Global Oy. All rights reserved.

1. Select Menu > ⚙ > Display settings > Wallpaper .
2. Select the wallpaper, and then the option to position the wallpaper on the screen.

SHOW DATE AND TIME

You can choose if you want to see date and time on the home screen of your phone.

1. Select Menu > ⚙ > Time settings > Display of time and date .
2. Select Show clock to have them visible on the home screen.

If you want your phone to have time updated automatically, set Auto-update of date and time to On .

Profiles

Your phone has different profiles for different situations. You can edit the profiles to your liking.

PERSONALIZE PROFILES

There are several profiles that you can use in different situations. There is, for example, a silent profile for when you cannot have sounds on, and an outdoor profile with loud tones.

You can personalize profiles further.

1. Select Menu > ⚙ > Profiles .
2. Select a profile and Personalise .

For each profile you can set a specific ringtone, ringtone volume, message sounds and so on.



Tip: You can add different profiles to Go to menu for quick access.

© 2018 HMD Global Oy. All rights reserved.

Settings for Go to

You can add quick links to different applications and settings to Go to .

EDIT GO TO SETTINGS

On the bottom left-hand corner you have Go to , and when you select it, you can access different applications and settings. You can change the applications and settings to your liking.

1. Select Menu > ⚙ > Go to settings .
2. Select Select options .
3. Scroll to a shortcut you want to add on the Go to list on the home screen and Mark them.
4. Select Done to exit the list, and Yes to save changes.

You can also reorganize your Go to list.

1. Select Organise .
2. Scroll to an item you want to move and select Move .
3. Select if you want to move it up, down, to top, or to bottom of the list.
4. Select Back to exit the list, and Yes to save changes.

© 2018 HMD Global Oy. All rights reserved.

Radio

Find and save radio stations

Connect a compatible headset. It acts as an antenna.

SEARCH FOR YOUR FAVORITE RADIO STATIONS

1. Select Menu > .
2. To search for all available stations select Opt. > Auto tuning .
3. To switch to a saved station, scroll up or down.



Tip: To switch to a saved station, you can also press a number key.



Tip: To rename station, select the station and Opt. > Rename .

Listen to radio

Did you find a good radio station? Next, start listening to it!

LISTEN TO YOUR FAVORITE RADIO STATIONS ON YOUR PHONE

Select Menu > .
To change the volume, scroll left or right.
To close the radio, select Stop .

© 2018 HMD Global Oy. All rights reserved.

Clock, calendar, and calculator

Set the time and date manually

You can set your phone clock manually.

CHANGE THE TIME AND DATE

1. Select Menu > ⚙ > Time settings .
2. Switch Auto-update of date and time to Off .
3. To set the time, scroll down, and select Clock . Use the scroll key to set the time, and select OK .
4. To set the date, scroll down, and select Date setting . Use the scroll key to set the date, and select OK .

Alarm clock

Learn how to use the alarm clock to wake up and get to places on time.

SET AN ALARM

No clock around? Use your phone as an alarm clock.

1. Select Menu > 🕒 > Set alarms .
2. Select an alarm.
3. To set the hour, scroll up or down. To set the minutes, scroll right and then up or down.
4. Select OK .
5. Scroll to Time of day and select either am or pm .

© 2018 HMD Global Oy. All rights reserved.

Calendar

Need to remember an event? Add it to your calendar.

ADD A CALENDAR REMINDER

1. Select Menu > 12.
2. Select a date and Opt. > Add reminder.
3. Type in a name for the event, and select OK.
4. To set an alarm, select Alarm on. To set the hour, scroll up or down. To set the minutes, scroll right and then up or down.
5. Select OK.
6. Scroll to Time of day and select either am or pm.

Calculator

Learn how to add, subtract, multiply and divide with your phone calculator.

HOW TO CALCULATE

1. Select Menu > .
2. Enter the first factor of your calculation, use the scroll key to select the operation, and enter the second factor.
3. Select Equals to get the result of the calculation.

Select Clear to empty the number fields.

© 2018 HMD Global Oy. All rights reserved.

Copy and remove content

Remove private content from your phone

If you buy a new phone, or otherwise want to dispose of or recycle your phone, here's how you can remove your personal info and content. Note that it is your responsibility to remove all private content.

REMOVE CONTENT FROM YOUR PHONE

When removing private content from your phone, pay attention to whether you are removing content from the phone memory or the SIM card.

1. To remove messages, select Menu > > Delete messages . Select from the available options the messages you want to delete.
2. To remove contacts, select Menu > > Delete , and select if you want to delete contacts One by one or Delete all .
3. To remove your call info, select Menu > > Delete recent call lists , and select All .
4. Check that all your personal content has been removed.

© 2018 HMD Global Oy. All rights reserved.

Settings

Call settings

You can change the call settings of your phone.

AVAILABLE CALL SETTINGS

You can edit call settings depending on a setting. You can set them to be either on or off, and check the status of the setting.
You can add phone numbers to lists to be screened or blocked in call settings.

1. Select Menu > ⚙ > Call settings .
2. Select a setting you want to change.

Phone settings

You can change your phone settings.

AVAILABLE PHONE SETTINGS

You can edit phone settings depending on a setting. You can change the language of your phone, set keyguard to be on or off, and add a welcome note.

Enhancements

You can edit the enhancement settings.

© 2018 HMD Global Oy. All rights reserved.

ENHANCEMENT SETTINGS

Select the available accessory and edit its available settings.

Security settings

You can edit the available security settings.

AVAILABLE SECURITY SETTINGS

You can edit the security settings depending on a setting. You can set them to be either on or off, and check the status of the setting.

You can add phone numbers to a list to be blocked and create a closed user group.

1. Select Menu > ⚙ > Security settings > Change access codes .
2. Select the code you want to change, for example, Change security code or Change PIN code .

You need to have the current codes in hand to be able to change them.

Message settings

You can edit the message settings.

MESSAGE SETTINGS

Select Menu > 💬 > Message settings .

You can switch on or off settings, such as info service and delivery reports.

© 2018 HMD Global Oy. All rights reserved.

Restore factory settings

You can restore factory settings in this setting. Be careful, however, since you lose all personalization and all data you have added on the phone.

RESET YOUR PHONE

Accidents may happen and your phone may stop responding. You can restore the original factory settings, but be careful, since this reset removes all data you have saved in the phone memory and all your personalization.

If you are disposing your phone, note that you are responsible of removing all private content.

You need to have the security code to restore the original settings. To reset your phone to its original settings and to remove all your data, on the home screen, type in *#7370#.

1. Select Menu > ⚙ > Restore factory set. .
2. Enter the security code. There is no more confirmation after you select OK, but the phone is reset and all data is removed.

© 2018 HMD Global Oy. All rights reserved.

Product and safety information

For your safety

Read these simple guidelines. Not following them may be dangerous or against local laws and regulations. For further info, read the complete user guide.



SWITCH OFF IN RESTRICTED AREAS

Switch the device off when mobile phone use is not allowed or when it may cause interference or danger, for example, in aircraft, in hospitals or near medical equipment, fuel, chemicals, or blasting areas. Obey all instructions in restricted areas.



ROAD SAFETY COMES FIRST

Obey all local laws. Always keep your hands free to operate the vehicle while driving. Your first consideration while driving should be road safety.

© 2018 HMD Global Oy. All rights reserved.



INTERFERENCE

All wireless devices may be susceptible to interference, which could affect performance.



AUTHORIZED SERVICE

Only authorized personnel may install or repair this product.



BATTERIES, CHARGERS, AND OTHER ACCESSORIES

Use only batteries, chargers, and other accessories approved by HMD Global Oy for use with this device. Do not connect incompatible products.

© 2018 HMD Global Oy. All rights reserved.



KEEP YOUR DEVICE DRY

If your device is water-resistant, please refer to its IP rating for more detailed guidance.



PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.



© 2018 HMD Global Oy. All rights reserved.

SAR

This device meets RF exposure guidelines when used either in the normal use position against the ear or when positioned at least 0.2 inches (5 mm) away from the body. The specific maximum SAR values can be found in the Certification Information (SAR) section of this user guide. For more info, go to www.sar-tick.com.

When a carry case, belt clip or other form of device holder is used for body-worn operation, it should not contain metal and should provide at least the above-stated separation distance from the body. Note that mobile devices may be transmitting even if you are not making a voice call.

Emergency calls

Important: Connections in all conditions cannot be guaranteed. Never rely solely on any wireless phone for essential communications like medical emergencies.

Before making the call:
- Switch the phone on.
- If the phone screen and keys are locked, unlock them.
- Move to a place with adequate signal strength.

1. Press the end key repeatedly, until the home screen is shown.
2. Type in the official emergency number for your present location. Emergency call numbers vary by location.
3. Press the call key.
4. Give the necessary info as accurately as possible. Do not end the call until given permission to do so.

You may also need to do the following:

- Put a SIM card in the phone.
- If your phone asks for a PIN code, type in the official emergency number for your present location, and press the call key.
- Switch the call restrictions off in your phone, such as call barring, fixed dialling, or closed user group.

© 2018 HMD Global Oy. All rights reserved.

Take care of your device

Handle your device, battery, charger and accessories with care. The following suggestions help you keep your device operational.

- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that corrode electronic circuits.
- Do not use or store the device in dusty or dirty areas.
- Do not store the device in high temperatures. High temperatures may damage the device or battery.
- Do not store the device in cold temperatures. When the device warms to its normal temperature, moisture can form inside the device and damage it.
- Do not open the device other than as instructed in the user guide.
- Unauthorized modifications may damage the device and violate regulations governing radio devices.
- Do not drop, knock, or shake the device or the battery. Rough handling can break it.
- Only use a soft, clean, dry cloth to clean the surface of the device.
- Do not paint the device. Paint can prevent proper operation.
- Keep the device away from magnets or magnetic fields.
- To keep your important data safe, store it in at least two separate places, such as your device, memory card, or computer, or write down important info.

During extended operation, the device may feel warm. In most cases, this is normal. To avoid getting too warm, the device may automatically slow down, close apps, switch off charging, and if necessary, switch itself off. If the device is not working properly, take it to the nearest authorized service facility.

Recycle



© 2018 HMD Global Oy. All rights reserved.

Always return your used electronic products, batteries, and packaging materials to dedicated collection points. This way you help prevent uncontrolled waste disposal and promote the recycling of materials. Electrical and electronic products contain a lot of valuable materials, including metals (such as copper, aluminum, steel, and magnesium) and precious metals (such as gold, silver, and palladium). All materials of the device can be recovered as materials and energy.

Crossed-out wheelie bin symbol



CROSSED-OUT WHEELIE BIN SYMBOL

The crossed-out wheelie bin symbol on your product, battery, literature, or packaging reminds you that all electrical and electronic products and batteries must be taken to separate collection at the end of their working life. Do not dispose of these products as unsorted municipal waste: take them for recycling. For info on your nearest recycling point, check with your local waste authority.

Battery and charger information

BATTERY AND CHARGER

Use your device only with an original BL-5CB rechargeable battery.

Charge your device with AC-18 charger. Charger plug type may vary.

HMD Global may make additional battery or charger models available for this device.

© 2018 HMD Global Oy. All rights reserved.

BATTERY AND CHARGER SAFETY INFO

To unplug a charger or an accessory, hold and pull the plug, not the cord.

When your charger is not in use, unplug it. If left unused, a fully charged battery will lose its charge over time.

Always keep the battery between 59°F and 77°F (15°C and 25°C) for optimal performance. Extreme temperatures reduce the capacity and lifetime of the battery. A device with a hot or cold battery may not work temporarily. Accidental short-circuiting can happen when a metallic object touches the metal strips on the battery. This may damage the battery or the other object.

Do not dispose of batteries in a fire as they may explode. Obey local regulations. Recycle when possible. Do not dispose as household waste.

Do not dismantle, cut, crush, bend, puncture, or otherwise damage the battery in any way. If a battery leaks, do not let liquid touch skin or eyes. If this happens, immediately flush the affected areas with water, or seek medical help. Do not modify, attempt to insert foreign objects into the battery, or immerse or expose it to water or other liquids. Batteries may explode if damaged.

Use the battery and charger for their intended purposes only. Improper use, or use of unapproved or incompatible batteries or chargers may present a risk of fire, explosion, or other hazard, and may invalidate any approval or warranty. If you believe the battery or charger is damaged, take it to a service centre or your phone dealer before continuing to use it. Never use a damaged battery or charger. Only use the charger indoors. Do not charge your device during a lightning storm.

Small children

Your device and its accessories are not toys. They may contain small parts. Keep them out of the reach of small children.

© 2018 HMD Global Oy. All rights reserved.

Medical devices

Operation of radio transmitting equipment, including wireless phones, may interfere with inadequately shielded medical devices' function. Consult a physician or the medical device's manufacturer to determine if it is adequately shielded from external radio energy.

Implanted medical devices

To avoid potential interference, manufacturers of implanted medical devices recommend a minimum separation of 15.3 centimeters (6 inches) between a wireless device and the medical device. Persons who have such devices should:

- Always keep the wireless device more than 15.3 centimeters (6 inches) from the medical device.
- Not carry the wireless device in a breast pocket.
- Hold the wireless device to the ear opposite the medical device.
- Switch the wireless device off if there is any reason to suspect that interference is taking place.
- Follow the manufacturer directions for the implanted medical device.

If you have any questions about using your wireless device with an implanted medical device, consult your health care provider.

Hearing



Warning: When you use the headset, your ability to hear outside sounds may be affected. Do not use the headset where it can endanger your safety.

Some wireless devices may interfere with some hearing aids.

© 2018 HMD Global Oy. All rights reserved.

Protect your device from harmful content

Your device may be exposed to viruses and other harmful content. Take the following precautions:

- Be cautious when opening messages. They may contain malicious software or otherwise be harmful to your device or computer.
- Be cautious when accepting connectivity requests, browsing the internet, or downloading content. Do not accept Bluetooth connections from sources you do not trust.
- Only install and use services and software from sources that you trust and that offer adequate security and protection.
- Install antivirus and other security software on your device and any connected computer. Only use one antivirus app at a time. Using more may affect performance and operation of the device and/or computer.
- If you access preinstalled bookmarks and links to third party internet sites, take the appropriate precautions. HMD Global does not endorse or assume liability for such sites.

Vehicles

Radio signals may affect improperly installed or inadequately shielded electronic systems in vehicles. For more info, check with the manufacturer of your vehicle or its equipment.
Only authorized personnel should install the device in a vehicle. Faulty installation may be dangerous and invalidate your warranty. Check regularly that all wireless device equipment in your vehicle is mounted and operating properly. Do not store or carry flammable or explosive materials in the same compartment as the device, its parts, or accessories. Do not place your device or accessories in the air bag deployment area.

© 2018 HMD Global Oy. All rights reserved.

Potentially explosive environments

Switch your device off in potentially explosive environments, such as near gasoline pumps. Sparks may cause an explosion or fire resulting in injury or death. Note restrictions in areas with fuel; chemical plants; or where blasting operations are in progress. Areas with a potentially explosive environment may not be clearly marked. These usually are areas where you are advised to switch your engine off, below deck on boats, chemical transfer or storage facilities, and where the air contains chemicals or particles. Check with the manufacturers of vehicles using liquefied petroleum gas (such as propane or butane) if this device can be safely used in their vicinity.

Certification information (SAR)

This mobile device meets guidelines for exposure to radio waves.

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields), recommended by international guidelines from the independent scientific organization ICNIRP. These guidelines incorporate substantial safety margins that are intended to assure the protection of all persons regardless of age and health. The exposure guidelines are based on the Specific Absorption Rate (SAR), which is an expression of the amount of radio frequency (RF) power deposited in the head or body when the device is transmitting. The ICNIRP SAR limit for mobile devices is 2.0 W/kg averaged over 10 grams of tissue.

SAR tests are carried out with the device in standard operating positions, transmitting at its highest certified power level, in all its frequency bands.

Please refer to www.nokia.com/phones/sar for the maximum SAR value of the device.

This device meets RF exposure guidelines when used against the head or when positioned at least 5/8 inch (1.5 centimetres) away from the body. When a carry case, belt clip or other form of device holder is used for body-worn operation, it should not contain metal and should provide at least the above stated separation distance from the body.

© 2018 HMD Global Oy. All rights reserved.

To send data or messages, a good connection to the network is needed. Sending may be delayed until such a connection is available. Follow the separation distance instructions until the sending is finished.

During general use, the SAR values are usually well below the values stated above. This is because, for purposes of system efficiency and to minimize interference on the network, the operating power of your mobile is automatically decreased when full power is not needed for the call. The lower the power output, the lower the SAR value.

Device models may have different versions and more than one value. Component and design changes may occur over time and some changes could affect SAR values.

For more info, go to www.sar-tick.com. Note that mobile devices may be transmitting even if you are not making a voice call.

The World Health Organization (WHO) has stated that current scientific information does not indicate the need for any special precautions when using mobile devices. If you are interested in reducing your exposure, they recommend you limit your usage or use a hands-free kit to keep the device away from your head and body. For more information and explanations and discussions on RF exposure, go to the WHO website at www.who.int/peh-emf/en.

About Digital Rights Management

When using this device, obey all laws and respect local customs, privacy and legitimate rights of others, including copyrights. Copyright protection may prevent you from copying, modifying, or transferring photos, music, and other content.

Copyrights and other notices

COPYRIGHTS

The availability of products, features, apps and services may vary by region. For more info, contact your dealer or your service provider. This device may contain commodities, technology or software subject to export laws and regulations from the US and other countries. Diversion contrary to law is prohibited.

© 2018 HMD Global Oy. All rights reserved.

The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. HMD Global reserves the right to revise this document or withdraw it at any time without prior notice.

To the maximum extent permitted by applicable law, under no circumstances shall HMD Global or any of its licensors be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.

Reproduction, transfer or distribution of part or all of the contents in this document in any form without the prior written permission of HMD Global is prohibited. HMD Global operates a policy of continuous development. HMD Global reserves the right to make changes and improvements to any of the products described in this document without prior notice.

HMD Global does not make any representations, provide a warranty, or take any responsibility for the functionality, content, or end-user support of third-party apps provided with your device. By using an app, you acknowledge that the app is provided as is.

Downloading of maps, games, music and videos and uploading of images and videos may involve transferring large amounts of data. Your service provider may charge for the data transmission. The availability of particular products, services and features may vary by region. Please check with your local dealer for further details and availability of language options.

Certain features, functionality and product specifications may be network dependent and subject to additional terms, conditions, and charges.

All are subject to change without notice.

HMD Global Privacy Policy, available at http://www.nokia.com/phones/privacy, applies to your use of the device.

HMD Global Oy is the exclusive licensee of the Nokia brand for phones & tablets. Nokia is a registered trademark of Nokia Corporation.

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by HMD Global is under license.

All other trademarks are the property of their respective owners.

© 2018 HMD Global Oy. All rights reserved.