


Getting to know your phone

Welcome to the brand new world of your **HUAWEI Ascend P6** smartphone! Before we begin, let's take a quick look at the **P6** and its external features.

 Use the headset delivered with your phone.



Installing the micro-SIM and microSD cards



Only micro-SIM cards are compatible with your **P6**. To purchase or replace a micro-SIM card, contact your service provider.

Before installing the micro-SIM or microSD card, take out the eject tool from the headset jack. Insert the end of the eject tool into the hole next to the micro-SIM or microSD card tray to release it. Then, follow the directions on the card tray to install the micro-SIM or microSD card.

After you complete these steps, you are ready to use **P6**. Press and hold the power button for a few seconds until **P6** vibrates to power it on.

i Be careful when using the eject tool to avoid hurting yourself or damaging the phone. Keep the eject tool away from children.

i Don't insert or remove the micro-SIM card when your phone is powered on.



Inserting the SIM card




i Apply pressure to the front end of the SIM card to make sure it's not protruding out as you insert the tray into the card slot.

ii Once the front end of the card has been inserted, apply pressure to the rear end of the card and fully insert the tray into the slot.

Using the buttons

From any screen, you can:


- Touch  to return to the previous screen or exit an application.
- Touch  to return to the home screen.
- Touch  to display recently used applications.
- Press the power button once to turn the screen on or off. Press and hold the power button for 10 seconds or more to restart your phone.
- Press the power and volume down buttons at the same time to take a screenshot.



Managing contacts

Touch  to access **People**.

If you are using your **P6** for the first time, tap  > **More > Manage contacts** to import contacts from a storage device to the phone. Touch the **Groups** tab to group your contacts for easier management.




Making a call

Touch  to access **Phone**.

Dial the phone number you wish to call or touch  to choose someone from your contacts.

You can also dial a phone number directly from a message, email, or web page by simply touching the number.




Sending a message

Touch  to access **Messaging**.

You can text your contacts or send a photo or audio clip in a multimedia message.

After you receive multimedia messages, you can save the photos and audio clips in these messages.



Taking a photo

Touch  to access **Camera**.

Your **P6** features a BSI HD camera that lets you take photos in several modes, such as smart, beauty, and HDR. To capture your most attractive smiles, your **P6** provides face detection.

The camera automatically focuses on certain objects. To focus on a particular object, touch it on the viewfinder.

Then, touch  to take a photo.




Open the settings menu

View your photos

Recording a video

Touch  to access **Camera**, and switch to video mode. Recording in 1080p full HD means stunning image quality and smooth video shots. Touch  to begin recording.



Viewing photos

Touch  to access **Gallery**.

Browse photos you have taken and relive those perfect moments.

To play your photos in a slideshow, choose an album and touch  > **Slideshow**.


To edit a photo, touch . You can then crop it, adjust its color, apply filters to it, and more.



Sending an email

Touch  to access **Email**.

Once you have set up your email accounts, you will be able to stay connected while on the go.



Listening to music


Touch  to access **Music**.

Your **P6** features Dolby Digital Plus, which produces superior surround sound through the stereo earphones provided.

It makes high-pitched sounds clearer and low-pitched sounds more natural. In addition, the speaker is optimized to provide you with a supreme audio experience.

To turn on Dolby Digital Plus, touch .

Play your songs by name, artist, or album, and mark your favorite songs to add them to the **My favorites** list.



More information

Need more help using P6?

Touch  on your **P6** to open **Help Center**.

Want to browse the user guide?

Visit www.huaweidevice.com/worldwide to download the *HUAWEI Ascend P6 User Guide*

Note

This guide is for reference only. The actual product, including but not limited to the color, size, and screen layout, may vary. All statements, information, and recommendations in this guide do not constitute a warranty of any kind, express or implied.