



WRANGLER

Quick Start Guide
Guía Rápida de Inicio



-  Make a Phone Call
-  Send a Message
-  Adjust Volumes/Ringtone Settings
-  Mobile Email
-  Add/Edit Contacts
-  My Contacts Backup
-  Use Camera
-  Use WAP Browser
-  Customize Phone Appearance
-  SetUp Bluetooth
-  Voice Commands (VR)
-  Download Application



1 Side Key→Volume up

3 Side Key→**easyedge**SM

5 Speaker

7 Side Key→Voice Commands

9 Earphone Jack

11 Battery Cover Lock

2 Side Key→Volume down

4 Micro-USB

6 External Screen

8 Side Key→Speaker phone switch

10 Receiver

12 Camera



	Pick up Send a call Access call memory (Redial) (short key press)
	Left Softkey Right Softkey
	Navigation Key Confirm an option (press the center of the key) Access main menu (short key press)
	Camera Key
	Back Key
	From main screen - Short key press: * - Press the Center Navigation Key, and then press the * key: Lock the phone - Press the Left Softkey, and then press the * key: Unlock the phone

4 Getting to know your phone

	In Edit mode: - Short key press: Access the Symbols table
	From main screen - Short key press: # - Long key press: Activate/deactivate Vibrating Mode In Edit mode: - Short key press: Change input methods
	From main screen - Short key press: 0 In Edit mode: - Space or 0

How to Use Your Phone

The call and messaging features on your phone are easy to use.

Make a Phone Call

1. From the idle screen, the idle screen, use the keypad to dial a number. You can also press the Left Softkey **[Contacts]** to access and open your contact list.
2. Press  on the keypad to dial the phone number.

Send a Text Message

1. From the idle screen, press the Right Navigation Key.
2. Select **Text Messaging**, and then select **New Text Message**.
3. When you finish writing the message, press the Left Softkey **[More]**.

4. Select **Send to**.
5. Enter the phone number or select from **Contact**.
6. Press the SEND Key.

Creating a picture message

You can create a picture message and send it to your family and friends. If the picture file size exceeds 1MB, an error message is displayed.

1. Press the Right Navigation Key, and then select **Picture Messaging**.
2. Select **Create Picture Message**.
3. Enter the phone number or press the Center Navigation Key [**Menu**], and then add a name from **Contacts**.
4. Select a contact by entering the first letter or two of the person's name and select **OK**.
5. Select a photo, and then press the Center Navigation Key [**Menu**].
6. Select **Insert**, and then select **Picture**, **Ringtone** or **Other**.
7. If desired, enter text under the photo.
8. Press the SEND Key.

Adjust Volumes/Ringtone Settings

You can adjust sound settings and make your phone suit your style with unique ringtones for incoming calls and notifications.

1. From the idle screen, press the Center Navigation Key [**Menu**].
2. Select **Profiles**.
3. Select from **Normal**, **Loud**, **Vibrate**, **Silent**, and **Airplane Mode**.
4. From here, you can adjust the ringtone, volume and other features.

Mobile Email

Mobile Email gives you access to your personal Email accounts such as Yahoo!, MSN, AOL and Gmail. Mobile Email works with any Email solution. If your Email service provider is not listed, you can manually enter the Email server address to add your account. Mobile Email even notifies you when a new message arrives in your inbox.

Download Instructions from easyedgeSM Catalog

1. From the idle screen, press the Center Navigation Key **[Menu]**.
2. Select the **easyedgeSM** icon.
3. Select **Browse the Shop**.
4. Select the appropriate folder (Mobile Email is in the My Data Apps folder).
5. Select **Free Mobile Email**.
6. Select **Get Pricing**.
7. Select purchasing option (**Free**).
8. Download will commence and the application will install on your device.

Automatic Email Account SetUp

1. Launch the application and follow the onscreen prompts.
2. Select an Email account provider.
3. Enter your user identification and password. Your Email account will sync, and the Email inbox will be displayed.

POP and IMAP Email Account Manual SetUp

1. Launch the application and follow the onscreen prompts to access the Email account provider screen.

2. Select **More**, and then select **Other**. In the text fields, enter your Email address, password and user name.
3. Next, you will be prompted for additional Email account and company IT network information. Select “next”.
4. Select protocol (**IMAP** or **POP**).
5. Enter incoming server settings, and then select **next**.
6. Enter outgoing server settings, and then select **next**.
7. Your Email account will sync, and the Email inbox will be displayed.

Add/Edit Contacts

To add a contact:

1. From the idle screen, press the Left Softkey.
2. Select **Options**, and then select **Create New Contact**.
3. Enter the contact's information, and then select **Edit**.
4. When you're finished, select **Save**.

To edit a contact:

1. Select the contact and enter the contact's information.
2. Select **More**, and then select **Edit**.
3. When you're finished, select **Save**.

My Contacts Backup

Download My Contacts Backup, so if your phone is lost or stolen, you can easily transfer your numbers to a new phone.

Access My Contacts Backup

1. Access the **easysedge** catalog (via the home screen shortcut or the menu options).
2. My Contacts Backup is added to the list of downloaded applications.
3. Select **My Contacts Backup** to launch it.

Set Up My Contacts Backup

1. After the application is launched, a Welcome Screen is displayed.
2. Select **next** to continue. You must accept the terms and conditions to proceed to the set up screen.
3. You will be prompted to enter your pin. By default, the pin is last 4 digits of your CTN.
4. If you have contacts saved to your device, you can back up contacts stored on the device to My Contacts Backup server by selecting **Backup** from the application main screen.
5. From the Set Up menu, you can view your account information, set automatic backups to occur, change pin, change language, and view the help section of the application.

Note: My Contacts Backup: **easysedge** Pay-As-You-Go users who incur data access charges for My Contacts Backup while roaming should dial 611 for a bill credit.

Use Camera

1. From the idle screen, press Camera Key  to activate the camera.
You can also access the camera by selecting the Camera icon from the idle screen.
2. Focus on the object and select **OK**.
3. Select **Options** , and then select **Save As Picture**.
4. To view the taken picture, press the Camera Key  .
5. Select Pictures to access PictureView.

Note: Your photo will be saved automatically to **PictureView on your phone's memory**. Please follow local laws and regulations when using your phone to take pictures.

Use Browser

1. From the idle screen, press the Center Navigation Key [**Menu**].
2. Select **Browser**.
3. Select **Home Page** to enter m.uscellular.com
4. Select **Enter URL** to enter new web address.
5. Select **Search** to search via Yahoo!, Bing, or Google.

Customize Phone Appearance

You can customize various display settings to fit your personality.

Change Wallpaper

1. From the idle screen, press the Center Navigation Key [**Menu**].
2. Select **Setting**, and then select **Display**.

3. Select **Wallpaper**. You can set wallpapers, your own photos, or live wallpapers as your background.
4. From the Gallery, select the wallpaper that you like.
5. Select Options, and then select Use As.
6. Then select OK to set the picture as your new wallpaper.

Change Themes

1. From the idle screen, press the Center Navigation Key [**Menu**].
2. Select **Setting**, and then select **Display**.
3. Select **Themes**.
4. Select the theme you like.

SetUp Bluetooth

Take advantage of the freedom of Bluetooth wireless technology with your phone.

1. From the idle screen, press the Center Navigation Key [**Menu**].
2. Select **Tools & Games**, and then select **Tools**.
3. Select **Bluetooth**.
4. You will need to turn Bluetooth on.
5. Select Options, and then select **Device Search**.
6. Select the name of the device you wish to pair with.
7. Select Options, and then select **Pair** to pair and connect.

Voice Command (VR)

The VR (Voice Recognition) feature allows you to make calls or use the phone's functions by simply using your voice. All you have to do is talk into the phone, and the phone will recognize your voice and complete tasks by itself.

Using VR (Voice Recognition)

1. To enter the voice recognition menu, press the Right Side Key up.
2. The phone displays the Command menu and prompts you to say the name of the command you want to use.
3. To complete your task, simply follow the voice prompts. You can say the name of the command after you hear a beep.
4. Select **Tutorial** to listen to additional information on using voice recognition.

Call <Name or #>

1. Say **Call <Name>**.
2. Your phone will ask you to confirm the name you said. Say "Yes", if it was repeated correctly.
3. The person's phone number will be dialed. If there is more than one number saved for contact, you will be asked to confirm which number to dial.

Send text <Name or #>

Say **Send Text <Name>**. For example, to send text to Tom, say "**Send Text Tom**".

Send picture <Name or #>

Say **Send Picture <Name>**. For example, to send a picture to Tom, say "**Send Picture Tom**".

Lookup <Name>

1. Say **Lookup <Name>**. For example, to look up to Tom, say “**Lookup Tom**”.
2. The **View Contact** page will be displayed for the contact name.

Go to <Menu>

1. Say **Go To <Menu>**. For example, to access the alarm, say “**Go to Alarm Clock**”.

Check <Item>

1. Say **Check <Item>**. For example, to check time, say “**Check Time**”.

Download Applications

From the idle screen, press the Center Navigation Key [Menu].

1. Select **easyedgeSM** to launch it.
2. Select your favorite application to download from **easyedge shop**.
3. Find and start it from **my stuff**.
4. Select **Option** to view more: **Launch/ View info/ Delete/ Check upgrade/ Sort by Date/ Name**.

