

S40 Shortcuts



Silent Mode: Press menu, then the * (star) key.



Key Lock: Press menu, then the # (pound) key.

Auto Redial: Press and hold the 0 (zero) key to redial your last outgoing call.

Checking Voicemail: Press and hold the 1 (one) key.

Mute Call: Press menu while on a call, then press the ok key.



Hold Call: During a call, press menu, scroll down to the "hold call" option, then press the ok key.



Quick Phone Book Access: Scroll down to phone book entries, enter the letter of the entry's name on the respective key and the corresponding lettered names will appear.

Quick Phone Book Calling: Find the phonebook entry you are trying to call and hold the "detail" menu button down until S40 begins to connect the call.

Quick SMS Text Message Reply: When replying to an SMS message and the original message is not needed, simply hold the clear key until original message is deleted.

Switching from T9 to ABC mode while creating SMS message: Press the side key on the right-hand of the phone.

To View Time/Date in full screen format: Quickly press the on/off key.

A tip: When charging the S40 for the first time, it will take several seconds for the charging indicator to appear on the phone. When it does appear, the symbol will switch from a battery symbol to a lightening bolt which shows the battery is being charged. When the symbol changes to only a battery, this indicates that the battery is completely charged.