



• GETTING STARTED

Getting Started

Your VINCI Tab is ready to enjoy. Turn on, unlock and explore.

1. Press & hold the *power* button until the screen turns on.
 2. Slide the lock icon up to unlock the screen.
 3. Tap an app on the home page to enjoy games, story books and music videos.
- Press the *power* button to go in and out of sleep mode.
 - Press and hold the *power* button for 5 seconds to reset your VINCI Tab.
 - Press the *Menu* button to access system settings.

Charging

- Make sure your VINCI Tab is turned on when charging.
- Use the included micro USB to USB cable and travel charger to charge your VINCI Tab.



Please Note:

- Your VINCI Tab may demonstrate unexpected behavior if played while charging.
- Usage and standby times will vary based on the applications used.



• USING VINCI TAB

VINCI Early Learning Apps

VINCI Apps are based on Age Norms, covering all developmental aspects of a growing child. For activities best suited for your child, check recommendations at www.VINCIGenius.com/curriculum

Register & Download Tab Manager

VINCI Tab Manager software completes the VINCI experience. It allows you to transfer files to and from your VINCI Tab and gives you access to updates and support. Just connect your VINCI Tab to your computer and go to: www.VINCIGenius.com/support
The on-screen instructions will guide you to register your VINCI Tab and download the VINCI Tab Manager software.



• ABOUT VINCI TAB

Cleaning Your VINCI Tab

Wipe your VINCI Tab with a dry, lint-free cloth. Do not use liquids, chemicals or detergents. To remove food or juice residue, use a slightly damp, lint-free cloth with warm water and wipe the area.

Technical Specifications:

Dimensions: (H) 7.25", (W) 10", (D) 0.625"

Weight: **VH-2001** 1.37 lb (620 g) / **VL-1001** 1.26 lb (570 g)

Display: 7" Multi-Touch display

Processor: Cortex A8

Battery: Rechargeable lithium-polymer

Memory: 512 MB RAM

Camera: 3 megapixel rear-facing

Operating System: Android OS 2.3

Warranty:

12 months parts and labor from date of purchase. Warranty is valid for defects during normal use. Accidental damage of the touch screen is not covered by the regular warranty.

QUICK GUIDE

WARNING: Your VINCI Tab contains fragile electronic components. Do not twist, disassemble, drop from a high place or onto a hard surface. Avoid extreme heat and do not submerge in water.

Customer Care Center:

Phone: 1-855-MY-VINCI

Email: contact@vincigenius.com

Live Chat: www.VINCIGenius.com/support

VINCI™, VINCI Tab™ and VINCI Tab Manager™ are all trademarks of Rullingnet Corporation. All content and images © 2011 Rullingnet Corporation. Patents Pending: 12/892,052, 12/908,390, 12/941,115, 29/318,313.



Rullingnet Corporation
1637 16th St.
Santa Monica, CA 90404

Housing Material Safety:
FDA 21 CFR 177.1580
Handle Material Safety:
USP Class VI, ISO 10993
Product Safety: ASTM F963
Other Compliances: FCC, CE



Model VH-2001 / VL-1001

