

Z079584506901




www.zteusa.com

Z936L

 *Bringing you Closer*

3. Carefully slide the tray back in place.



The diagram illustrates the ZTE N9500 smartphone from both front and back perspectives. The front view shows the screen displaying a landscape wallpaper, the status bar at the top, and the dock with five icons. The back view shows the camera, flash, and ZTE logo. Labels with leader lines identify the following components:

- Indicator Light**: Located at the top center of the front face.
- Proximity Sensor**: Located at the top center of the front face, below the indicator light.
- Front Camera**: Located at the top left of the front face.
- Volume Up/Down Key**: Located on the left side of the front face.
- Touch Screen**: The main display area of the front face.
- Back Key**: Located at the bottom left of the front face.
- Home Key**: Located at the bottom center of the front face.
- Earpiece**: Located at the top right of the front face.
- microSDHC Card Tray**: Located on the right side of the front face.
- micro-UM Card Tray**: Located on the right side of the front face, below the microSDHC card tray.
- Power/Lock Key**: Located on the right side of the front face.
- Flash**: Located at the top left of the back face.
- Camera**: Located at the top center of the back face.
- Headset Jack**: Located at the top right of the back face.
- Recent Apps Key**: Located at the bottom right of the front face.
- Micro USB Charging Port**: Located at the bottom center of the front face.
- Microphone**: Located at the bottom center of the front face, above the charging port.
- Speaker**: Located at the bottom center of the back face.

	No signal		Alarm set		New SMS		Storage removed
	Signal strength		Ringer off		New MMS		microSDHC card unmounted
	4G LTE connected		Vibration mode		New email		Upcoming event
	Battery empty		Airplane mode		New Gmail message		Downloading data
	Battery low		Wired headset connected		Updates available		GPS on
	Battery partially drained		Bluetooth on		Problem with SMS/MMS delivery		USB connected
	Battery full		Connected to a Wi-Fi network		Missed call		Call in progress
	Battery charging		Wi-Fi in use		Song is playing		


ZTE and the ZTE logos are trademarks of ZTE Corporation. Google and Android are trademarks of Google, Inc. The Bluetooth® trademark and logos are owned by the Bluetooth SIG, and any use of such trademarks by ZTE Corporation is under license. The microSDHC logo is a trademark of SD-3C, LLC. Other trademarks and trade names are the property of their respective owners. Qualcomm® Snapdragon™ processors are products of Qualcomm Technologies, Inc. Qualcomm and Snapdragon are trademarks of Qualcomm Incorporated, registered in the United States and other countries. Used with permission. Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.

QSG 2079584506091

*In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

Blasting Caps and Areas
Power off your mobile phone or wireless device when in a blasting area or in areas posted power off "two-way radios" or "electronic devices" to avoid interfering with blasting operations.


1. Press if the current screen is not the home screen.
2. Tap .
3. Slide left or right on the screen and tap an app to open it.



Connecting via Wi-Fi

1. From the home screen, tap  > **Wi-Fi**.
2. Slide the **ON/OFF** switch if Wi-Fi is off. Your phone automatically searches for Wi-Fi networks in range and displays their names and security settings. Your phone also connects to previously linked networks when they are in range.
3. Tap a network name to connect to it.
4. If the network is secured, enter a password or other credentials (ask your network administrator for details) and tap **Connect**.

1. From the home screen, tap > > **Mobile networks**.
2. Check **Data enabled**.



- Full attention must be given to driving at all times in order to reduce the risk of an accident. Using a phone while driving (even with a hands free kit) can cause distraction and lead to an accident. You must comply with local laws and regulations restricting the use of wireless devices while driving.


This screenshot shows the iPhone's Phone app. At the top, the contact 'Lisa Johnson' is displayed with her profile picture, phone number '011 234 567 890', and email 'lisa.johnson@icloud.com'. Below this is a large black dial pad with white numbers 1-9, *, 0, and #. Above the numbers are labels: '1' for 'voicemail', '2' for 'ABC', '3' for 'DEF', '4' for 'GHI', '5' for 'JKL', '6' for 'MNO', '7' for 'PQRS', '8' for 'TUV', and '9' for 'WXYZ'. At the bottom of the dial pad are icons for 'Recent' (blue), 'Favorites' (green), 'Voicemail' (blue), and 'More' (grey). A red 'End' button is at the very bottom. The status bar at the top shows the time as 8:30 AM and battery level at 83%.

The screenshot shows the Windows Phone 8.1 Start screen. The background is a live tile titled "Nature" showing a close-up of green grass. At the top, the status bar displays "Signal", "Wi-Fi", and "Battery" icons. Below the status bar, the "Start" screen features several tiles: a "Clock" tile showing "12:00 PM", a "Weather" tile for "London, UK" showing "15°C", a "Calendar" tile for "July 2015", a "Reminders" tile, a "Contacts" tile, a "Calendar" tile for "July 2015", and a "Calendar" tile for "July 2015". At the bottom, there is a "Wallpapers" button and a "Set wallpaper" button.

1. From the home screen, tap > .


NOTE: If another email account is already set up, press > > **Add account** > **Email**.

2. Enter the email address and password.
3. Tap **Next** and follow the on-screen instructions.




Air Bags
Do not place a phone in the area over an air bag or in the air bag deployment area as an airbag inflates with great force and serious injury could result. Store the phone safely before driving your vehicle.


Please don't text and drive.



3. Select an account in which to save the contacts.
4. If prompted, choose to import one, multiple, or all vCard files.
5. If prompted, tap **OK**.



8. The app is successfully installed when the icon appears in the status bar. You can find the new app after pressing > .




- Do not disassemble or crush, bend or deform, puncture, or shred.
- Do not modify or remanufacture; attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.
- Only use the battery for the system for which it is specified.
- Only use the battery with a charging system that has been qualified with the system per CITA Certification (IEEE 1725).
- Do not use the battery with a charging system that is not qualified with the system per CITA Certification (IEEE 1725). Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- Do not short-circuit a battery or allow metallic conductive objects to contact battery terminals.
- Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-1725.
- Do not use the battery with a charging system that may present a risk of fire, explosion, leakage or other hazard.
- Promptly dispose of used batteries in accordance with local regulations.


The screenshot shows the Flow app interface. At the top, the status bar displays '5G', signal strength, and the time '11:30 AM'. The app header includes the text 'Flow' and 'Discover'. Below the header is a music player interface. The album artwork for 'Brie' is displayed in the center. Below the artwork, the text 'Place lyrics and music in the same folder' is visible. At the bottom, the playback controls are shown, including a progress bar with a green slider, and buttons for previous, play/pause, next, and favorite. Annotations with lines pointing to specific features are as follows:

- Song and artist information**: Points to the 'Flow Discover' header.
- Access additional options**: Points to the three-dot menu icon in the top right corner.
- Tap to toggle shuffle and repeat mode: no repeat, repeat the current song, or repeat the current playlist**: Points to the shuffle and repeat icons in the top right corner.
- Album artwork**: Points to the album artwork for 'Brie'.
- Tap to open the current playlist**: Points to the playlist icon in the bottom left corner.
- Tap to add a song to the Favorite playlist**: Points to the star icon in the bottom right corner.
- Playback control: Skip songs or pause and resume playback. Drag the slider to jump to any part of the song.**: Points to the playback controls at the bottom, including the progress bar and skip/pause/next buttons.

TIP: While the recording is in progress, you can tap to save the frame as a photo.



Computer



NOTE: The content you can access in the Play Store depends on your region and your service provider.