ZTE Maven™ 3

Let's get started

AT&T 4-Star Eco-Rating 2.0
att.com/ecospace

WIRELESS EMERGENCY ALERTS CAPABLE™


AT&T Eco Rating 2.0 only applies to ZTE Maven 3. For limited factors evaluated visit att.com/EcoSpace. Wireless Emergency Alerts is a registered Trademark and Service Mark of CTIA.

ZTE, Maven, and the ZTE logo are trademarks of the ZTE Corporation. LTE is a trademark of ETSI. 4G LTE not avail. everywhere. Contains Lithium ion battery – recycle or dispose of properly. ©2017 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks are the property of their respective owners.


Printed in USA 081704100720

Device Help

From the home screen, swipe left and tap .



Swipe down to view and make changes to connectivity, app, and battery settings.



The expanded screen allows you to view additional available options to adjust your device settings.

Note: Always use the charger included with your device for optimal battery performance. Standby and use time may vary depending on your current usage patterns, settings, and other factors and conditions.

What's in the Box?

- ZTE Maven™ 3
- Lithium-ion Battery
- Pre-installed SIM Card
- Quick Start Guide
- Safety & Warranty
- Charger
- Micro-USB Cable

Useful Apps*

DriveMode®
Silence notifications, set an auto-reply so people will know you're driving, and more.

myAT&T
Manage your AT&T Wireless, U-verse®, home phone, and Internet accounts with your smarphone.

Setup & Transfer
Transfer your content (contacts, pictures, videos, music, messages, and more) from your old device to your new device wirelessly.

Visual Voicemail
Receive voicemail messages in an email-like inbox. You can easily play and delete messages, return calls, and manage voicemail features.

YP
The real Yellow Pages helps you connect instantly with great local businesses.

*Compatible device and subscription may be required. Data and messaging rates may apply. Restrictions and limitations may apply. For more app information, go to **https://att.com/shop/apps**.

Find More Information

Manage Your Account with myAT&T
- On your phone: **Apps > myAT&T**
- On the web: **att.com/myprepaid**

Compatible device and online account required. Data and messaging rates may apply for download and app usage.

Need More Help?
- On your phone: **Apps > Device Help**
- On the web: **att.com/DeviceHowTo**

Give Us a Call
- 611 from any AT&T wireless phone
- 800.331.0500 or prepaid 800.901.9878



Need more help?
Go to **Apps > Device Help**


Easily Adjust Settings

Settings Menu

From the home screen, tap ⋯ **> Settings**.

Quick Settings

1. Use two fingers to swipe down from the top of any screen to access the Quick Settings menu. Swipe left to view more settings.
2. Press and hold an icon to view the full Settings menu for that function, if available.



Capture Life's Moments

Take a Picture




1. From the home screen, tap .
2. Tap ⚙ to adjust your camera settings. Zoom in and out by pressing the **Volume up key** or **Volume down key**.
3. Tap ◯ to take a photo.

Record a Video



1. In camera mode, tap **VIDEO >** ⚙ to adjust your camcorder settings.
2. Tap ● to start and tap ■ to stop recording video.

Share a Picture or Video



1. From the home screen, tap ⋯ **> Photos**.
2. Tap a photo or video.
3. Tap the screen **>** ⤴ and select an option for sharing.


Let's Set Up Your Phone

Install a Nano-SIM/microSDHC™ Card

1. Remove the back cover via the notch at the bottom corner of the phone, and then remove the battery via the notch below it.

Note: Your new prepaid nano-SIM card is preinstalled. If you are an existing AT&T customer, replace it with your current SIM (see instructions below). If your SIM does not fit, use the new SIM that is already inserted, and call Customer Care at 800-331-0500 (follow prompts to speak to a representative).

2. Insert the nano-SIM card with the cut corner first and the gold-colored contacts facing down.




3. Insert the microSDHC card (sold separately) with the gold-colored contacts facing down.
4. Insert the battery, making sure the connectors align. Gently push down on the battery until it clicks into place.
5. Replace the back cover.

Turn On Your New Phone

Follow your phone's on-screen setup instructions.

Call Family & Friends

Make a Call



1. From the home screen, tap .
2. Enter the name or phone number of a contact in the search box at the top of the screen, or tap ⋯ and enter a phone number.
3. Tap ✆ to place the call.

Check Voicemail



1. From the home screen, tap **>** ⋯.
2. Press and hold the **1 key**.
3. Follow voice prompts to listen to messages.


Surf & Stream in No Time

Connect to Wi-Fi®



1. From the home screen, tap ⋯ **> Settings > Wi-Fi**.
2. If Wi-Fi is off, tap ⬭ to enable it.
3. Tap a network name. Enter a password if required, and then tap **CONNECT**.

Use Bluetooth®



1. From the home screen, tap ⋯ **> Settings > Bluetooth**.
2. If *Bluetooth* is off, tap ⬭ to enable it.
3. Your phone will automatically search for devices. Tap the name of a device to pair and connect with it.

Data rates may apply.