

Get *Started*

All you need to know to get going.

Sprint **VITAL™**



BC

Welcome!

Thanks for choosing Sprint. This booklet introduces you to the basics of getting started with Sprint and your Sprint Vital™.

ReadyNow – For more help in getting up and running with your new phone, take advantage of exclusive **Ready Now** resources at **sprint.com/readynow**. You can even schedule a one-on-one appointment at a Sprint Store near you.

*For ongoing support and resources, visit **sprint.com/support**. There, you'll find guides, tutorials, and more to help you get the most out of your phone.*

***Note:** Available applications and services are subject to change at any time.*

Using This Guide

This Get Started guide is designed to help you set up and use your new Sprint Vital. It's divided into four sections to help you find the information you need quickly and easily.

■ Get Ready — page 1 — *Find out what you need to do before you use your phone the first time, including inserting a battery and activating Sprint service on your phone.*

■ Android Basics — page 4 — *Learn some basics about how to move around on your phone, use the home screen, and enter text. If you're familiar with Android phones, you can probably skip these pages (although a refresher course never hurt anyone).*

■ Use Your Phone — page 12 — *Take advantage of your phone's features and Sprint services, from the basics (making calls) to the more advanced (using Google Play™, WiFi, and more).*

■ Tools & Resources — page 29 — *Find useful tips for your phone and discover resources and other helpful Sprint information. For additional information including the full User Guide, videos, tutorials, and community forums, visit sprint.com/support.*

Your Sprint Vital



Get Your Phone Ready

Before you start: Visit sprint.com/readynow to learn about transferring contacts, calendars, and more from your old phone.

Install the Battery

1. Insert the battery, contacts end first, and gently press the battery into place.
2. Replace the back cover.

Charge the Battery

1. Insert the USB cable into the AC adapter.
2. Insert the small end of the USB cable into the charger/accessory jack on the left side of the phone.
3. Plug the AC adapter into a standard AC power outlet.

Turn the Phone On

- Press and hold the Power button.

Unlock the Screen

- Touch and hold  to unlock it.

Turn the Screen On and Off

- To quickly turn the display screen off, press the power button on top of the phone.
- To turn the screen on and display the unlock screen, press the power button.

Turn the Phone Off

- Press and hold the power button and then touch **Power off** > **OK** to turn the phone off.

Activate Your Phone

Activate Your Phone



If you purchased your phone at a Sprint Store, it is probably activated and ready to use.



*If you received your phone in the mail, and it is a new Sprint account or a new phone number, your phone is designed to activate automatically when you first turn it on. You will see a **Hands Free Activation** screen at startup. When it's finished, touch **OK** to continue. To confirm your activation, make a phone call.*



If you received your phone in the mail and it is going to be activated on an existing number (you're swapping phones), go to sprint.com/activate and follow the instructions. When you have finished, make a phone call to confirm your activation.

When you have finished, if your phone is still not activated or you do not have access to the Internet, contact Sprint Customer Service at **1-888-211-4727** for assistance.

Phone Basics

These instructions help you set up various options and applications, including setting up your Google™ Account.*

Sprint Default

Shortly after activation, you will be prompted to install the Sprint Default ID. Tap **Install** to download now or tap **Not Now**.

Set Up a Google Account

Setting up a Google Account lets you access many features of your Android phone. It also allows you to sync Google contacts and apps you may previously have used.

1. Touch  >  > **Settings** > **Add account** > **Google**.
2. Follow the prompts to set up a new Google Account or sign in to an existing Google Account.

** You do not need to sign up for a Google Account to use your phone; however, to download content from the Google Play™ Store app, you must link your phone to a Google Account.*

Android Basics: Getting Around Your Phone

Move Around Your Phone's Menus and Screens

Your phone's touchscreen lets you control everything through various types of touches, or gestures.

Touch: When you want to type using the onscreen keyboard, select items such as application and settings icons, or press onscreen buttons, simply touch them with your finger. A light touch works best.

Touch and hold: To display the available options for an item simply touch and hold the item.

Flick: Move your finger in lighter, quicker strokes than swiping. This finger gesture is always used in a vertical motion, such as when flicking through contacts or a message list.

Swipe or slide: Quickly drag your finger vertically or horizontally across the screen.

Drag: Press and hold your finger with some pressure before you start to move it. Do not release your finger until you have reached the target position.

Rotate: Activate the auto-rotate feature to automatically change the screen orientation from portrait to landscape by turning the phone sideways.


Pinch and Spread: “Pinch” the screen using your thumb and forefinger to zoom out or “spread” the screen to zoom in when viewing a picture or a Web page.

Your Home Screen

Viewing Your Home Screen

Your phone's Home screen extends horizontally to five full screens. This gives you room to customize your phone and put the things you need front and center, just a swipe away.

- To display the main (center) Home screen, touch  from any screen.
- To view extended screens, swipe the screen left or right. There are two additional screens on each side of the main Home screen.



Status Bar

The status bar at the top of the Home screen lets you quickly see both your phone status (connections, signal strength, battery) and any current notifications.



Notification
area

Phone
status area

Your Home Screen

Notifications Panel

You can expand the notification area to provide more detailed information about the current onscreen notification icons.

1. Drag down the notifications panel to see your notifications.
2. Touch a notification entry to open the associated application.

Add Items to Your Home Screen


1. Touch  and then touch .
2. To add an app shortcut, touch **APPS** and then touch and hold an app icon and drag it to the home screen. To add a widget, touch **WIDGETS** and then touch and hold a widget and drag it to the Home screen.



Buttons and Keys

Buttons and Keys

Just below the touchscreen, you'll find a row of static keys that let you perform specific functions. Above this row is a row of program icons that are available from every Home screen.




- **Home Key** (🏠) – Touch to return to the main Home screen.
- **Back key** (↶) – Touch to return to the previous screen view.
- **Menu key** (☰) – Touch to display a list of the menu options.
- **Phone icon** (📞) – Touch to open the phone screen.
- **People icon** (👤) – Touch to open your contacts list.
- **Apps icon** (🗳️) – Touch to display the applications list.
- **Messaging icon** (💬) – Touch to open the Messaging app.
- **Sprint ID icon** (🆔) – Touch to open the Sprint ID app.

Buttons and Keys

Open Apps

- If an app is on one of your Home screens, just touch it to open it.
- If an app is not available from your Home screen, touch  (if you're not already on the Home screen), touch  to display the apps list, and then touch the app icon from the alphabetical list. You may have to scroll right or left to find the app you're looking for.



Access Recently-Used Apps

Your phone keeps a running list of your most recently used apps.

1. Touch and hold  to open the recently-used apps window.
2. Touch an icon to open an app.

Entering Text With the Onscreen Keyboard

Your QWERTY Keyboards

There are three ways to use the QWERTY keyboard on your Sprint Vital: Android keyboard (traditional typing), Swype, and TouchPal Keyboard. The Swype and TouchPal keyboards give you options to enter whole words quickly. When you select a field that requires text or numbers, an onscreen keyboard will appear. (If you don't see the keyboard when, for instance, you're entering contact information, just touch the field you're working on to bring it up.) The phone's onscreen QWERTY keyboards can be used in either portrait or landscape mode.

Note: To switch between keyboard types, drag the notifications bar down from the top of the screen, touch **Choose input method**, and then touch the method you want to use.

Using Swype to Enter Text

Swype lets you enter words by tracing over the letters in a single motion.

1. Touch an onscreen character, and then, while maintaining your finger onscreen, drag to the next character in the desired word.
2. Repeat this process until the desired characters have been drawn over. Select from an onscreen list of possible word matches (if prompted). This occurs if your current action has generated more than one possible word match.

Entering Text With the Onscreen Keyboard

Typing with Android Keyboard

Entering text using the traditional Android QWERTY keyboard is easy: just touch the letters to type the words.

1. From a screen where you can enter text, touch the input field to reveal the onscreen keyboard.
2. Touch the corresponding onscreen keys to begin typing.
 - If you make a mistake, touch  to erase.
 - To enter numbers or symbols, touch .

Using TouchPal Keyboard to Enter Text

TouchPal Keyboard provides a number of options for entering text, including trace entry (similar to Swype), traditional typing, alternate keyboard formats, and more.

1. From a screen where you can enter text, touch the field to display the keyboard.
2. Enter text by tracing over the letters on the keyboard in a single motion.
 - For a full menu of numbers and symbols, touch .
 - For additional options and settings, touch .

Entering Text With the Onscreen Keyboard

Your Keyboard Settings

You can customize your onscreen keyboard settings to suit your needs:

Touch  > **Settings** > **Language & input** to access the options menus.

- Touch **Default** and touch an option to set a default keyboard (**English (US) Android keyboard**, **Swype**, or **TouchPal Keyboard**).
- To set options for a specific keyboard, touch the Settings icon () next to any of the keyboard options.
- **Android keyboard** options may include Language, General options such as Auto-capitalization and keypress actions, Auto correction options, and Advanced settings.

- **Swype** options may include tutorial, dictionary, and language options. The **Preferences** option lets you access additional settings such as Auto-spacing, Auto-capitalization, and Next word prediction.
- **TouchPal Keyboard** options include a **General settings** menu with keypress and other options; a **Keyboard layout** menu allowing you to choose alternate layouts for TouchPal; a **Smart input** menu for options such as correction, spellcheck, Advanced mode, and TouchPal Curve; **Languages**; a **Dictionary manage** menu that allows you to update, customize, and back up your user dictionary; and a Help & About menu.

Use Your Phone: Make and Answer Calls

Make a Phone Call

1. If the screen is locked, touch and hold  to unlock it.
2. Touch  >  Phone.
3. Touch the digits of the number you want to call on the phone keypad. (The number will appear just above the keypad as you enter it. Touch  to delete one or more digits.)
4. Touch .

Answer an Incoming Call

- Drag  to the right to .

Send a Call Directly to Voicemail

- Drag  to the left to .

Reject a Call and Send a Text Message

1. Drag  up to .
2. Touch a quick message from the list to send it to the caller.

Mute the Ringer on a Call

- Press the volume button on the left side of the phone to mute the ringer.

Set Up Your Voicemail

All unanswered calls are automatically transferred to your voicemail, even if your phone is in use or turned off. You should set up your voicemail and personal greeting as soon as your phone is activated:

1. Touch  > , and then touch and hold  to dial your voicemail box.
2. Follow the voice prompts to create your password and record your name and greeting.

Sprint strongly recommends setting a voicemail password. Without a password, anyone who has access to your phone can access your messages.

Retrieve Your Voicemail

1. Touch  > , and then touch and hold  to dial your voicemail box.
2. Follow the prompts to listen to your voicemail messages.

From any other phone:

1. Dial your wireless phone number.
2. When your voicemail answers, touch *****.
3. Enter your password.

Messaging

Send a Text Message

1. Touch  > **Messaging** .
2. Touch .
3. Enter a phone number, email address, or contact name in the **To** field. (If the phone recognizes a contact, you'll see a list. Touch the contact to complete the address.)
4. Touch **Type message** and then type your message.
5. When you are finished, touch .

Send a Picture or Video Message (Multimedia Messaging)

1. Follow steps 1 – 4 for sending a text message.
2. Touch .
3. Touch a media type (such as Pictures, Videos, Audio, etc.) and then touch an available album.
4. Touch a picture or clip to select it. (For Audio, touch OK.)
5. If you are satisfied with your message, touch .

Note: For information on taking pictures and videos with your phone, see "Camera & Camcorder" on page 20.

Access Messages

1. Touch  and touch **Messaging** .
2. From the Messaging screen, touch the message you want to view.

–or–

1. Open the **Notifications** panel.
2. Touch the message you want to view.

All of your text and MMS messages for a contact are collected in an ongoing "conversation," so when you view a message, you can scroll through the entire history of your messages with that person.

Be a hero. Don't drive distracted.

sprint.com/focusondriving



Focus on driving

Contacts

Your phone's Contacts function (also known as People) lets you access and manage contacts from a variety of sources, including Google and Corporate email accounts, contacts synced from your computer, and old-fashioned contacts entered by hand.

Save a Phone Number

1. Touch  > .
2. Enter a phone number using the onscreen keypad.
3. Touch  > **Add to contacts** > **CREATE NEW CONTACT**.
4. Select an account for the contact. Select **Google** to save the contact to your Google account, which will update automatically across all your Google devices. Select **Phone** to save the contact to your phone only.
5. Touch **Name** and enter a name for the new entry.
6. Touch **MOBILE** (default) to select a label such as **MOBILE**, **HOME**, **WORK**, **WORK FAX**, **HOME FAX**, **PAGER**, **CUSTOM**, etc.

7. Touch **DONE** to complete and save the entry.

Retrieve a Phone Number

1. Touch  >  > **People** , and then touch .
2. Enter the first letter or letters of an entry.
3. Touch the contact to display the contact's phone number(s).

Add a New Entry to Contacts

1. Touch  >  > **People** .
2. Touch .
3. Touch any field and use the onscreen keyboard to enter the name, phone number, and other contact details.
4. Add more data fields or a picture if desired, and touch **DONE**.

Contacts

Edit a Contact Entry

1. Touch  >  > **People**  > [contact you'd like to edit].
2. Touch  > **Edit**.
3. Touch an option:
 - [image icon] to assign a picture to the entry.
 - **Name** to edit the current name.
 - **PHONE** to add or delete a phone number.
 - **GROUPS** to assign the contact to a group.
4. Touch **DONE** to save your updates.

***Note:** To change an information type (for example, to change a Home phone number to a Mobile phone number), touch the type next to the number and then touch an option from the drop-down list.*

***Note:** To add a phone number, email address, or other field to an existing contact, touch **Add another field** at the bottom of the entry and select a data type (such as Email, Address, Website, etc.). To add another phone number, email address, etc., where one already exists, touch **Add new** at the bottom of the information type.*



Your phone's Email applications let you access and manage multiple email accounts simultaneously in one convenient location. Although there is a separate Gmail application, the main email application can manage both Internet-based email services (Gmail™ and Yahoo™) and Corporate Work Email (Outlook®). The phone can also be manually configured to connect to other email systems.

Set Up a Gmail Account

1. Touch  >  > Gmail.
2. Follow the instructions to set up or sign in to a Gmail account.

Note: Although you need a Google Account to use certain features such as Google Play™, you do not have to use Gmail as the default account for your phone.

Set Up an Email Account

1. Touch  >  > Email.
2. If another email account is already set up, touch  > **Settings** > **ADD ACCOUNT**.
3. Enter the **Email address** and **Password** for the email account.
4. Touch **Next** and follow on the onscreen instructions.

Set Up a Microsoft Exchange ActiveSync Account

1. Touch  >  > Email.
2. If another email account is already set up, touch  > **Settings** > **ADD ACCOUNT**.
3. Enter your **Email address** and **Password** information and then touch **Manual setup**.
 - Contact your Exchange Server administrator for required sign-in information.

4. Touch **Exchange**.
5. When prompted to provide additional detailed information, scroll down the screen and touch **Next**.
6. Enter a **Domain\Username, Password, and Server** information.
7. Read the onscreen activation disclaimer and, if prompted, touch **Next**.

***Note:** If the server requires remote control over some of your phone's security features, touch **OK** to allow it.*

8. Configure your **Inbox checking frequency, Days to sync** (days to synchronize between your phone and server), and activate any other email settings, and then touch **Next**.

***Note:** If a screen displays showing the security operations that the server may do remotely to your phone, touch **Activate** to allow these operations from the server through the Email application as a device administrator.*

9. Identify your new account with a unique name and then touch **Next**.

Access Email Messages

1. Touch  >  > **Email** or **Gmail**.
 - If necessary, touch the selection arrow () and touch the email account you want to use.
2. From the inbox, touch the message you want to view.

Send an Email Message

1. Touch  >  > **Email** or **Gmail**.
2. If necessary, touch the selection arrow () and touch the email account you want to use.
3. Touch .
4. Enter an email address in the **To** field.
5. Enter a subject and a message.
 - To add attachments, touch  > **Attach file** and select an attachment. For **Gmail**, touch  > **Attach picture** or **Attach video** to add pictures or videos as attachments.
6. Touch .

Camera & Camcorder

Take a Picture

1. Touch  >  > **Camera**.
2. Aim the camera lens at your subject, and touch .

View Pictures

1. Touch  >  > **Gallery** to view the Camera folders.
2. Touch a picture and then touch  to explore other options. For sharing photos, touch  at the top of the screen.

Record a Video

1. Touch  >  > **Camera**. Slide the camera/camcorder icon on the side or bottom of the screen to switch to the camcorder mode.
2. Aim the lens at your subject, and touch  to begin recording.


3. Touch  to stop recording.

View videos

1. Touch  >  > **Gallery** and select a folder.
2. Touch a video thumbnail and touch  to view the video.

Share Pictures and Videos

1. Touch  and touch  > **Gallery**.
2. Touch a folder of your pictures and videos, and then touch a picture or video to send.
3. Touch  > **See all** and select any of several methods such as **Picasa**, **Bluetooth**, and **Messaging**. Follow the onscreen instructions to send your picture or video clip.



Find sports scores, news, and weather. Shop online. On-the-go access lets you browse full-color versions of your favorite websites.

Go Online

1. Touch  >  **Browser**. The first time, you may be prompted to enter your wireless phone number.
2. From the Sprint home page, select categories, navigate to websites, read blogs, download content, and more.
 - Touch a category to open it.
 - For more options, touch  from any page. Options may include **Bookmarks**, **Save to bookmarks**, **Share page**, **Find on page**, **Save for offline reading**, **Downloads**, **Page info**, **Settings**, and **About browser**.
 - To scroll, slide your finger up or down the page.
 - To zoom in or out, pinch the screen.

Downloading Apps From the Web

You can download Apps while browsing the Web, but you must first set permissions in settings to allow applications from unknown sources. Applications downloaded from the Google Play Store app (see page 23) do not require additional permissions.

1. Touch  >  > **Settings** > **Security**.
2. Select the **Unknown sources** check box.
3. When the Attention dialog box opens, read the disclaimer and touch **OK**.

***Note:** You can choose to save the downloaded applications in your phone's memory or the microSD card installed.*

Connect to a Wi-Fi Network

When you're in range of an available Wi-Fi network you can use your phone's Wi-Fi feature to access the Internet and other data services.

1. Touch  >  > **Settings** .
2. Touch the icon next to **Wi-Fi** and slide to the "on" position to turn Wi-Fi on.
3. Touch **Wi-Fi** and then touch  > **Scan** to display a list of available networks.
4. Touch a Wi-Fi network to connect. If necessary, enter the security key (password) and touch **Connect**.
 - When you're connected to a Wi-Fi network, you'll see the Wi-Fi icon () in the status bar.

***Note:** To quickly toggle Wi-Fi on or off, you can add the Power control widget to your Home screen. You can also toggle **Bluetooth**, **GPS**, **Sync**, and **Brightness** from the power control widget.*



Google Play™ Store App

Find new Android apps, books, movies, and music for your phone on Google Play™.

Download Apps and Games

1. Touch  >  > **Play Store** .
2. The first time you visit the Google Play Store app, touch **Accept** to accept the Terms of Service.
3. To find what you want quickly:
 - Browse through featured apps and games. Scroll through the options or browse by categories within **Apps, Games, Music, Books, Magazines, and Movies & TV**.
 - Search for an app or game. Touch  at the top of the Google Play Store app home screen, enter the name or key word, and then touch  in the bottom right corner.
4. Touch an app or game to read a description and user reviews.

5. Touch **Install** (for free apps) or the price (for paid applications) and follow the onscreen prompts.

***Note:** You must have a Google (Gmail) Account set up on your phone to purchase and download applications from the Google Play Store app.*

Opening Installed Apps and Games

- Touch  > . Locate the downloaded item and touch it to launch. You can also launch from the **Play Store** >  > **My Apps**.

Google™ Mobile Services

Your Sprint Vital provides easy access to a variety of Google services including Gmail™, Google Talk™, Google Maps™, Google Navigation, and YouTube™.

- **Gmail** – The Google mail service. Your Gmail account lets you access many Google-related services as well as the Google Play™. (See “Set Up a Gmail Account” on page 18.)
- **Google Talk** – Google’s instant messaging service. Touch  >  > **Talk** to begin using the service. (If you’re signed in to your Gmail account, you are already signed in to Google Talk.)
- **Google Maps** and **Google Navigation** – The Google location programs let you track your current location, view real-time traffic situations, and receive detailed directions to your destination. They also provide search tools where you can locate places of interest or an address on a vector or aerial map, or view locations in street level. Touch  >  > **Maps** or **Navigation** to begin using the services.
- **YouTube** – View and share videos on one of the Web’s most popular video sites. Touch  >  > **YouTube** to browse through and view available videos. Sign in with your Gmail account to upload your own videos.

Pair and Connect With a Bluetooth®-Capable Device

1. Verify your Bluetooth is active. (Touch  >  > **Settings** > **Bluetooth** and slide the switch to **ON** to turn on Bluetooth.)
2. From the Bluetooth settings page, touch your phone's name if necessary to make it discoverable by other devices. Your phone must be visible to successfully pair with an external phone.
3. Touch **SEARCH FOR DEVICES**. (Your phone will display a list of discovered in-range Bluetooth devices.)
4. Touch a device from the list to initiate pairing.
5. Enter the passkey or PIN code, or verify the shared key, and touch **Pair**.
6. The external device will then have to also accept the connection and enter your or verify phone's PIN code.
7. Once you're paired with a device, your connection should launch. The  and  icons show your current connection status.

Share Contacts, Files, or Pictures Using Bluetooth

1. Open the application containing the file you want to share (for example, touch  >  > **Gallery**).
2. Locate the file or entry you want to share.
 - You can send pictures and videos directly from the camera or from Gallery, Calendar events, Contacts (as vCards), music tracks, and voice recordings. Not all devices will be able to receive all file types.
3. Depending on the application, touch  > **Bluetooth** or touch and hold the file and select **Share** (or **Send**) > **Bluetooth**.
4. Touch the name of the device to which you're sending the file. (If prompted, touch **Turn on** to turn Bluetooth on.)

Adding Music to Your Music Folder

Before you can listen to music with the **Music** application on your phone, you will need to load songs into your Music folder.

1. Use the supplied USB cable to connect your phone to an available USB port on your computer.
2. Open the Notifications panel, touch  and make sure **Media device (MTP)** is the selected mode.
3. On your computer, locate the MTP device, double-click either **SD Card** or **Phone** (depending on where you want to store your files), and open or create the Music folder.
4. Copy music files from your computer to the music folder.

5. When you are done, follow your computer's procedures to safely remove the drive, and then disconnect the phone from the USB cable.

Listening to Music

1. Touch  >  > **Music**.
2. Touch **Artists, Albums, Songs, Playlists, Folders, or GenreList**.
3. Touch a song to begin playing.
 - Use the controls at the bottom to play, pause, or skip songs.

***Note:** Your phone includes additional music playing options, including Google Play™ Music (Play Music) and Sprint Music Plus.*

Social Networking: Facebook, Twitter & More

You can set up and access all your favorite social media apps on the go.

Set Up Social Networking Accounts

Before using your social networking accounts, you may need to download them from the Google Play Store app.

1. Touch  >  > **Play Store** .
2. Browse or search for the app you want to download, for example **Facebook for Android**, **Twitter**, or **Instagram**.
3. Touch the app and then touch **Install**. Follow the prompts to download and install the app.

Use Social Networking Accounts

1. Touch  >  > **Facebook** (or **Twitter**, **Instagram**, etc.).
2. Follow the onscreen instructions to sign into your account, for example, by entering a user name and password.
3. Update your status, post pictures, follow your favorite tweets, and more, all on your Sprint Vital.

***Note:** Touch  to access settings for your apps, depending on the account type.*

***Tip:** You can add Home screen widgets for many social networking apps. Touch  >  > **WIDGETS**, and then touch and hold a widget and drag it to an empty space on a home page.*

Sprint Applications

Access additional exclusive Sprint features right from your phone.

Sprint Music Plus

In addition to the Music application (see page 26), your phone offers Sprint Music Plus, an all-in-one music store and player for full songs, ringtones, and ringback tones.

Get Sprint Music Plus

1. Touch  >  > **Play Store** .
2. Search for “sprint music plus” and follow the prompts to download and install the app.

Use Sprint Music Plus

- ▶ Touch  >  > **Sprint Music Plus**.
 - Touch **My Library** to access all your music, including items you have purchased or loaded onto your phone’s microSD card.

- Touch **Downloads** to access your list of downloaded music.
- Touch **Music Store** to access the music store, where you can search for, sample, and purchase DRM-free music.
- Touch **Ringtone Store** or **Ringback Tone Store** to find and purchase new ringtones and ringback tones for your phone.
- For more information, touch  > **More** > **Help & About**.

Scout™

Scout™ by Telenav is a daily personal navigator that helps you get where you’re going. It lets you see and hear turn-by-turn directions and it can provide important, personalized information about traffic and alternate routes.

Sprint Applications

Get Scout

1. Touch  >  > **Play Store** .
2. Search for “scout” and follow the prompts to download and install the app.

Use Scout by TeleNav

1. Touch  >  > **Scout**.
2. Follow the onscreen instructions to access, launch, and use.

Note: Before using any navigation programs, make sure your phone is set to allow location detection, and then select which sources you want to use.

Touch  >  > **Settings** > **Location services**.
Select **Google’s location service** and/or **GPS satellites** for location sources.

Sprint Zone

Enhance your Sprint experience. The free Sprint Zone application makes it a snap to manage your account, get tips and tricks for your phone, find recommended apps, and more.

1. Touch  >  > **Sprint Zone** .
2. From the Sprint Zone Web page, scroll up or down and touch an item to check your account, read the latest news about your phone, load an application, and more.

Tools & Resources: Settings

Explore ways to customize your phone, set permissions, update your phone, and more in the Settings menu.

Accessing Settings

1. Touch  >  > **Settings**.
—or—

Touch  >  > **System settings**.

2. Select the settings category you want to change.

Categories include:

- Airplane mode
- Wi-Fi
- Bluetooth
- Mobile networks
- Sound
- Display
- Date & time
- Language & input
- Data usage

- Portable hotspot
- More...
- Storage
- Battery
- Apps
- System updates
- Connect to PC
- Activate this device
- Location services
- Security
- Backup & reset
- Add account
- Accessibility
- Developer options
- About phone

For detailed information about settings, please see the User Guide at sprint.com/support.

Battery-Saving Tips

Manage the Display Brightness and Sleep Timeout

- Touch  >  > **Settings** > **Display** > **Brightness** to modify the backlight setting as desired.
- Touch  >  > **Settings** > **Display** > **Sleep** and select a short duration before the phone goes into sleep mode.
- To turn off the screen, press the Power button. The phone will continue to function.

Manage Your Phone's Wireless Functions

Disable the Wi-Fi, Bluetooth, and GPS functions of the phone when you're not using them.

- Use the toggle options in either the Power control widget or the main Settings menu to turn these off when not in use. From the Power control widget, touch **Wi-Fi**, **Bluetooth**, **GPS**, or **Sync** to toggle these options on or off.

For more useful tips about battery care and safety, see the *User Guide* at www.sprint.com/support.

Manage Your Account

Online: www.sprint.com

- Make a payment, see your bills, enroll in online billing.
- Check minute usage and account balance.
- See or modify the details of your Sprint service plan.
- Get detailed instructions and download content.

From Your Sprint Phone

- Touch    to check minute usage and account balance.
- Touch    to make a payment.
- Touch    to access the Sprint Zone, where you can check your account, update your phone, watch video tutorials, or contact Sprint Customer Service.

From Any Other Phone

- Sprint Customer Service:
Dial 1-888-211-4727
- Business Customer Service:
Dial 1-888-788-4727

Resources For Your Phone

- This *Get Started Guide* to get you up and running.
- **Ready Now** – Visit sprint.com/readynow for additional help to get started on your new phone. You'll find more information on basic setup, activation, maximizing your phone's performance, and personalization. Plus, you can even schedule a personalized one-on-one Ready Now appointment at a Sprint Store near you.
- **Online Support** – For ongoing help over the life of your phone, visit sprint.com/support to find videos, tutorials, troubleshooting tips, and the complete User Guide for your Sprint Vital TM.
- **Community** – Visit community.sprint.com to join the discussion about all things Sprint. Here people help each other make the most of their wireless services with tips, forums, blogs, and the latest news.
- **On Your Phone** – Press  >  > **Sprint Zone**  to access account services, Sprint news, phone information, suggested applications, troubleshooting, and more.

Sustainability

At Sprint, environmental responsibility is more than talk. We're continuously working to reduce our carbon footprint and decrease our use of natural resources.

So where is my user guide?

We took the full printed user guide out of the box and put it, along with expanded support resources, online for you. Less paper, more and better information. Just visit sprint.com/support from any computer to access your complete user guide and the rest of our support materials.

What else has Sprint been doing?

Plenty. To find out just what we've been up to, use your phone to scan the QR code below or visit sprint.com/green for more information.



To scan the code, download and install a QR code reader from the Google Play Store app, launch the reader, and aim your phone's camera at the image.



This guide is printed with soy inks and contains up to 30% post consumer paper.

The services described in this guide may require a subscription to a service plan and/or may incur additional charges. Not all services will work on all phones. See sprint.com/coverage for more details.

Portions of this guide are reproductions of work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License.

Important Privacy Message. This phone is capable of determining its/your geographical location. To set controls for access and use of your location information by others, touch  >  > **Settings > Location services.** Select **Google's location service** and/or **GPS satellites** for location sources. Follow any applicable prompts. These settings for the use of location information can be turned on and off. For some applications and services you select, a phone must be turned on and set to allow collection of location information in order to function.

Please be advised that if you use a third party application, the application may collect your personal information or require Sprint to disclose your customer information, including location information (when applicable), to the application provider or some other third party. Sprint's policies do not apply to these third party applications. Please carefully review the application's terms of use and/or the application provider's policies for more information about how the application will collect, access, use or disclose your information before using a third-party application. Terms of use and other policies usually are available on the application provider's website.

©2013 Sprint. Sprint and the logo are trademarks of Sprint. Gmail, Google Talk, Google Maps, YouTube, Android, Google, Picasa, Google Maps Navigation Beta, Google Mobile Services, and Google Play are trademarks of Google, Inc. Other marks are property of their respective owners. Screen images simulated.

Printed in China

079584505395