

Sprint PCS®

The clear alternative to cellular.™

© 2001 Sprint Spectrum L.P. All rights reserved. No reproduction in whole or in part without prior written approval. Sprint, Sprint PCS, Sprint Personal Communication Services, Sprint PCS Phone, Sprint PCS Wireless Web and the diamond logo are trademarks of Sprint Communications Company L.P. All other trademarks are property of their respective owners.

Printed in Japan

Table of Contents

Welcome to Sprint PCS	7
1. Getting Started with Sprint PCS Service	9
▶ Getting Started with Sprint PCS Service	10
▶ Setting Up your Voicemail	12
▶ Setting Up your Sprint PCS Voice Command SM	12
▶ Getting Help	13
▶ Understanding this User Guide	18
2. Getting to Know your Sprint PCS PhoneTM	19
▶ Parts Name	20
▶ Viewing the Display Screen	22
▶ Turning your Phone ON and OFF	25
▶ Using the Battery	26
▶ Entering Information Using Keypad	28
3. Understanding Roaming	33
▶ Understanding How Roaming Works	34
▶ Setting your Phone's Roam Mode	36
▶ Setting an Alert When Roam Charges Apply (Call Guard)	37
4. Making Calls	39
▶ Making Calls	40
▶ Correcting Dialing Mistakes	40
▶ Answering Calls	40
▶ Calling Emergency Numbers	43
▶ Dialing from an Internal Phone Book Memory Location	43
▶ Redialing Last Outgoing Number	43
▶ Using Speed Dial	44
▶ Displaying your Phone Number	44
5. Adjusting Volume	45
▶ Changing Ringer/Key Volume	46
▶ Silencing the Ringer	46
▶ Selecting Ringer Types	47

▶ Setting Alerts	48
▶ Adjusting Volume During a Conversation	49
▶ Setting Melody Tempo	49
▶ Setting Tone Length or Start-up/Power-off Tone	50
▶ Muting a Call	50
6. Managing Call History	51
▶ Viewing the Call History List (Outgoing, Incoming and Missed) ..	52
▶ Making a Call from the Call History List	53
▶ Saving a Phone Number from the Call History List	54
▶ Adding Options to the Entry in the Call History List	55
▶ Erasing Individual Calls or All Call History	56
7. Using Sprint PCS Service Features	57
▶ Using Caller ID	58
▶ Responding to Call Waiting	58
▶ Setting Up a Three-Way Call	59
▶ Forwarding your Calls	60
8. Managing Messaging	61
▶ Setting Up Voicemail	62
▶ Message Types	62
▶ Knowing When you Have Messages	63
▶ Retrieving your Messages	64
▶ Classifying Page/Text Messages	68
9. Using your Internal Phone Book	73
▶ Saving New Entries	74
▶ Adding Multiple Phone Numbers/E-mail/Web Addresses to an Existing Entry	75
▶ Storing and Viewing Long Phone Numbers	76
▶ Storing Short Phone Numbers	77
▶ Finding and Retrieving Numbers	78
▶ Setting Incoming Ringer/Picture to the Phone Book Entry	79
▶ Erasing a Stored Entry	80
▶ Entering Secret Phone Numbers	81
▶ Changing Stored Phone Numbers, E-mail and Web Addresses	81

- ▶ Storing Special Numbers in the Phone Book82
- ▶ Using Different Dialing Methods83

10.Changing your Phone's Display87

- ▶ Changing the Menu Language88
- ▶ Changing the Backlight Time Length88
- ▶ Changing your Standby Mode Display Banner89
- ▶ Setting Font Size89
- ▶ Changing the Display Color90
- ▶ Changing the Contrast Setting90
- ▶ Setting the Animation91
- ▶ Setting the Display for Incoming Calls91
- ▶ Setting the Display for the Standby Mode92
- ▶ Setting Sleep Mode94
- ▶ Displaying the Version Information94

11.Setting your Phone's Security95

- ▶ Locking the Side Key96
- ▶ Locking your Phone97
- ▶ Unlocking your Phone97
- ▶ Changing your Lock Code98
- ▶ Restricting your Calls99
- ▶ Storing Special Numbers100
- ▶ Erasing the Entire Internal Phone Book100
- ▶ Resetting your Phone101
- ▶ Resetting and Locking your Phone through SMS101
- ▶ Changing the Passcode102

12.Personal Information Management103

- ▶ Managing Phone Book104
- ▶ Checking My Profile104
- ▶ Managing Schedules105
- ▶ Using Voice Memo113
- ▶ Setting Up Screen Call115
- ▶ Using Voice-Activated Dialing118

▶ Playing Game	122
▶ Using the Calculator	123
▶ Using the Downloaded Data	124
13.Experiencing Sprint PCS Wireless WebSM	127
▶ The Sprint PCS Wireless Web Browser	128
▶ Launching the Sprint PCS Wireless Web Browser Session	130
▶ Navigating the Sprint PCS Wireless Web	132
▶ Using Special Features within the Sprint PCS Wireless Web	135
▶ Setting up the Sprint PCS Wireless Web Connection	138
▶ Accessing Sprint PCS Wireless Web Updates	142
14.Learning the Settings on your Sprint PCS Phone	145
▶ Viewing the Menus	146
▶ Working within the Menu Structure	149
▶ Defining the Menu Categories	150
15.Selecting your Accessories	161
▶ Overview of Available Accessories for this Phone	162
▶ How to Order	164
16.Knowing Performance and Safety Guidelines	165
▶ Getting the Most Out of your Reception	166
▶ Safety Information: FCC RF Exposure Information	167
▶ Maintaining Safe Use of and Access to your Phone	170
▶ Caring for the Battery	174
▶ Acknowledging Special Precautions and the FCC Notice	175
17.Index	177


Welcome to Sprint PCS

Sprint PCS built the only all-digital, all-PCS nationwide network from the ground up for clearer calls, serving more than 300 major metropolitan areas. We built our network to give you what we believe you really want from a wireless phone: clear sound, private conversations and time-saving features.

And Sprint Personal Communications Services® can do something even more far-reaching — simplify your life. Our advanced technology is designed to grow with your communications needs so that one day, you'll be able to rely entirely on your Sprint PCS Phone™ to stay connected.

This guide will introduce you to our technology and your new Sprint PCS Phone through simple, easy-to-follow instructions. Since you're probably anxious to start using your phone, we encourage you to immediately flip to Section One — Getting Started With Sprint PCS Service. This section provides all the information you need to quickly activate your phone, set up your voicemail and much more. It also contains information on how to contact Sprint PCS should you have questions about service, want to purchase additional products or services, or just check your account balance.

Thank you for choosing Sprint PCS.



1

Getting Started with Sprint PCS Service

Getting Started

1

In This Section

- ▶ **Getting Started with Sprint PCS Service**
- ▶ **Setting Up your Voicemail**
- ▶ **Setting Up your Sprint PCS Voice CommandSM**
- ▶ **Getting Help**
- ▶ **Understanding this User Guide**

This section walks you through the step-by-step basics of setting up service to your Sprint PCS PhoneTM, including activating or unlocking your phone, selecting your Sprint PCS Service Plan, receiving your new Sprint PCS Phone Number and setting up your voicemail.

Once you have completed this section, you're ready to explore the advanced features of your new phone.

Tip:

If you can't recall your lock code, try using the last four digits of your Social Security number or Sprint PCS Phone Number or try 0000. If none of these work, call Sprint PCS Customer Care at 1-888-211-4PCS (4727).

Getting Started with Sprint PCS Service

Determine if your Phone is Already Activated

If you received your phone in the mail or purchased it at a Sprint PCS Center, your phone is probably already activated. All you need to do is unlock your phone.

Unlocking your Phone

Follow these steps to unlock your phone:

1. Press **END/O** to turn the phone on.
2. When "Locked" is displayed on the Main LCD, press **Unlock** (left soft key).
3. Enter your four-digit lock code. For security purposes, the code is not visible as you type.

Activating your Phone

There are two ways to activate your phone. Follow these steps:

- The fastest way is to call from your new Sprint PCS Phone™.
1. Fully charge your battery (see instructions on page 26).
 2. Turn on your Sprint PCS Phone.
 3. Press **Shift *** **2** **TALK** to reach a Sprint PCS Customer Care Advocate. You must be in a Sprint PCS Service Area when making this call.

- ▶ The other way is to call Sprint PCS Customer Care from any phone other than your new Sprint PCS Phone (which isn't yet activated).

1. Call us toll-free at 1-888-715-4588.

During this call you will be guided through the activation process. The call typically takes approximately 30 minutes, but could be longer during peak times. You can streamline the process by reviewing the Clear and Simple Facts brochure and pre-selecting your Sprint PCS Service Plan.

What you Should have Handy When you Call:

- ▶ Your new Sprint PCS Phone
- ▶ The original packaging from your phone
- ▶ Your Social Security number or Tax ID number
- ▶ Your driver's license number
- ▶ Pen and paper to write down your new Sprint PCS Phone Number

Getting Started
1

Note:

The activation process varies in certain Affiliate areas.

Note:

The voicemail setup process may vary in certain Affiliate areas.

Setting Up your Voicemail

All unanswered calls to your Sprint PCS Phone are automatically transferred to voicemail, even if your phone is off or in use. To avoid missing any important messages, you will want to set up your Sprint PCS voicemail box and personal greeting as soon as your Sprint PCS Phone is activated.

To set up voicemail, follow these steps:

1. From the Standby mode, press and hold .
2. Follow the system prompts to create your passcode, record your greeting, record your name announcement and choose whether to activate One-Touch Message Access (a feature that lets you press one key to access messages and bypasses the need for you to enter your passcode).

For more information on accessing voicemail messages, see page 64.

Setting Up your Sprint PCS Voice CommandSM

This feature lets you dial with your voice. Introducing Sprint PCS Voice Command, a new way to make calls and manage information.

To set up your Sprint PCS Voice CommandSM, follow these steps:

1. From the Standby mode, press and hold  (or press  ).
2. Follow the system prompts. And you will be given a Web page address, a user name, and a passcode so you can create your personalized address book for using Sprint PCS Voice Command.

Getting Help

Visit our Web Site

Stop by www.sprintpcs.com to get up-to-date information on Sprint PCS. You can also:

- ▶ Review coverage maps
- ▶ Learn how to use voicemail
- ▶ Access your customer account
- ▶ Purchase accessories
- ▶ Add additional options to your service plan
- ▶ Check out frequently asked questions
- ▶ And much more

Sprint PCS Customer Care

Sprint PCS Customer Advocates are available to assist you 24 hours a day, seven days a week. Simply dial 1-888-211-4PCS (4727) from any phone, or press **Shift *** **2** **TALK** from your activated Sprint PCS Phone while on the Sprint PCS Nationwide Network.

To reach Sprint PCS Customer Care from the main menu:

1. From the Standby mode, press **Menu** to display the main menu.
 2. Highlight **Phone Book**.
 3. Press **OK**.
 4. Highlight **Services**.
 5. Press **OK**.
 6. Highlight **Customer Care**.
 7. Press **OK**.
 8. Press **TALK**.
- or
- Press **Menu** to display the options, highlight **Call** and press **OK**.

Tip:

If you need to reach Customer Care while you are off the Sprint PCS Network, dial 1-888-211-4PCS (4727).

Getting Started
1

Once you dial Sprint PCS Customer Care, you can access a number of helpful account services through our automated Customer Care line. By following the voice prompts, you'll be able to learn more about Sprint PCS Products and Services, get Sprint PCS coverage by zip code or request a copy of your invoice.

Sprint PCS Directory Assistance

Sprint PCS Directory Assistance provides a variety of services, including: residential, business and government listings; assistance with local or long-distance calls; movie listings; hotel, restaurant and shopping information and major local event information. There is a per call charge and you will be billed for airtime.

1. Press **4** **1** **1** **TALK**.

OR

1. From the Standby mode, press **Menu** to display the main menu.
 2. Highlight **Phone Book**.
 3. Press **OK**.
 4. Highlight **Services**.
 5. Press **OK**.
 6. Highlight **Dir Assist**.
 7. Press **OK**.
 8. Press **TALK**
- or
- Press **Menu** to display the options, highlight **Call** and press **OK**.

Prepaid Calls

Prepaid customers can access the Prepaid Options Menu to receive account balance notification, replenish their account or speak with Sprint PCS Customer Care. There are two ways to access the Prepaid Options Menu, free of charge.

1. Press **Shift *** **7** **2** **9** **TALK** .

OR

1. From the Standby mode, press **Menu** to display the main menu .
2. Highlight **Phone Book** .
3. Press **OK** .
4. Highlight **Services** .
5. Press **OK** .
6. Highlight **Prepaid** .
7. Press **OK** .
8. Press **TALK**

or

Press **Menu** to display the options, highlight **Call** and press **OK** .

Tip:

Prepaid Options Menu is only available to Sprint PCS customers that have a Prepaid account.

Getting Started
1

Dialing Sprint PCS Roadside Rescue

If you need emergency service on the road, you can get help from Sprint PCS Roadside Rescue. Follow these steps:

1. Press **Space #** **7** **6** **2** **3** **TALK** .

OR

1. From the Standby mode, press **Menu** to display the main menu .
2. Highlight **Phone Book** .
3. Press **OK** .
4. Highlight **Services** .
5. Press **OK** .
6. Highlight **Road Assist** .
7. Press **OK** .
8. Press **TALK** .

OR

Press **Menu** to display the options, highlight **Call** and press **OK** .

Receiving Automated Billing Information

For your convenience, your phone gives you free access to billing information on your Sprint PCS Account. This information includes balance due, payment received, billing cycle and the amount of minutes used since your last billing cycle. Follow these steps to access this information:

1. Press **Shift *** **4** **TALK** .
2. Follow the voice prompts to receive the information you want.

OR

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Phone Book**.
3. Press **OK**.
4. Highlight **Services**.
5. Press **OK**.
6. Highlight **Account Info.**.
7. Press **OK**.
8. Press **TALK**
or
Press **Menu** to display the options,
highlight **Call** and press **OK**.

Sprint PCS Operator Services

Sprint PCS Operator Services can provide assistance in placing collect calls or calls billed to a local telephone calling card or a third party.

1. From the Standby mode, press and hold **0** (or press **0** **TALK**).

For more information or to see the latest in products and services, visit our web site www.sprintpcs.com.

Understanding this User Guide

This user guide introduces you to Sprint PCS technology and all the features of your new Sprint PCS Phone — through easy-to-follow instructions.

- ▶ **Sections** breakdown categories of information to progressively take you all the way from learning the basics to using the most advanced phone features.
- ▶ **Tips** highlight special shortcuts and timely reminders to help you make the most of your new phone.
- ▶ **The Index** helps you find specific information quickly.

We know that your time is valuable and that's why we've designed this guide to be used in a building block format or in stand-alone sections. You'll get the most out of your phone if you read each section. However, if you'd like to get right to a specific feature, you'll be able to locate the specific section through color coded tabbing. Follow the instructions in that section and you'll be ready to use your phone in no time.

2

Getting to Know your Sprint PCS Phone™

In This Section

- ▶ **Parts Name**
- ▶ **Viewing the Display Screen**
- ▶ **Turning your Phone ON and OFF**
- ▶ **Using the Battery**
- ▶ **Entering Information Using Keypad**

Getting to Know
your Phone
2

Your Sprint PCS Phone is packed with features that can simplify your life and expand your ability to stay connected to the people and information that are important to you. We know that you're anxious to start using it, so this section will give you a quick introduction to your new phone. Easy-to-follow instructions will guide you through the basics of the most common features of your phone.

Don't forget the other chapters in this guide. They're filled with information about the capabilities and benefits of your new Sprint PCS Phone. They include detailed step-by-step instructions to familiarize you with all the features, and how to customize your phone to meet your specific needs.

Parts Name



1. **Antenna:** The voice on the other end sounds clearest when the antenna is all the way up.
2. **Headset Jack:** Insert the plug of the headset (must be purchased separately) for hands-free listening.
3. **Memo:** Long press for Memo recording, and short press for Memo playing when the clamshell is open. When receiving incoming calls, long press for Screen Call start, and short press for ringer off.
4. **Volume key:** Lets you adjust the sound level during a call, or ringer volume in Standby mode when the clamshell is open. Lets you off the ringer when ringing. When you have more than two Sub LCD messages, you can check them by scrolling.
5. **LED (green/red light):** The green LED blinks when you have incoming calls. The red LED blinks when you have notification (Messages, Voicemail, etc.).
6. **Sub LCD:** When the clamshell is closed, it's useful to see the various status of the phone on this screen.
7. **Earpiece:** Lets you hear the caller's voice and voice prompts.
8. **Main LCD:** Displays the main menus, features, mode, etc.
9. **Soft Key (left):** Lets you select the menu (option) corresponding to the bottom left line on the Main LCD.
10. **Web:** Lets you launch the Browser.
11. **Navigation Key:** Lets you navigate quickly and easily through the menu options. It takes a short cut to the menus by pressing ▲ Message, ► Phone Book, ▼ Calendar and ◀ Settings.
12. **OK:** Lets you select menu options and receive a call.
13. **TALK:** Lets you place a call, receive a call, answer Call Waiting, use Three-Way Calling and Voice-Activated Dialing.
14. **Microphone:** You should speak into this microphone.
15. **END/POWER:** Lets you disconnect a call and return to Standby mode. Lets you mute ringer when receiving incoming calls. Or turns the phone ON and OFF.
16. **CLR (Clear):** Allows you to clear characters from the screen, mute ringer when receiving incoming calls or back up menu levels.
17. **Soft Key (right):** Lets you select the menu (option) corresponding to the bottom right line on the Main LCD.
18. **Menu:** Lets you display the menus and options.

Viewing the Display Screen

The following list identifies some of the more common symbols you'll see on your display screen.

Main LCD

- ▶  shows your current signal strength.
The more lines you have, the stronger your signal.
- ▶  means your phone cannot find a signal.
- ▶  (flashing) tells you a call is in progress.
- ▶  indicates the phone is roaming on another service provider's network.
If this icon is not displayed, you are on the digital Sprint PCS Nationwide Network.
- ▶  indicates you have new messages (Voice, Page Text or Web Alert) waiting.
- ▶  indicates the phone is roaming on an analog cellular network.
- ▶  shows the level of your battery charge.
The more black you see, the more power you have left. (While charging: )
- ▶  indicates you have menus to scroll (in four directions).
- ▶  indicates the vibrate feature is set to ON.
- ▶  indicates you have new voice memos waiting.
- ▶  indicates the Screen Call Auto setting is ON.

Sub LCD

- ▶  shows your current signal strength.
The more lines you have, the stronger your signal.
- ▶ Local time (e.g. **10:30a**)- “a” indicates “am” and “p” indicates “pm”.
- ▶  indicates you have new messages (Voice, Page Text or Web Alert) waiting.
- ▶  indicates you have new voice memos waiting.
- ▶  indicates the ringer volume setting is “High + Vibrate”
 indicates the ringer volume setting is Off.
 indicates the vibrate feature is set to ON.
- ▶  shows the level of your battery charge.
The more black you see, the more power you have left. (While charging: )

Managing Sub LCD

- ▶ The Sub LCD display illuminates indicating to the user that there are incoming calls, new messages, Call Alarm, etc.
- ▶ If the caller’s number matches the Phone Book entry’s number, the orange backlight turns on. (Other case: green backlight turns on.)
- ▶ You can notice that you have a missed call, new message, Calendar Alarm, etc. because the Sub LCD indication remains.
The newest event is indicated, but you can scroll and check old ones by using the side volume key  / .
- ▶ All the Sub LCD indications are deleted when you open the clamshell.



Soft Keys

You can select the menus or options, which are described at the bottom line of the Main LCD, by pressing the corresponding soft key  (left/right). In this User Manual, the explanation for selecting such menus/options is as shown below:

Press Email.

(It means, “Press the soft key  (left/right) corresponding to Email”.)

Turning your Phone ON and OFF

Turning your Phone ON:

1. Fully extend the antenna to receive the best reception.
2. Press **END/0** for approximately one second.

Once your phone is ON, the red LED light turns on for approximately 5 seconds while your phone looks for a signal. When your phone finds a signal, it automatically enters Standby mode—the phone's idle state. At this point, you're ready to begin making and receiving calls.

If your phone is unable to find a signal after 15 minutes of searching, a Power Save feature is automatically activated. When a signal is found, your phone returns to Standby mode.

Your phone searches for a signal periodically without your intervention. You can also initiate a search for Sprint PCS Service by pressing any key (when your phone is turned ON).

Turning your Phone OFF:

Follow these steps:

1. Press **END/0** for approximately two seconds until you see "Powering off" on the display.

Your screen remains blank while your phone is off, unless you're charging the battery.



Tip:

The Power Save feature helps to conserve your battery power while outside a Sprint PCS Service Area.

Tip:

Be sure to charge your phone's battery and watch your indicator to ensure your levels are OK.

Using the Battery

Installing the Battery

Your Sprint PCS Phone comes with a Lithium Ion battery. Follow these steps to install it:

1. Place the battery into the space beneath the antenna with the metal contacts at the bottom, facing downward.
2. Gently press down until it's in place and the battery release latch snaps.

Removing the Battery

To remove your battery for charging or for another reason, follow these easy steps:

1. Make sure the power is off so that you don't lose any stored numbers or messages.
2. Press up on the battery release latch and hold the battery, then pull it up and out at a 45-degree angle.

Charging the Battery

Your Sprint PCS Phone comes with a rechargeable battery. You should charge the battery as soon as possible so you can begin using your phone.

Keeping track of your battery's charge is important. If your battery level becomes too low, your phone automatically turns off and you'll lose everything you were just working on. (A series of alert tones will sound just before the phone turns itself off.)

For a quick check of your phone's battery level, glance at the battery charge indicator located on your phone's (Main or Sub) display screen.

If the battery charge gets too low, the phone will beep and the blank battery icon (Main:  -black, Sub: ) appears. When the remaining talk time is not enough, the Main LCD battery icon turns in red. The warning message also appears on your screen prompting you to recharge your battery.

Always use the approved manufacturer approved Desktop Charger, Travel Charger or Cigarette Lighter Adapter to charge your battery.

Using the Travel Charger

When you're ready to charge your battery, it is vital that you use only Sanyo-approved chargers. To use your Travel Charger:

1. Plug the Travel Charger into a wall outlet.
2. Plug the other end of the Travel Charger into the bottom of your phone, with the battery installed.

► Charging when your phone is turned on:

The battery icon  appears on the display while charging. When charging is complete, the battery icon turns to .

► Charging when your phone is turned off:

The battery icon  appears, and the message (Main: "BATTERY CHARGING -Power Off", Sub: "Power Off") is shown on the display while charging. When the battery is completely discharged, you may wait for several minutes until the message is shown on the display. When charging is complete, the battery icon turns to , and the Main LCD message changes to "CHARGING COMPLETE-Power Off".

Warning:

Using the wrong battery charger could cause damage to your phone and void the warranty.



Tip:

You can shift the process of entering letters to upper/lower case by pressing . It will change as follows:

- **T9e**—One-character-shifted
- **T9E**—Caps Lock
- **t9e**—Unshifted

The current selecting mode is shown at the bottom center of the display.

Entering Information Using Keypad

Entering Text Using T9 Mode

T9 mode uses an intelligent software protocol that allows you to enter text with fewer key presses than the multi-tap method. Type the entire word by pressing each corresponding key only once for each letter of the word. T9 determines the word by matching the keys you pressed with words in an internal database and displays the matching word that is used most often.

1. In a text entry field (e.g. for entering a folder name on page 68 and an event description on page 106, etc.), press  (right soft key) to display the “Input Mode” menu.
2. Highlight .
3. Press .
4. Type the entire word, but press each key only once per letter.
 - For example, to type the word “Hello”, press the keys      (in that order). As you type, T9 matches your key presses with words from its database.
 - Different words may appear as you type because each key you press changes the word possibility. The word you want may appear only after you press all of the necessary keys.

- ▶ Press **Next 0** to display alternate word choices. Short words are more likely to share the same key sequences. Cycle through all the choices for a key sequence by pressing **Next 0**.
- ▶ Press **Space #** to accept the word displayed and continue typing the next word. Add a space by pressing **Space #**.
- ▶ Press **CLR** to correct the last letter you entered. To clear an entire word or the reversed text (selected status), press and hold **CLR** for about two seconds.

Adding Words to T9 Database

Each word you type in Alphabet mode is automatically added to your T9 database. If the word you want isn't one of the T9 alternate choices, it's easy to add it.

1. Switch to Alphabet mode (press **Mode**, highlight **Alphabet** and press **OK** .)
 2. Type the word using the multi-tap method.
 3. Switch back to T9 (press **Mode**, highlight **T9 Word** and press **OK** .)
- ▶ Press **Next 0** to display the new word if other words share the same key sequence.

The word is saved automatically and will appear as a word choice in T9 the next time you use it.

Tip:

Instead of pressing

Next 0 you can use

▲ / ▼ of the Navigation key.



Tip:

Press **Shift *** to change:

- ▶ **Abc**—One-character-shifted
- ▶ **ABC**—Caps Lock
- ▶ **abc**—Unshifted

These settings are shown on the display.

Tip:

The beginning of the word after the space is changed to upper/lower case by the entry field.

You can change the shift by pressing

Shift *.

Using Smart Punctuation

“Smart punctuation” is available using **1** in T9 mode. It’s a quick and easy way to type e-mail domains, possessive forms and contractions. When you press **1**, T9 displays a period.

However, as you continue to type, T9 determines the appropriate mark based on your word database.

For example, to type “It’s easy.”

Press **4 8 1 7 Space # 3 2 7 9 1**.

Entering Text Using Alphabet Mode

1. In a text entry field, press **Mode**.
2. Highlight **Alphabet**.
3. Press **OK**.
4. Press a key several times until the desired letter appears.

Letters scroll in the following order:

Key	English Sequence	
	capital letter	small letter
1	. - ' / : @ , ? ! 1	
2	A B C 2	a b c 2
3	D E F 3	d e f 3
4	G H I 4	g h i 4
5	J K L 5	j k l 5
6	M N O 6	m n o 6
7	P Q R S 7	p q r s 7
8	T U V 8	t u v 8
9	W X Y Z 9	w x y z 9
Next 0	0	
Space #	Space	
Shift *	One-character-shifted Caps Lock Unshifted	

Key	Spanish Sequence	
	capital letter	small letter
1	. - ' / : @ , ¿ ? ¡ ! 1	
2	A Á B C 2	a á b c 2
3	D E E F 3	d e e f 3
4	G H I I 4	g h i i 4
5	J K L 5	j k l 5
6	M N Ñ O Ó 6	m n ñ o ó 6
7	P Q R S 7	p q r s 7
8	T U Ú Ü V 8	t u ú ü v 8
9	W X Y Z 9	w x y z 9
Next 0	0	
Space #	Space	
Shift *	One-character-shifted Caps Lock Unshifted	

For example, to enter the letter “j”, press **5** once in rapid succession. To enter the letter “Z”, press **9** four times. After two seconds, the cursor will automatically advance to the next space once a character has been entered.

- To expedite the process, use your Navigation key (right/left) to move the cursor to the right/left. To move the cursor rapidly, press and hold the corresponding Navigation key.
- Press **CLR** to correct the last letter you entered. To clear the whole text, press and hold **CLR** for about one second.

Getting to Know
your Phone
2

Tip:

For the Shortcut to the Symbol mode from the other entering mode, press and hold **Shift ***.

Tip:

One symbol input reverts to the previous mode automatically.

Tip:

For the Shortcut to the Number mode from the other entering mode, press and hold **Space #**. Or press and hold the corresponding numeric key to enter the number directly.

Entering Special Characters Using Symbol Mode

1. In a text entry field, press **Mode** (right soft key).
2. Highlight **SYMBOL**.
3. Press **OK**.
4. Highlight the line that includes your desired symbol.
5. Press the corresponding key (1 ~ 9) with each symbol.

or

Highlight your desired symbol by using the Navigation key, and press **OK**.

SYMBOL List

1	2	3	4	5	6	7	8	9
.	-	'	/	:	@	,	?	!
(	)	"	\	;	%	&	*	#
{	}	~		=	^	-	[	]
<	>	+	\$	«	»	°	¿	¡

Entering Text Using Number Mode

Number mode allows you to enter numbers.
To change to Number mode in a text entry field:

1. Press **Mode**.
2. Highlight **NUMBER**.
3. Press **OK**.

3

Understanding Roaming

In This Section

- Understanding How Roaming Works
- Setting your Phone's Roam Mode
- Setting an Alert When Roam Charges Apply (Call Guard)

Roaming is the ability to make or receive calls while you're off the Sprint PCS Nationwide Network. Your new dual-band Sprint PCS Phone™ works anywhere on the Sprint PCS Nationwide Network and allows you to roam on analog cellular and digital networks where Sprint PCS has implemented roaming agreements.

This section explains how roaming works, as well as special features that let you manage your roaming experience.

Understanding
Roaming
3

Tip:

Remember, when you're using your phone off the Sprint PCS Network, always dial numbers using 11 digits (1 + area code + number).

Tip:

You will pay a higher per-minute rate for roaming calls.

Tip:

When the clamshell is closed, you will see the roaming status on the Sub LCD.

Understanding How Roaming Works

Your phone's display screen always lets you know when you're off the Sprint PCS Network and whether your phone is operating in analog cellular or digital mode. The following chart indicates what you'll see depending on where you're using your phone.

Main LCD	Analog Indicator	Roaming Indicator
Sprint PCS Nationwide Network		
Other CDMA Networks		R
Analog Cellular Networks	YA	R

Sub LCD	Analog Indicator	Roaming Indicator
Sprint PCS Nationwide Network		
Other CDMA Networks		Digital Roaming
Analog Cellular Networks	Analog Roaming	

Roaming on Other PCS CDMA Networks

When you're roaming on other PCS CDMA networks, your call quality will be similar to the quality you receive when making calls while on the Sprint PCS Network. You may not be able to access certain calling features, such as Sprint PCS Wireless Web, however, all of your calls are still private and secure.

Roaming on Analog Cellular Networks

When you roam on analog cellular networks, you will experience the same quality provided by analog cellular carriers today. Although certain calling features, such as Sprint PCS Wireless Web, may be unavailable, you can still make and receive calls. You will experience a few differences including:

- ▶ You are more likely to experience static, cross-talk, fade-out and dropped calls.
- ▶ Some calling features that are standard on the Sprint PCS Network are unavailable.
- ▶ There are security and privacy risks (eavesdropping and cloning) that exist with conventional analog cellular services today.
- ▶ Your battery needs recharging sooner when you use your phone for analog cellular roaming.

Tip:

If you're on a call when you leave the Sprint PCS Network and enter an area where roaming is available (whether CDMA or analog cellular), your call is dropped. If your call is dropped in an area where you think Sprint PCS Service is available, turn your phone off and on again to reconnect to the Sprint PCS Nationwide Network.

Setting your Phone's Roam Mode

Your Sprint PCS Phone allows you to control your ability to roam. By using the menu option **Roaming**, you determine which signals your phone accepts.

Set Mode

Choose from three different settings on your dual-band phone to control your roaming experience:

1. From the Standby mode, press **Menu** to display the main menu.
 2. Highlight **Roaming**.
 3. Press **OK**.
 4. Highlight **Set Mode**.
 5. Press **OK**.
 6. To select an option, highlight it and press **OK**.
- **Sprint PCS:** This setting allows you to select the Sprint PCS Nationwide Network only and prevents roaming on other networks.
 - **Automatic:** This setting seeks Sprint PCS Service. When Sprint PCS Service is unavailable, it searches for an alternative system.
 - **Analog:** This setting forces the phone to seek an analog roaming system. The previous setting is restored the next time the phone is turned on.

Setting an Alert When Roam Charges Apply (Call Guard)

In addition to the roaming icon, Call Guard alerts you when roaming charges will apply. The following settings apply to Call Guard.

Call Guard

This feature makes it easy to control when you roam by reminding you when you are about to make or receive a roaming call. It also requires you to take additional steps before placing or answering a roaming call. These additional steps are not required when you make or receive calls while on the Sprint PCS Nationwide Network.

To Turn the Call Guard Feature On/Off:

1. From the Standby mode press **Menu** to display the main menu.
2. Highlight **Roaming**.
3. Press **OK**.
4. Highlight **Call Guard**.
5. Press **OK**.
6. Highlight **On** or **Off**.
7. Press **OK**.

To Place Roaming Calls with Call Guard On:

1. From the Standby mode, dial 1 + area code + the seven-digit number.
2. Press **TALK** (or press **Menu**, highlight **Call** and press **OK**).
3. Press **1** to proceed.
or
Press **Menu**, highlight **Roam Call** and press **OK**.

To Answer Incoming Roaming Calls with Call Guard On:

1. Press **TALK**.
2. Press **1** to proceed.
OR
1. Press **Menu**, highlight **Answer** and press **OK**.

Remember if the Call Guard feature is set to **On**, you need to take extra steps to make and receive roaming calls even if you have selected the **Analog** setting.

4

Making Calls

In This Section

- ▶ **Making Calls**
- ▶ **Correcting Dialing Mistakes**
- ▶ **Answering Calls**
- ▶ **Calling Emergency Numbers**
- ▶ **Dialing from an Internal Phone Book Memory Location**
- ▶ **Redialing Last Outgoing Number**
- ▶ **Using Speed Dial**
- ▶ **Displaying your Phone Number**

Your Sprint PCS Phone™ gives you different options for making calls so that you can use the method that works best for you.

Making Calls
4

Tip:

When making calls off the Sprint PCS Network, always dial using 11 digits (1 + area code + number)

Note:

While "Screen Call" or your phone is connecting to the Headset, Car Kit or Data/Fax, you cannot end the call by closing the clamshell.

Tip:

In 10 seconds after disconnecting the call, you can use menu options (Call Again or Save Phone# / Alternate) by pressing **Menu**.

Making Calls

1. Make sure your phone is on.
2. Enter a phone number.
3. Press **TALK**
or
Press **Menu**, highlight **Call** and press **OK**.
4. When you're finished, press **END/0** or close the clamshell to disconnect the call.

Correcting Dialing Mistakes

If you make a mistake while dialing, press **CLR** to erase one digit at a time. Or, if you need to erase the entire number all at once, press and hold **CLR** for at least one second.

Answering Calls

1. Make sure your phone is on. If your phone is off, incoming calls go to voicemail.
2. When your phone rings, press **TALK**
or
Press **Menu**, highlight **Answer** and press **OK**
or
Open the clamshell ("Open to Answer setting ON" is required, see page 42).
3. To disconnect the call, press **END/0** or close the clamshell.

Any Key Answer

This feature allows you to answer incoming calls by pressing any key (not including the **END/⓪**, **CLR**, side volume key **▲** or **▼**, **☒**, Navigation key and **Menu**).

To activate this feature:

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Settings**, and press **OK**.
 - ▶ Press **◀** of the Navigation key for the shortcut (steps 1 through 2).
3. Highlight **Others**.
4. Press **OK**.
5. Highlight **Any Key Answer**.
6. Press **OK**.
7. Highlight **On**.
8. Press **OK**.
 - ▶ To deactivate this feature, select **Off** at step 7 above.

Tip:

This feature is also available in locked state.

Note:

While your phone is connecting to the Headset, Car Kit or Data/Fax, you can not end the call by closing the clamshell.

Auto Answer

This feature sets the phone to automatically pick up after 5 or 15 seconds. This feature only works with the hands-free car kit and headset (must be purchased separately).

To activate this feature:

1. Press ◀ of the Navigation key.
 2. Highlight **Others**.
 3. Press **OK**.
 4. Highlight **AutoAns.Car/HS**.
 5. Press **OK**.
 6. Highlight **5 Seconds** or **15 Seconds**.
 7. Press **OK**.
- To deactivate this feature, select **Off** at step 6 above.

Open to Answer

This feature enables you to answer incoming calls by opening the clamshell so that you don't have to press **TALK**.

To activate this feature:

1. Follow the above steps 1-3.
 2. Highlight **Open to Answer**.
 3. Press **OK**.
 4. Highlight **On**.
 5. Press **OK**.
- To deactivate this feature, select **Off** at step 4 above.

Calling Emergency Numbers

You can place calls to 911, (dial **9** **1** **1** and press **TALK**) even if your keypad is locked or your account is restricted, just as long as you are in a Sprint PCS Service Area.

Dialing from an Internal Phone Book Memory Location

To dial directly from an Internal Phone Book memory location:

1. Press ► of the Navigation key.
2. Scroll to the Internal Phone Book entry you want to call, and press **OK**.
3. Highlight your desired phone number, and press **TALK**.

Redialing Last Outgoing Number

Press **TALK** twice.

Tip:

While connecting to 911, you can confirm your phone number quickly by pressing **Menu** and selecting **My Phone#**.

Using Speed Dial

Speed dial lets you dial numbers saved in your internal Phone Book by pressing a few keys. See page 84 for the details.

To speed dial:

1. Press and hold the appropriate key (2-9) that corresponds to the memory location for approximately two seconds

or

Press the appropriate key, and then press

TALK.

- Then the phone automatically finds the number in the Internal Phone Book, and displays it on the screen and places the call.

Displaying your Phone Number

Just in case you forget your own number, your Sprint PCS Phone can remind you.

To display your phone number:

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **My Profile**.
3. Press **OK**. Your phone number is shown as "My PCS#".

5

Adjusting Volume

In This Section

- ▶ **Changing Ringer/Key Volume**
- ▶ **Silencing the Ringer**
- ▶ **Selecting Ringer Types**
- ▶ **Setting Alerts**
- ▶ **Adjusting Volume During a Conversation**
- ▶ **Setting Melody Tempo**
- ▶ **Setting Tone Length or Start-up/Power-off Tone**
- ▶ **Muting a Call**

With all the things that demand your attention in today's fast paced world, it's important to tune in to what really matters. Your Sprint PCS Phone™ gives you the ability to control your phone's volume with the touch of a button. Not only can you control what you hear, you can also control what your caller hears.



Tip:

You can change the ringer volume (when the clamshell is open) by using:

- ▶  or  of the side volume key in the Standby mode.
- ▶  or  of the Navigation key while ringing.

Tip:

The confirmation beep (saved/error) volume also changes with the "Key Beep" setting.

Tip:

If you press and hold  while ringing, it starts Screen Call.

After you silence the ringer, you also have an option to activate Screen Call.

Changing Ringer/Key Volume

To change the ringer/key volume:

1. From the Standby mode, press  to display the main menu.
2. Highlight .
3. Press .
- ▶ Press  of the Navigation key to take a shortcut (steps 1 through 3).
4. Highlight .
5. Press .
6. Highlight .
7. Press .
8. Highlight  or .
- ▶  for adjusting Headset Key volume and  for the Car Kit Ringer/Key volume can also be selected.
9. Press .
10. Select your desired volume level.

Silencing the Ringer

You can silence the ringer on incoming calls. Follow these steps:

1. When the phone rings, press the any of the following keys shortly to off the ringer (stop vibration) temporarily: , ,  or side volume key ( / ).
2. Press  (or press , highlight  and press ) to answer the call.

OR

1. When the phone rings, press **Menu** to display the options.
2. Highlight **Quiet Ringer**.
3. Press **OK**.
4. Press **TALK** (or press **Menu**, highlight **Answer** and press **OK**) to answer the call.

Selecting Ringer Types

Your phone provides you with multiple ringer types including the different 4 chord melodies, downloaded melodies, vibration and none. Besides being fun to play with, this allows you to assign different ringer types for Voice Calls (With Caller ID, Restricted ID, No Caller ID, or Roaming.), Voicemail, Messages (Page/Text) and Web Alert (Browser Messages). Select a ringer type by following these simple directions:

1. Press **◀** of the Navigation key.
2. Highlight **Sounds**, and press **OK**.
3. Highlight **Ringer Type**.
4. Press **OK**.
5. Highlight one of the options, and press **OK**.
If you selected "Voice Calls" or "Messages", you have an extra step to select a category.
6. You can hear each ringer type by scrolling the list (except "Vibrate" and "None"), so you can select the one you desire.
 - It is not applicable when the Ringer Volume is set to "Vibrate" and "Off".

Tip:

While the phone is connecting to chargers or hands-free car kit, "Vibrate" cannot work, but the ringer will sound at lower level.

Tip:

See page 124 for melody downloading.

Adjusting
Volume
5

Tip:

“With Reminder” sounds every two minutes for twenty minutes. But when the Ringer Type setting is melody, the alert sounds for ten seconds.

Setting Alerts

Your phone comes with several different options to keep you aware of what’s going on by sounding the alert tone.

- ▶ **Service** sets alert On or Off for network services parameter changes.
- ▶ **Voicemail** sets alert for Voicemail receiving.
- ▶ **Messages** sets alert for Messages (page/text) receiving.
- ▶ **Web Alert** sets alert for Browser Messages receiving.
- ▶ **Minute Beep** sets a minute reminder that beeps ten seconds before the end of each minute during a call.

To set the alerts:

1. Press ◀ of the Navigation key.
2. Highlight **Sounds**, and press **OK**.
3. Highlight **Alerts**.
4. Press **OK**.
5. Highlight your desired option, and press **OK**.
6. If you selected “Service” or “Minute Beep”, highlight **On** or **Off**.
If you selected “Voicemail”, “Messages” or “Web Alert”, highlight **Once**, **With Reminder** or **Off**.
7. Press **OK**.

Adjusting Volume During a Conversation

When you need to hear more or less of a conversation, adjust the volume keys on the side of your phone. You can do this during a call or in between calls.

To adjust volume:

1. Use the side volume key  or  while talking. (It's also applicable for Headset Earpiece volume while the headset is in use.)
- OR
1. Press  of the Navigation key.
2. Highlight **Sounds**, and press .
3. Highlight **Receiver Volume**.
4. Press .
5. Highlight **Earpiece**.
 - You can also select **HeadsetEarpiece** or **CarKit Speaker**.
6. Press .
7. Select your desired volume level.

Setting Melody Tempo

Your phone allows you to change the tempo of melodies that are selected as the ringer at “Ringer Type”. Default tempo is Normal.

1. Press  of the Navigation key.
2. Highlight **Sounds**, and press .
3. Highlight **Melody Tempo**, and press .
4. Highlight a melody title, and press .
5. You can hear the selected melody on the highlighted tempo by scrolling the list, so select your desired tempo.
 - It is not applicable when the Ringer Volume is set to “Vibrate” and “Off”.



Setting Tone Length or Start-up/Power-off Tone

You can determine the length of your key beep (you hear this when you press any key) or type of Start-up/Power-off tone (sounds when you turn the phone on/off except when Key Beep volume is off) on this feature.

1. Press ◀ of the Navigation key.
2. Highlight **Sounds**, and press **OK**.
3. Highlight **Others**.
4. Press **OK**.
5. Highlight either **Tone Length**, **Start-up Tone** or **Power-off Tone**.
6. Press **OK**.
7. Highlight your desired option.
8. Press **OK**.

Muting a Call

There are times when it's necessary to mute a call so that your caller does not hear you or certain background noise. To use this function during a call:

1. Press **Menu** to display the options.
 2. Highlight **Mute**.
 3. Press **OK**.
- When the phone is muted, "MUTE:" blinks on the display.

To deactivate Mute setting:

1. Press **Menu**.
2. Highlight **Unmute**.
3. Press **OK**.

6

Managing Call History

Managing
Call History

6

In This Section

- ▶ **Viewing the Call History List (Outgoing, Incoming and Missed)**
- ▶ **Making a Call from the Call History List**
- ▶ **Saving a Phone Number from the Call History List**
- ▶ **Adding Options to the Entry in the Call History List**
- ▶ **Erasing Individual Calls or All Call History**

The call history list helps you manage your time more effectively. It keeps track of incoming calls, calls made from your Sprint PCS Phone™ and calls that you missed. This section guides you through accessing and making the most of your call history list.

Viewing the Call History List (Outgoing, Incoming and Missed)

You'll find your recent call history list invaluable. This is a list of the last 10 phone numbers for calls you placed, accepted, or missed. The call history list makes redialing a number fast and easy. It is continually updated as new numbers are added to the beginning of the list and the oldest entries are removed from the bottom of the list.

Depending on the operating mode and available features, each entry may contain a phone number, name and time stamp of when the call occurred. Duplicate calls (same number in last 7 digits and type of call) may only appear once on the list. When reviewing your entries, you'll see the type of call as described below:

- ▶ **Outgoing:** Indicates a call you placed.
- ▶ **Incoming:** Indicates a call you received and answered. When the clamshell is closed, Sub LCD backlight turns on and displays caller's number. If the number is stored in the phone book, name and phone number will be displayed every second.
- ▶ **Missed:** Indicates an unanswered incoming call. When the clamshell is closed, Sub LCD displays the time of latest call and a total number of missed calls.

Making a Call from the Call History List

To place a call from the recent call history list, follow these steps:

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Call History**.
3. Press **OK**.
4. Highlight either **Outgoing Calls**, **Incoming Calls** or **Missed Calls**.
5. Press **OK**.
6. Highlight the entry you want to call by scrolling through the list.
7. Press **OK** to display the details of the entry.
8. Press **TALK**
or
Press **Menu**, highlight **Call** and press **OK**.

Note:

You will be unable to make Sprint PCS Wireless Web calls from the call history list.

Note:

Sprint PCS Wireless Web calls cannot be saved in the call history list.

Tip:

If the selected entry has already been stored in the phone book, **Alternate** appears on the display except **Secret** setting.

Tip:

“New Name” – Enter a name directly.
“From Phone Book” – Select a name from Phone Book list.

Saving a Phone Number from the Call History List

Your Sprint PCS Phone can store up to 300 names and 500 phone numbers. Each entry can contain up to 32 digits, with an associated name of up to 16 characters. Your phone automatically sorts the Internal Phone Book entries by memory location number.

To **save numbers to your Phone Book**, follow these steps:

1. From the Call History List (to display the Call History List, see the previous page), highlight the entry you want to save, and press **OK**.
2. Press **Menu** to display the menu options.
3. Highlight **Save Phone#**.
4. Press **OK**.
5. Highlight appropriate label (Home, Work, Mobile, Pager, Data, Fax or No Label).
6. Press **OK**.
7. Enter a Name, and press **OK** or **OK**. (If you have any already-stored entries in the Phone Book, you are prompted to select the entry mode “New Name” or “From Phone Book”.) See “Entering Information Using Keypad” on page 28.
8. Press **Save**
or
► If you want to store the phone number without a name, press **OK** from the name entry display then highlight **Yes** and press **OK**.

Adding Options to the Entry in the Call History List

For additional options on a particular call:

1. Highlight the desired entry in the call history menu, and press **OK**.
2. Press **Menu** to display the menu options.
3. Highlight one of following and press **OK**.
 - ▶ **Call** to place a call.
 - ▶ **Alternate** to store other numbers into the same entry in the Phone Book
or
Save Phone# to store the number in the Internal Phone Book.
 - ▶ **Prepend** to add additional numbers.
 - ▶ **Erase** to erase the entry.

Erasing Individual Calls or All Call History

To erase an individual call:

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Call History**.
3. Press **OK**.
4. Highlight either **Outgoing Calls**, **Incoming Calls** or **Missed Calls**.
5. Press **OK**.
6. Highlight the entry you want to erase and press **OK**.
7. Press **Menu** to display the menu options.
8. Highlight **Erase**, and press **OK**.
9. Highlight **Yes**, and press **OK**.

To erase all calls (Outgoing calls, Incoming calls or Missed calls):

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Call History**.
3. Press **OK**.
4. Highlight either **Outgoing Calls**, **Incoming Calls** or **Missed Calls**.
5. Press **Menu** to display the menu options.
6. Highlight **Erase History**, and press **OK**.
7. Highlight **Yes**, and press **OK**.

7

Using Sprint PCS Service Features

In This Section

- ▶ **Using Caller ID**
- ▶ **Responding to Call Waiting**
- ▶ **Setting Up a Three-Way Call**
- ▶ **Forwarding your Calls**

Service
Features

7

Now that you've mastered the basics, you can begin to focus on where you want to go. This section guides you step-by-step through the calling features that enhance your Sprint PCS Service. From Caller ID to Call Forwarding, using these features will help you make the most of your Sprint PCS Service.

Tip:

For those calls where you don't want to be interrupted, you can temporarily disable call waiting by pressing **Shift * 7 0** before placing your call. Call Waiting is automatically reactivated once you end the call.

Using Caller ID

Caller ID lets you know who's calling by displaying the number of the person calling when your phone rings. If the caller's name and number are already stored in your Internal Phone Book, the corresponding name appears with the number. In the same way, if you call someone who has this feature, your phone number displays on their phone.

If you want to block your phone number from being displayed for a specific outgoing call, follow these steps:

1. Press **Shift * 6 7**.
2. Dial the number you want to call.
3. Press **TALK**.

To permanently block your number, call Sprint PCS Customer Care (see page 13 for number).

Responding to Call Waiting

Call Waiting alerts you of incoming calls while you're on a call by sounding beeps. The display screen informs you that a call is coming in and shows the caller's name (if you have the Phone Book entry) or the phone number. To respond to an incoming call while you're on a call:

1. Press **TALK**.

OR

1. Press **Menu** to display options.
2. Highlight **Flash**.
3. Press **OK**.

- These steps put the first caller on hold and answer the second call.

To switch back to the first caller:

1. Press **TALK** again.

OR

1. Press **Menu** to display options again.
2. Highlight **Flash**.
3. Press **OK**.

Setting Up a Three-Way Call

With Three-Way Calling, you can talk to two different people at the same time. When using this feature, the normal airtime rates will be charged for each of the two calls.

1. Dial a number you wish to call.
2. Press **TALK** (or press **Menu**, highlight **Call** and press **OK**).
3. Once you have established the connection, press **TALK** (or press **Menu**, highlight **Three Way Call** and press **OK**).
4. Dial the second number you wish to call.
- You can also select a phone number from options by pressing **Menu**. (e.g. from Call History or Phone Book list)
5. Press **TALK** (or press **Menu**, highlight **Call** and press **OK**).
6. When you're connected to the second party, press **TALK** once more (or press **Menu**, highlight **Flash** and press **OK**) to begin your three-way call.

If one of the people you called hangs up, you and the remaining caller stay connected. If you initiated the call and are the first to hang up, all three callers are disconnected.

Tip:

You don't have to worry about being interrupted during a Sprint PCS Wireless Web call because Call Waiting and Three-Way Calling are automatically disabled.

Tip:

Three-Way Call menu doesn't appear when you are roaming off the Sprint PCS Network.

Service
Features

7

Forwarding your Calls

Call Forwarding lets you forward all your incoming calls to another phone number — even when your phone is turned off. You can continue to make calls from your phone with Call Forwarding activated.

To Activate Call Forwarding:

1. Press **Shift *** **7** **2** .
2. Enter the area code and phone number to which your calls should be forwarded.
3. Press **TALK** . You will hear a tone confirming the activation of Call Forwarding.

To Deactivate Call Forwarding:

1. Press **Shift *** **7** **2** **0** .
2. Press **TALK** . You will hear a tone to confirm the deactivation.

8

Managing Messaging

In This Section

- ▶ **Setting Up Voicemail**
- ▶ **Message Types**
- ▶ **Knowing When you Have Messages**
- ▶ **Retrieving your Messages**
- ▶ **Classifying Page/Text Messages**

Your Sprint PCS Phone™ is always working to help you stay connected even when you're unavailable. With three types of messaging, you can depend on your callers being able to leave you important information. This section steps you through the messaging functions available on your phone including Sprint PCS Wireless Web™ Messaging.

Managing
Messaging

8

Tip:

When you are roaming off the Sprint PCS Network, you may not receive notification of new voicemail messages. It is recommended that you periodically check your voicemail by dialing 1 + area code + your Sprint PCS Phone Number.

Setting Up Voicemail

The first thing you'll want to do after activating your phone is to set up voicemail. See Section 1 page 12 for instructions.

Message Types

There are three types of messaging functions available on your Sprint PCS Phone. Voicemail, Numeric Paging and Sprint PCS Wireless Web Messaging allow you to receive messages as long as your phone has enough memory locations to store them. And you can send e-mail from your Sprint PCS Wireless Web.

Voicemail captures calls automatically when you can't answer your phone or it is turned off. The voicemail system sends a notification to your phone letting you know when you have new voice messages waiting in your voicemail box.

Numeric paging allows a caller to enter a phone number into your voicemail box instead of a voice message. The phone number appears on your phone as a numeric page.

Sprint PCS Wireless Web Messaging (also known as Text Messaging) allows messages to appear as short alphanumeric messages on your phone's display screen. You must purchase a Wireless Web Plan in order to receive text messages on your Sprint PCS Phone.

There are three ways to send a text message to a Sprint PCS Phone:

1. E-mail (your phone number @messaging.sprintpcs.com).
2. Through the Sprint PCS Web site—www.sprintpcs.com. Select the wireless web messaging link.
3. Using a messaging software (TAP 1.5 compatible).

To take a shortcut to connect the web site for sending e-mail:

1. Press **Email** (left soft key) in the Standby mode.

Knowing When you Have Messages

There are several ways your Sprint PCS Phone alerts you of new messages.

- ▶ By displaying a message on Main LCD.
- ▶ By displaying a message on Sub LCD, when the clamshell is closed.
- ▶ By blinking a red LED light.
- ▶ By displaying new message icon  at the top of Main LCD.
- ▶ By sounding tone alerts (except when the “Alerts-Voicemail/Messages” that is described on page 48 is set to Off).

The total number of new message will be counted up at the right side of the **Messages**. To display the **Messages** from the Standby mode, press **Menu**, highlight **Wireless Web** and press **OK**.

Note:

Sprint PCS
Wireless Web services
may not be available in
certain Affiliate areas.

Note:

When the clamshell is closed, Sub LCD displays the message or icon to notify you of the new message.



Tip:

Press any key to stop blinking red LED or sounding tone alerts.

Tip:

Your phone accepts messages even when it is turned **off**. However, you are only notified of new messages when your phone is turned **on**.

Receiving Messages

You will receive voicemail even if you have not set up your voicemail.

In other words, callers can leave messages they just would not hear a greeting.

Retrieving your Messages

You can review your messages directly from your Sprint PCS Phone or from any other touch-tone phone. To dial from your Sprint PCS Phone, you can either speed dial to your voicemail box or use the menu keys.

Using One-Touch Message Access:

1. From the Standby mode, press and hold . Follow the system prompts.
- When you have a voicemail notification, you can access to the message by pressing .

Using the Menu Keys on your Sprint PCS Phone to Access your Messages:

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Voicemail**.
3. Press **OK**.
4. Highlight **Call Voicemail**.
5. Press **OK** or **TALK**.

To see the details of the new voicemail:

1. From the Standby mode, press **Menu** to display the main menu.
 2. Highlight **Voicemail**.
 3. Press **OK**.
 4. Highlight **Details**.
 5. Press **OK**.
- When you have a voicemail notification, press **OK** (left soft key) or **OK** to display the options.

Message Clear Count

In the rare circumstance that the network does not clear the  icon even when you don't have any new voicemail, you can use this feature to reset the  icon.

Tip:

You are charged for airtime minutes when you are accessing your voicemail.

Tip:

Use **1** to check voicemail.



Tip:

You can adjust the font size depending on your preference (see "Setting Font Size" on page 89).

To clear the voice message count:

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Voicemail**.
3. Press **OK**.
4. Highlight **Clear Count**.
5. Press **OK**.
6. Highlight **Yes**.
7. Press **OK**.

Reading Page/Text messages:

When you have message notification, press **View** (left soft key) then **Menu** to display the options.

OR

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Wireless Web**.
3. Press **OK**.
4. Highlight **Messages**.
5. Press **OK**.
 - Press **▲** of the Navigation key to take a shortcut (steps 1 through 5).
6. Highlight **Unfiled** or your defined folder.
7. Press **OK**.
8. Highlight the header of the message you want to see.
9. Press **OK**.
10. Press **Menu** to display the options.

- ▶ An icon appears at the left side of each header of the message. The icons are as follows:

 New message

 Read message

- ▶ If the sender's information has already been stored in the phone book, the corresponding name, phone number or e-mail address appears as the header of the message. If nothing has been stored, the phone number, e-mail address or text that was included in the message appears as the header of the message.

To read other messages:

- ▶ Press ◀ of the Navigation key to read the previous message.
- ▶ Press ▶ of the Navigation key to read the next message.

If the incoming message has a phone number, you can return the call:

1. Press ▲ of the Navigation key.
2. Highlight the header of the message that has a call back number within **Unfiled** or your defined folder.
3. Press **OK**.
4. Press **Menu** to display the menu options.
5. Highlight **Call Back**.
6. Press **OK** or **TALK**.



Note:

If the incoming message does not have a call back number, "Call Back", "Alternate/Save Phone #" and "Prepend" are not shown.

Note:

If 10 user defined folders exist, "Add Folder" menu disappears.

Classifying Page/Text Messages

Your Sprint PCS Phone allows you to classify received messages into 10 User-defined Folders. If new messages contain the keyword, set by you, they are stored into the folder. Each folder can store up to 200 messages.

Adding a Folder:

1. Press ▲ of the Navigation key.
2. Highlight **Unfiled**, and press **OK**.
3. Highlight a header and press **OK**.
4. Press **Menu**.
5. Highlight **Add Folder** by scrolling, and press **OK**.
6. Enter a folder name from 3 to 13 letters, and press **OK** or **OK**. See "Entering Information Using Keypad" on page 28.
7. If you want the message to be filed into the folder automatically, highlight **Auto Filing** and press **OK**.
8. Highlight **On**, and press **OK**.
9. Highlight **Keyword**.
10. Press **OK**.
11. Highlight **Keyword match** or **Edit**, and press **OK**.
12. Highlight your desired Keyword from the list or edit your own Keyword, then press **OK**.
13. Press **Save** (left soft key).
 - If you want to set optional feature to the added folder:
 1. From the step 9 above, scroll down to **Ringer Type**, **Notification** or **Envelope Icon** and press **OK**.
 2. Highlight the item you want, and press **OK**.
 3. Press **Save** (left soft key).

Creating a Folder:

1. Press ▲ of the Navigation key.
2. Press **Menu**.
3. Highlight **Create Folder**.
4. Press **OK**.
5. Enter a folder name from 3 to 13 letters.
6. Press **OK** or **OK**.
- ▶ Pressing **Save** (left soft key) allows you to save the folder name.
7. If you want the message to be filed into the folder automatically, highlight **Auto Filing** and press **OK**.
8. Highlight **On**, and press **OK**.
9. Highlight **Keyword**.
10. Press **OK**.
11. Enter a Keyword from 3 to 15 letters, and press **OK** or **OK**.
12. Press **Save** (left soft key).
 - ▶ If you want to add a set optional feature to the new folder:
 1. From the step 9 above, scroll down to **Ringer Type**, **Notification** or **Envelope Icon** and press **OK**.
 2. Highlight the item you want, and press **OK**.
 3. Press **Save** (left soft key).

Note:

If 10 user defined folders exist, "Create Folder" menu disappears.



Note:

The messages within the folder are also erased.

Editing the Folder

1. Press ▲ of the Navigation key.
2. Highlight the folder you want to edit.
3. Press **Menu**.
4. Highlight **Edit Folder**.
5. Press **OK**.
6. Highlight **Folder Name**, **Auto Filing**, **Keyword**, **Ringer Type**, **Notification** or **Envelope Icon**.
7. Press **OK**.
8. Enter or select your new name/setting.
9. Press **OK** or **OK**.
10. Press **Save**.

Erasing a Folder

1. Press ▲ of the Navigation key.
2. Highlight the folder you want to erase.
3. Press **Menu**.
4. Highlight **Erase Folder**.
5. Press **OK**.
6. Highlight **Yes**, and press **OK**.

Moving a Page/Text Message Into the Other Folder

1. Highlight the message within **Unfiled** or your defined folder, and press **OK**.
2. Press **Menu** to display the menu options.
3. Highlight **Move Message** by scrolling.
4. Press **OK**.
5. Highlight the desired folder, and press **OK**.

Managing your Page/Text Messages

Your Sprint PCS Phone can store up to 200 incoming text messages and numeric pages. Deleting old messages keeps memory space available for new messages. Erasing the message notification does not erase the messages. New messages are rejected if your phone's memory is full.

To extract a phone number, e-mail or web address from a Page/Text message:

1. While reading a received message, press **Menu** to display the menu options.
2. Highlight **Extract Info.**.
3. Press **OK**.
4. Highlight **Phone#**, **Email Address** or **Web Address**.
5. Press **OK**.
6. Highlight the appropriate number or address.
7. Press **Menu** to display the menu options. Then highlight the optional feature you want, and press **OK**.



Tip:

Remember, it's time to delete old messages when available memory falls below 10% of the total memory. A warning message will appear on the display to notify you.

To erase a Page/Text message:

1. Press ▲ of the Navigation key.
2. Highlight **Unfiled** or your defined folder, and press **OK**.
3. Highlight the header of the message you want to erase, and press **OK**.
4. Press **Menu** to display the menu options.
5. Highlight **Erase**, and press **OK**.
6. Highlight **Yes**, and press **OK**.

OR

1. Press ▲ of the Navigation key.
2. Press **Menu** to display the menu options.
3. Highlight **Erase Old Msgs**.
4. Press **OK**.
5. Highlight **Yes**, and press **OK**.

9

Using your Internal Phone Book

In This Section

- ▶ Saving New Entries
- ▶ Adding Multiple Phone Numbers/E-mail/Web Addresses to an Existing Entry
- ▶ Storing and Viewing Long Phone Numbers
- ▶ Storing Short Phone Numbers
- ▶ Finding and Retrieving Numbers
- ▶ Setting Incoming Ringer/Picture to the Phone Book Entry
- ▶ Erasing a Stored Entry
- ▶ Entering Secret Phone Numbers
- ▶ Changing Stored Phone Numbers, E-mail and Web Addresses
- ▶ Storing Special Numbers in the Phone Book
- ▶ Using Different Dialing Methods

Now you know the basics and you've learned the advanced features that can help make it easier to stay in touch with people and information. This section helps you use your time more effectively when you're trying to connect with the important people in your life.

Saving New Entries

Your Sptint PCS Phone can store up to 300 names, 500 phone numbers, 300 e-mail addresses and 300 web addresses. Each entry can contain up to 32 digits, with an associated name of up to 16 characters. Your phone automatically stores the Internal Phone Book entries in alphabetical order.

Each entry is divided into 11 categories as 7 phone numbers (Home, Work, Mobile, Pager, Data, Fax and No Label), 1 Email, 1 Web, Ringer and Picture.

To **save numbers to your phone book**, follow these steps:

1. From the Standby mode, enter the phone number you want to save.
2. Press **Menu** to display the menu options.
3. Highlight **Save Phone#**, and press **OK**.
4. Select the appropriate label.
5. Enter a name, and press **OK** or **OK**. (If you have already stored any entry to the Phone Book, you are prompted to select the entry mode “New Name” or “From Phone Book”). See “Entering Information Using Keypad” on page 28 for entering method.
6. Press **Save**.

OR

Tip:

“New Name” –
Enter a name directly.
“From Phone Book” –
Select a name from
Phone Book list.

1. From the Standby mode, press **Menu** to display the main menu.
 2. Highlight **Phone Book**, and press **OK**.
 3. Highlight **Add New Entry**.
 4. Press **OK**.
 5. Enter a name, and press **OK** or **OK**.
 6. Select your desired label category by scrolling.
 7. Enter the number or address, and press **OK**.
 8. Press **Save**.
- If you store the number without a name, press **OK** or **OK** at step 5 above and select **Yes**.

Adding Multiple Phone Numbers/ E-mail/Web Addresses to an Existing Entry

1. From the Standby mode, press **Menu** to display the main menu.
 2. Highlight **Phone Book**, and press **OK**.
 3. Highlight **Find Name**, and press **OK**.
- Press ► of the Navigation key for the shortcut (steps 1 through 3).
4. Select the entry you wish to add phone numbers/e-mail/web addresses to.
 5. Select your desired label category by scrolling.
 6. Enter the number or address, and press **OK**.
 7. Press **Save**.

Tip:

Your Sprint PCS Phone can store up to 300 names, 500 phone numbers, 300 e-mail and 300 Web addresses. When these storage capacities are full, the display shows warning message.

Tip:

You can store up to 7 phone numbers (including pager, data and fax) and 1 e-mail and 1 web address per entry.

Internal
Phone Book
9

Storing and Viewing Long Phone Numbers

Your Sprint PCS Phone can also store five 48-digit phone numbers within its 500 phone number memory. If you enter more than 32 digits, it is necessary to enter a hard pause or 2-second pause between any 2 digits within the 32 digits, or immediately after the 32 digits. See also “Using the Pause Feature” on page 82.

To store a long phone number (for example, 48 digit storing):

1. Enter the 32 digit number.
2. Press **Menu** to display the menu options.
3. Select either “**H** Hard Pause” or “**T** 2-Second Pause” (See page 82 for these instructions).
4. Enter the rest of the 15 digit number.
5. Press **Menu** to display the menu options.
6. Highlight **Save Phone#**, and press **OK**.
Then follow the menu instructions.

Viewing Long Phone Numbers

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Phone Book**, and press **OK**.
3. Highlight **Long Phone#s**.
4. Press **OK**.
5. The Long Phone number's list appears, highlight your desired entry.
6. Press **OK** to see the details.
 - ▶ To make a call from the list, press **TALK** at step 5 or 6 above.
 - ▶ See page 82 for the pause feature.

Storing Short Phone Numbers

You can also store phone numbers with less than 7 digits numbers. Follow the instructions:

1. Enter the phone number (less than 7 digits).
2. Press **Menu** to display the menu options.
3. Highlight **Save Phone#**, and press **OK**.
4. A warning message appears because the number contains less than 7 digits.
5. If you are sure you want to save the short number, highlight **Yes**.
6. Press **OK**. Follow the menu instructions.



Tip:

If you have more than two label categories per entry, you can scroll through the other label by using ◀ ▶ from the Phone Book list.

Tip:

After selecting the entry, you can scroll through the other name entries by using ◀ ▶ of the Navigation key.

Finding and Retrieving Numbers

There are several ways to access numbers in your Internal Phone Book. Follow the steps outlined in the sections below. Make sure your phone is in Standby mode.

Reviewing All Memory Locations

You can review all the numbers stored in your Internal Phone Book by name, phone number, e-mail and web address. Follow these simple steps:

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Phone Book**, and press **OK**.
3. Highlight **Find Name**, and press **OK**.
 - ▶ Press ▶ of the Navigation key for the shortcut (steps 1 through 3).
4. Use your Navigation key to scroll through the Phone Book list and select one of the appropriate entries.
5. Highlight your desired memory location by scrolling.
6. Press **Menu** for the menu options, then highlight your desired feature and press **OK**.

Finding a Number Using a Person's Name

To find a number by using a person's name:

1. Press ▶ of the Navigation key.
2. Enter the first letter of the name or part of a name using the multi-tap method.
3. Select your desired entry by scrolling through the phone book.
 - ▶ If you enter a single letter, the display shows a list that begins with that letter.

Finding a Number When you Know at Least Four Digits

You can search for a number in the Internal Phone Book even if all you can remember is four to seven consecutive numbers from the phone number.

1. Enter the 4 to 7 digits.
2. Press **Menu**.
3. Highlight **Find**, and press **OK**.
4. The phone book entry list that includes the numbers you dialed appears.
5. Scroll through the list to select your desired entry.
6. Press **TALK**.

Setting Incoming Ringer/Picture to the Phone Book Entry

To set the incoming ringer:

1. Press **►** of the Navigation key.
2. Highlight the entry you want to set the incoming ringer and press **OK**.
3. Highlight **Ringer** by scrolling up or down.
4. Press **OK**.
5. Highlight your desired ringer type, and press **OK**.
6. Press **Save**.

To set the incoming picture:

1. Press **►** of the Navigation key.
 2. Select the entry you want to set the incoming picture.
 3. Highlight **Picture** by scrolling up or down.
 4. Press **OK**.
 5. Highlight your desired picture, and press **OK**.
 6. The preview display appears, then press **OK**.
 7. Press **Save**.
- You should have downloaded data to use this feature.

Note:

See page 124 for downloading melody and 125 for downloading picture.



Erasing a Stored Entry

To erase an entry from your Internal Phone Book:

1. Press **►** of the Navigation key.
2. Scroll to the Internal Phone Book entry you want to erase.
3. Press **Menu** to display the menu options.
4. Highlight **Erase Entry**.
5. Press **OK** to confirm that you want to erase the entry.
6. Highlight **Yes**, and press **OK**. “Phone Book Entry Erased” appears on the display to confirm that the entry has been successfully deleted.

Erasing a Stored Phone Number, E-mail or Web Address

To erase a phone number, e-mail or web address:

1. Press **►** of the Navigation key.
2. Scroll to the Internal Phone Book entry you want to erase.
3. Press **OK** to see the details of the entry.
4. Highlight phone number entry, e-mail entry or web entry.
5. Press **Menu** to display the menu options.
6. Highlight **Erase** by scrolling, and press **OK**.
7. Press **Save**.

Entering Secret Phone Numbers

In order to enter an Internal Phone Book entry that is tagged **Secret**:

1. Press ► of the Navigation key.
2. Scroll to the Internal Phone Book entry you want to tag **Secret**.
3. Press **Menu** to display the menu options.
4. Highlight **Set Secret**.
5. Press **OK**.
6. Enter 4 digits lock code.
7. Highlight **On**.
8. Press **OK**.
 - For Non-Secret setting, select **Off** at step 7 above.

Changing Stored Phone Numbers, E-mail and Web Addresses

You can change the phone number, address and name of any phone number stored in your Internal Phone Book.

To change a number:

1. Press ► of the Navigation key.
2. Scroll to the Internal Phone Book entry you want to change and press **OK**.
3. Highlight the category you want to edit.
4. Press **OK**.
5. Use **CLR** and the digit keys to edit the phone number, address or name.
6. Press **OK**.
7. Press **Save**.



Storing Special Numbers in the Phone Book

Using the Pause Feature

Generally, when you call an automated system like voicemail boxes or credit card companies, you are required to enter a password or account number. Rather than entering the numbers manually each time, you can store the numbers in your Internal Phone Book, separated by special characters called “pauses”.

Using Two Different Types of Pauses

There are two different types of pauses that you can use when storing a number in your Internal Phone Book.

- ▶ **Timed pauses** wait two seconds before sending the next string of digits.
- ▶ **Hard pauses** cause the phone to stop dialing until you select **Send Tone** or press **TALK**. To display “Send Tone”, press **Menu**, highlight **Send Tone** and press **OK**.

To insert pauses into a number:

1. Enter the number you want to dial.
2. Press **Menu** to display the menu options.
3. Highlight:
 - ▶ “**H** Hard Pause” for a hard pause.
 - ▶ “**T** 2-Second Pause” for a timed pause.
 - ▶ “Hyphen” for a hyphen (see following section).
4. Press **OK** to insert a pause or manual hyphen.
5. Finish entering the rest of the numbers, then dial or save the entered number. See page 76 for saving.

Using Hyphens

You can add hyphens to your Internal Phone Book numbers, however they are mainly for show. You can insert hyphens manually where you like, or choose automatic hyphenation which inserts hyphens according to the North American Numbering Plan. Entering a manual hyphen suspends any automatic hyphenation for that number.

Using Different Dialing Methods

Prepend Dialing

Prepend dialing allows you to alter a phone number in your Phone Book by adding additional numbers. For example, if your Internal Phone Book entry was entered without an area code and you are out of town, you can prepend that entry with the appropriate area code.

1. Highlight the phone number stored in Phone Book entry or call history using one of the previously described methods.
2. Press **Menu** to display the menu options.
3. Highlight **Prepend**.
4. Press **OK**.
5. Enter the digits you wish to prepend.
6. Press **TALK**
or
Press **Menu** to display the menu options, then highlight **Call** and press **OK**.



Tip:

Save your memory locations 2-9 for speed dialing or your most commonly used phone numbers.

Using Speed Dial

With this feature you can dial Internal Phone Book entries with one key press for locations 2-9. Speed dial numbers must be stored in your Phone Book to use this feature.

To store a speed dial number:

1. Press **►** of the Navigation key.
2. Select the Internal Phone Book entry for which want to set a speed dial number.
3. Highlight the phone number you want to set a speed dial.
4. Press **Menu** to display the menu options.
5. Highlight **Set Speed Dial**.
6. Press **OK**.
7. To select a corresponding speed dial number from 2-9, highlight an unassigned number and press **OK**.

OR

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Phone Book**, and press **OK**.
3. Highlight **Speed Dial #s**.
4. Press **OK**.
5. To select a corresponding speed dial number from 2-9, highlight an unassigned number and press **OK**.
6. Highlight the entry from the list.
7. Press **OK**.
8. Select the labeled category you want to set a speed dial.

To use speed dial:

1. From the Standby mode, press and hold for approximately two seconds the appropriate key that corresponds to the memory location.

OR

From the Standby mode, press the appropriate key, and then press **TALK**.

- The display confirms that the number has been dialed when it shows “Connecting”.



Note:

If you entered less than 6 digits, the display shows a warning message.

Abbreviated Dialing

Abbreviated Dialing is another form of speed dialing. If the last four digits you entered do not match any entry's phone number in your phone book, the four digits are prepended with the digits specified by you and a call to the prepended number is initiated without further input.

To activate this feature:

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Settings**.
3. Press **OK**.
4. Highlight **Others**.
5. Press **OK**.
6. Highlight **Abbrev. Dial**.
7. Press **OK**.
8. Enter a six-digit number.
9. Press **OK**.

To use this feature:

1. From the Standby mode, dial the last four digits of a Phone Book entry's phone number.
2. Press **Menu** to display the menu options.
3. Highlight **Abbrev. Dial**.
4. Press **OK** or **TALK**.

10

Changing your Phone's Display

In This Section

- ▶ Changing the Menu Language
- ▶ Changing the Backlight Time Length
- ▶ Changing your Standby Mode Display Banner
- ▶ Setting Font Size
- ▶ Changing the Display Color
- ▶ Changing the Contrast Setting
- ▶ Setting the Animation
- ▶ Setting the Display for Incoming Calls
- ▶ Setting the Display for the Standby Mode
- ▶ Setting Sleep Mode
- ▶ Displaying the Version Information

This section describes how to change your phone's display to best suit your viewing requirements. Every function and feature is displayed through your phone's menu. Take a few moments to review these options and adjust or add settings that are right for you.

Changing your
Phone's Display
10

Changing the Menu Language

When you first turn your phone on, the menus are displayed in English. To change the menu language to Spanish, follow these steps:

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Settings**, and press **OK**.
 - ▶ Press **◀** of the Navigation key for the shortcut (steps 1 through 2).
3. Highlight **Others**.
4. Press **OK**.
5. Highlight **Language** by scrolling.
6. Press **OK**.
7. Highlight **Español**.
8. Press **OK**.

Changing the Backlight Time Length

Backlight lets you choose how long the display screen and keypad are backlit after any key press is made. To change the backlight setting:

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Settings**.
3. Press **OK**.
 - ▶ Press **◀** of the Navigation key to take a shortcut (1 through 3).
4. Highlight **Display**.
5. Press **OK**.
6. Highlight **Backlight**.
7. Press **OK**.
8. Highlight your desired time length, and press **OK**.

Changing your Standby Mode Display Banner

The banner lets you customize the 15 characters of text displayed on the first line of your phone's display screen in Standby mode. You can create or change your banner by:

1. Press ◀ of the Navigation key.
2. Highlight **Display**, and press **OK**.
3. Highlight **Greeting**.
4. Press **OK**.
5. Pressing and holding **CLR**.
6. Entering characters. (See "Entering Information Using Keypad" on page 28).
7. Press **OK**
or
Press **OK** (left soft key).

Setting Font Size

There are four font size settings for the messages and browser. To change the font size, follow these steps:

1. Press ◀ of the Navigation key.
2. Highlight **Display**, and press **OK**.
3. Highlight **Font Size**.
4. Press **OK**.
5. Highlight **Messages** or **Browser**, and press **OK**.
6. Select your desired font size.
A font size example is shown on the display.
7. Press **OK** to set the selected font.

Tip:

From the font example display, you can see the larger/smaller font displays by pressing ▶/◀ of the Navigation key.

Changing your
Phone's Display **10**

Changing the Display Color

There are four different display color settings available. To change the display color setting:

1. Press ◀ of the Navigation key.
2. Highlight **Display**, and press **OK**.
3. Highlight **Color**.
4. Press **OK**.
5. Select your desired color.

Changing the Contrast Setting

Contrast lets you choose the shade of the display screen. This feature allows you to change the contrast setting of Main LCD and Sub LCD:

1. Press ◀ of the Navigation key.
2. Highlight **Display**, and press **OK**.
3. Highlight **Contrast** by scrolling.
4. Press **OK**.
5. Highlight **Main LCD** or **Sub LCD**, and press **OK**.
6. Select your desired setting.

Setting the Animation

This feature lets you display the animation as a screen saver or a display for Outgoing Calls. To set the Animation to On/Off:

1. Press ◀ of the Navigation key.
2. Highlight **Display**, and press **OK**.
3. Highlight **Animation** by scrolling.
4. Press **OK**.
5. Highlight **Screen Saver** or **Outgoing Calls** depending on your preference.
6. Press **OK**.
7. Highlight **On** or **Off**.
8. Press **OK**.
 - ▶ If you set “Screen Saver” to On, press **OK** then enter the time length before the Screen Saver starts, and press **OK** or **OK**.

Setting the Display for Incoming Calls

You can set the color or graphic (if you have download data) to be shown on the Incoming Call display. Follow these steps:

1. Press ◀ of the Navigation key.
2. Highlight **Display**, and press **OK**.
3. Highlight **Incoming Calls** by scrolling.
4. Press **OK**.
5. Select one of the settings.

If you do not want to set anything, select **Off**.

Tip:

If you have downloaded data, you can select from them. See page 125.

Changing your
Phone's Display **10**

Tip:

“☀” icon is shown in the summer time.

Tip:

In Analog mode or No Service area, “World Clock”, “Time (Large)”, “Calendar” or “Count Down” cannot be shown on the Standby display.

Setting the Display for the Standby Mode

This feature enables you to select a variety of items to display on the Standby mode.

Follow these steps:

1. Press ◀ of the Navigation key.
2. Highlight **Display**, and press **OK**.
3. Highlight **StandbyDisplay** by scrolling.
4. Press **OK**.
5. Highlight one of the desired items, and press **OK**.

Items:

- ▶ **World Clock** displays the time of the selected country with the local time. You can scroll the World Clock list by pressing ◀/▶ for changing country, **Summer** / **Standard** for changing between summer and standard time if applicable.
- ▶ **Time (Large)** displays the local time in a large, simple format.
- ▶ **Calendar** displays the Calendar.
- ▶ **Text** edits your own message to display with the local time.
- ▶ **Count Down** first edits the target (e.g. Birthday), and then enters the target date (from Jan 1, 2000 to Dec 31, 2020) for Count Down display.
- ▶ **Wallpaper** selects the wallpaper to display. You can also add your own message to the wallpaper for options (See the next page).
- ▶ **Off** sets this feature to Off.

6. After following each system prompt or confirming the preview display, press **OK** to save the setting.

Further explanation for setting wallpaper:

1. Select **Wallpaper** at the previous step 5.
2. Highlight your desired wallpaper, and press **OK**.
3. Depending on your preference for the wallpaper size, highlight **Small** or **Large** and press **OK**.
4. Highlight your desired option and press **OK**.

Options:

- **Save** saves the wallpaper selection.
 - **Add Message** adds your personal message to the wallpaper. After editing the 1st and 2nd line messages, you can also select the letter color (Black or White).
5. Confirm the preview display, and press **OK** to save the wallpaper.
- The picture can be moved within the frame of wallpaper by using the Navigation key on the preview display.

Tip:

After you have downloaded wallpapers, you can select from them. See page 125.

Setting Sleep Mode

This feature helps conserve your battery power by restricting the display. It is applicable for the display of Standby, Power Save, Missed Calls, Message Alert, Missed Alarm, etc. To set Sleep Mode:

1. Press ◀ of the Navigation key.
 2. Highlight **Display**, and press **OK**.
 3. Highlight **Sleep Mode** by scrolling.
 4. Press **OK**.
 5. Highlight **On**.
 6. Press **OK**.
 7. Enter the time length (5-99 seconds) from the last key press before the Sleep Mode starts, and press **OK** or **OK** (left soft key).
- To deactivate this feature, select **Off** at step 5 above.

Displaying the Version Information

Display the version number of the software, hardware, PRL (Preferred Roaming List), PRI (Product Release Instructions) and Browser installed on your Sprint PCS Phone.

1. Press ◀ of the Navigation key.
2. Highlight **Display**, and press **OK**.
3. Highlight **Version** by scrolling.
4. Press **OK**.

11

Setting your Phone's Security



Your Phone's
Security
11

In This Section

- ▶ Locking the Side Key
 - ▶ Locking your Phone
 - ▶ Unlocking your Phone
 - ▶ Changing your Lock Code
 - ▶ Restricting your Calls
 - ▶ Storing Special Numbers
 - ▶ Erasing the Entire Internal Phone Book
 - ▶ Resetting your Phone
 - ▶ Resetting and Locking your Phone through SMS
 - ▶ Changing the Passcode
-

By using the security setting on your Sprint PCS Phone™, you receive peace of mind without sacrificing flexibility. With several options available, you can customize your phone to meet your personal needs.

Locking the Side Key

The side key guard feature disables the keys ( and ) on the side of the phone so that your phone is protected against accidental operation while the clamshell is closed.

To activate this feature:

1. From the Standby mode, press  to display the main menu.
2. Highlight **Settings**.
3. Press .
- ▶ Press  of the Navigation key for the shortcut (steps 1 through 3).
4. Highlight **Others**.
5. Press .
6. Highlight **Side Key Guard**.
7. Press .
8. Highlight **On**.
9. Press . Then “Side Key Guard” message appears on the Sub LCD if you close the clamshell.
- ▶ To deactivate this feature, select “Off” at step 8 above.
- ▶ If the clamshell is opened, Side keys are available.

Locking your Phone

When your phone is locked, you can only make emergency calls (9-1-1, and your user-specified Special Numbers) or receive incoming calls. All other functions of the phone are disabled.

To lock your phone:

1. Press ◀ of the Navigation key for the shortcut.
2. Highlight **Security**, and press **OK**.
3. Enter lock code.
4. Highlight **Lock Phone**.
5. Press **OK**.
6. Depending on your preference, highlight either **Lock Now** or **On Power-up**, and press **OK**.

Unlocking your Phone

1. From the Locked display, press **Unlock** (left soft key).
2. Enter lock code.
- If you want to cancel the “On Power-up” setting before turning the phone off, select “Unlocked” instead of “On Power-up” at the step 6 described previously.

Tip:

You must enter your lock code to view the security menu.

Typical default values are either the last 4 digits of your phone number or 0000.

If you forget your lock code, take your phone to the nearest Sprint PCS Center.

Your Phone's
Security
11

Changing your Lock Code

You can enter a personal lock code and then change it as often as you like. To enter a new lock code:

1. Press ◀ of the Navigation key.
2. Highlight **Security**, and press **OK**.
3. Enter lock code.
4. Highlight **SecuritySetting**.
5. Press **OK**.
6. Highlight **Lock Code**.
7. Press **OK**.
8. Enter new lock code.
9. Re-enter your new lock code.

If you've changed your lock code and forgotten what you changed it to, call Sprint Customer Care for assistance. (See page 13 for number).

Restricting your Calls

You can limit your outgoing and incoming calls. Even while limiting outgoing calls, emergency numbers and Sprint PCS Customer Care are available to call.

To restrict your calls:

1. Press ◀ of the Navigation key.
2. Highlight **Security**, and press **OK**.
3. Enter lock code.
4. Highlight **SecuritySetting**.
5. Press **OK**.
6. Highlight **Limit Use**.
7. Press **OK**.
8. Highlight **Outgoing Calls** or **Incoming Calls**.
9. Press **OK**.
10. Select your desired option.

The options on this setting are “Allow All”, “Phone Book Only” or “Special #s Only”.

Allow All: You can make or receive all calls.

Phone Book Only: Only Phone Book entries or special numbers (see the next page) are available to make or receive calls.

Special Numbers Only: Only three special number entries are available to make or receive calls.

- If you want to deactivate the restricted calls, you have to set “Allow All” to the incoming or outgoing call.
- If you leave the restricted incoming calls for 30 seconds, they connect to voicemail.

Tip:

Emergency calls (9-1-1, **Shift** ***** **2**) can still be made in this state.

Your Phone's
Security
11

Tip:

Press **Menu**, highlight **Hang Up** and press **OK** to disconnect the restricted incoming calls before they connect to the voicemail.

Tip:

If the phone number has already been stored, these "Phone#" options change to "H Hard Pause", "T 2-Second Pause" and "Hyphen".

Storing Special Numbers

This feature allows you to store three important phone numbers that you would like to access even if your phone is locked.

To add a phone number to your Special Numbers:

1. Press ◀ of the Navigation key.
2. Highlight **Security**, and press **OK**.
3. Enter lock code.
4. Highlight **SecuritySetting**.
5. Press **OK**.
6. Highlight **Special #s**.
7. Press **OK**.
8. Highlight the entry number where you would like to store the number.
9. Press **OK**.
10. Enter the phone number and press **OK**
or
Press **Menu**, then highlight **From Phone Book** or **Voicemail** and press **OK**. Follow the system prompts.

Erasing the Entire Internal Phone Book

1. Press ◀ of the Navigation key.
2. Highlight **Security**, and press **OK**.
3. Enter lock code.
4. Highlight **Erase PhoneBook**.
5. Press **OK**.
6. If you're sure you want to erase your Phone Book, highlight **Yes** and press **OK**.

Resetting your Phone

Resetting your Sprint PCS Phone will restore all the factory defaults, including ringer types, display settings, etc. However, your Call History, Internal Phone Book and Messages will not be affected.

1. Press ◀ of the Navigation key.
2. Highlight **Security**, and press **OK**.
3. Enter lock code.
4. Highlight **Reset Phone**.
5. Press **OK**.
6. If you're sure you want to reset your phone, highlight **Yes** and press **OK**.

Resetting and Locking your Phone through SMS

When your phone is lost or stolen, you can erase your important personal information (such as phone book entries, call history and messages) and lock your phone by sending a special formatted SMS message to your phone. Send the following format from your computer:

\\RESET * * <Passcode> * * RESET

- <Passcode> —your defined passcode.
Default Passcode is
11-digit ESN (Electronic
Serial Number) which is
described on the package
or phone itself.

The locked phone will display the following message:

"If found, please call Sprint PCS Customer Care 1-888-217-4727".



Tip:

There is a help menu for “Found Me” instruction. Select “Help” at the step 8.

To activate this feature, the following presetting is required:

1. Press ◀ of the Navigation key.
2. Highlight **Security**.
3. Enter lock code.
4. Highlight **SecuritySetting**.
5. Press **OK**.
6. Highlight **Found Me**.
7. Press **OK**.
8. Highlight **Reset/Lock**.
9. Press **OK**.
10. Highlight **Enable**.
11. Press **OK**.
 - To unlock a phone that has been locked through SMS, bring the phone to a Sprint PCS Retail Store.

Changing the Passcode

To change the passcode for the special formatted SMS messages:

1. Press ◀ of the Navigation key.
2. Highlight **Security**.
3. Press **OK**.
4. Enter lock code.
5. Highlight **SecuritySetting**.
6. Highlight **Found Me**.
7. Press **OK**.
8. Highlight **ChangePasscode**.
9. Press **OK**.
10. Enter new passcode (11 digits).
11. Re- enter the new code and your new code will be saved.

12

Personal Information Management

In This Section

- ▶ **Managing Phone Book**
- ▶ **Checking My Profile**
- ▶ **Managing Schedules**
- ▶ **Using Voice Memo**
- ▶ **Setting Up Screen Call**
- ▶ **Using Voice-Activated Dialing**
- ▶ **Playing Game**
- ▶ **Using the Calculator**
- ▶ **Using the Downloaded Data**

Personal
Information
12

Your Sprint PCS Phone™ has been equipped with several personal information management features to help you manage your busy lifestyle. These features turn your phone into a time management planner that helps you keep up with your contacts, schedules and commitments.

Managing Phone Book

See “Internal Phone Book” on page 73.

Checking My Profile

This phone can store your personal data in “My Profile” menu. These are including My Name, My PCS#, Birthday, Blood Type, Address, **H** Phone# (home), **H** Email (home), **W** Phone# (work) and **W** Email (work).

Editing My Profile

To edit or select your personal data (except My PCS#):

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **My Profile**, and press **OK**.
3. Highlight your desired item, and press **OK**.
4. Edit (enter) or select the data, and press **OK**.
5. Press **Save**.

Setting Secret My Profile

In order to display the My Profile data (other than My Name and My PCS#) that are tagged **Secret**:

1. From the Standby mode, press **Menu**.
2. Highlight **My Profile**, and press **OK**.
3. Highlight **My Name**, and press **Menu**.
4. Highlight **Set Secret**.
5. Press **OK**.
6. Enter your 4-digit lock code.
7. Highlight **On**.
8. Press **OK**.
9. Press **Save**.

► To cancel the secret setting, select **Off** at step 7 above.

Tip:

If the stored data is more than 15 digits, the pop up display appears to show the whole data.

Tip:

To display the options such as “Erase”, “Call” and “Send Email”, highlight one of the My Profile data (except My Name, My PCS# and Blood Type) and press **Menu**.

Managing Schedules

Calendar

Use the Calendar to remind you of events or important calls you need to make. You can schedule up to 100 events, 15 Call Alarms and 20 To-Do Items.

Setting Holidays

You can set your personal holidays by displaying the date in red on the Calendar display. The default holidays displayed in red are Sundays and National holidays.

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Calendar**.
3. Press **OK**.
 - ▶ Press **▼** of the Navigation key to take a shortcut (steps 1 through 3).
4. Highlight the day you want to set as a holiday by using the Navigation key (**◀** previous day, **▶** next day, **▲** previous week, **▼** next week) and the side volume key (**□** previous month, **▢** next month).
5. Press **Menu**.
6. Highlight **Set Date** or **Set Weekly** from the options, and press **OK**.

Options:

- ▶ **Set Date** sets the selected day as a holiday.
- ▶ **Set Weekly** sets weekly holidays.
- ▶ **Reset Date** resets the holiday setting with the selected day.
- ▶ **Reset Weekly** resets the weekly holiday setting.

Tip:

In Analog mode or No Service areas, it's necessary to set the actual time and date to use the Calendar function.

Set the current Time/Date by using numeric keys and/or the Navigation key (**◀** / **▶** move cursor, **▲** / **▼** change value). It's available from 12:00 AM, Jan 1, 2000 to 11:59 PM, Dec 31, 2099.

Tip:

You can set holidays from Jan 1, 2000 to Dec 31, 2020.

Tip:

The framed date indicates the current date.

Tip:

When you select "Set Weekly", "Reset Weekly" or "Reset All", you'll be prompted to select **Yes** or **No**.



Tip:

If you have To-Do memory, you can extract the description from them. Press **Mode**, highlight **From To Do List** and press **OK**, then select your desired item.

- **Reset All** resets all the holiday settings and returns to the default settings.

Adding Events

1. From the Standby mode, press ▼ of the Navigation key.
2. Highlight the day you want to add an event by using the Navigation key and the side volume key **▲** or **▼**, and press **OK**.
3. Press **Menu** to display the options.
4. Highlight **Add Event**.
5. Press **OK**.
6. Highlight **Event**.
7. Press **OK**.
8. Highlight one of the following event details, and press **OK**.

Details:

- **Description** Entering a description of your event (up to 15 characters).
 - **From** Scheduling the start time.
 - **To** Scheduling the end time.
 - **Location** Editing the location of your event (up to 15 characters).
 - **Alarm** Setting the alarm to On or Off.
 - **Alarm Time** Editing the alarm time (number of hours or minutes before the event starts). Default alarm times are 10 minutes.
 - **Repeat** Repeating the event. Select “None”, “Daily”, “Weekly”, “Monthly”, or “Yearly”.
9. Press **Save** (left soft key) to schedule the event.

Notifying Events

When an event alarm is scheduled, notification is displayed at the set time. The red LED light will also blink and the alarm will sound until you press any key. If Event Alarm beeps with the clamshell closed, the message appears on the Sub LCD and the event description scrolls once. You can stop the beep by pressing one of the side keys ( and ) and erase the message by opening the clamshell.

To check the notification:

1. Press  or  (left soft key) to see the event details.
2. Press  to display the options.
3. Highlight an option, and press .

Options:

- ▶ **Snooze** notifies again after 10 minutes.
- ▶ **Erase** deletes the event that you are checking, even if it is a repeating event.

Tip:

Event Alarm cannot sound if your phone is turned off, in Analog mode/No Service area or while the phone is in use.

Missed Alarm notification is displayed at the time when the phone returns to each appropriate mode.



Tip:

You can also add a Call Alarm from the Phone Book menu.

Highlight the entry's phone number, and press **Menu** to select **Call Alarm**.

Tip:

If the phone number has already been stored, the "Phone#" options change to "**H** Hard Pause", "**T** 2-Second Pause" and "Hyphen".

Adding Call Alarms

Scheduling a Call Alarm lets you remind yourself to make an important call by displaying a notice. Follow these steps:

1. From the Standby mode, press **▼** of the Navigation key.
2. Highlight the day you want to schedule a Call Alarm, and press **OK**.
3. Press **Menu** to display the options.
4. Highlight **Add Event**.
5. Press **OK**.
6. Highlight **Call Alarm**.
7. Press **OK**.
8. Highlight one of the following Call Alarm details, and press **OK**.

Details:

► **Phone number** Editing the phone number:

Enter the phone number directly and press

OK

or

Press **Menu**, then highlight

From Phone Book or **VoiceMail** and press

OK. When you selected

From Phone Book, you can extract the entry phone number by following the prompt order.

- **Time/Date** Editing the start time/date.
- **Repeat** Repeating the Call Alarm. Select "None", "Daily", "Weekly", "Monthly", or "Yearly".
9. Press **Save** (left soft key).

Notifying Call Alarms

When a Call Alarm is scheduled, notification is displayed at the set time. The red LED light will also blink and the alarm will sound until you press any key. If Call Alarm beeps with the clamshell closed, the message appears on the Sub LCD and the phone number (or phone book entry name) scrolls once. You can stop the beep by pressing side keys ( and ) and erase the message by opening the clamshell.

1. Press  or  (left soft key) to see the Call Alarm details.
- ▶ If you want to call the number immediately, press .

2. Press  to display the options.

3. Highlight an option, and press .

Options:

- ▶ **Call** lets you place a call.
 - ▶ **Snooze** notifies again after 10 minutes.
 - ▶ **Alternate** when you stored some other numbers into the same entry in Phone Book, enables you to alternate it.
- or
- ▶ **Save Phone #** stores the number into Phone Book.
 - ▶ **Erase** deletes the Call Alarm, even if it is a repeating one.

Tip:

Call Alarm cannot sound if your phone is turned off, in Analog mode/No Service area or while the phone is in use.

Missed Alarm notification is displayed at the time when the phone returns to each appropriate mode.

Personal
Information

12

Tip:

Event list (including events and Call Alarm) are displayed in chronological order.

Navigation key leads to the next day (▶ right) and the previous day (◀ left).

Viewing Events and Call Alarms

1. From the Standby mode, press ▼ of the Navigation key.
2. Then, a “▶” is displayed next to the date if an event or Call Alarm is scheduled.
3. To view an individual day, highlight the day by using the Navigation key (◀ previous day, ▶ next day, ▲ previous week, ▼ next week) and the side volume key (⏮ previous month, ⏭ next month), and press **OK**.
4. Highlight one of the Events from the list, and press **OK**. The event or Call Alarm details display appears.
 - ▶ To edit the details data, highlight it and press **OK**. (See “Adding Events” on page 106 or “Adding Call Alarms” on page 108 for the details.)
 - ▶ To erase the Events, press **Menu**, highlight **Erase** and press **OK**. Then Highlight **Yes** and press **OK**.

To view a future/past day's scheduled Events, follow these steps:

1. From the Event list display, press **Menu**.
2. Highlight **Go To Date**.
3. Press **OK**.
4. Enter the date by using numeric keys and/or the Navigation key, and press **OK**.
5. Press **OK** again to view the day's Event list.

Adding To-Do's

To add an item to your To-Do List, follow these steps:

1. From the Standby mode, press ▼ of the Navigation key.
2. Press **OK**.
3. Press **Menu** to display the options.
4. Highlight **To Do List**.
5. Press **OK**.
6. Press **Menu**.
7. Highlight **Add Item**.
8. Press **OK**.
9. Highlight **Description** or **Priority**, and press **OK**.
 - ▶ **Description** Entering a description of the To-Do (up to 15 characters).
 - ▶ **Priority** Editing the To-Do's priority. You can select from "Normal", "! Urgent" or "√ Done".
10. Press **Save**.

Viewing To-Do List

To view your To-Do List, follow these steps:

1. From the Standby mode, press ▼ of the Navigation key.
2. Press **OK**.
3. Press **Menu** to display the options.
4. Highlight **To Do List**.
5. Press **OK**.
6. Highlight an item from the To-Do list, and press **OK**. The details display appears.
 - ▶ To edit the details data, highlight it and press **OK**. (See "Adding To-Do's".)



Editing To-Do Items

1. Follow the previous steps 1-6.
2. Press **Menu** to display the options.
3. Highlight an option and press **OK**.

Options:

- **Add To Schedule** extracts an item from the To-Do list and makes it a scheduled event.
- **Erase** deletes the To-Do.

Viewing Event, Call Alarm and To-Do Memory

To view memory space, follow these steps:

1. From the Standby mode, press ▼ of the Navigation key.
2. Press **OK**.
3. Press **Menu** to display the options.
4. Highlight **View Memory**.
5. Press **OK**.
6. Highlight **Schedule Event**, **Call Alarm** or **To Do List**.
7. Press **OK**.

To further options,

8. Press **Menu**.
9. Highlight **Erase Old**, **Erase Done** or **Erase All**, and press **OK**.
- **Erase Old** deletes the old events or Call Alarms.
- **Erase Done** deletes the To-Do's that were done.
- **Erase All** deletes the all events, Call Alarms or To-Do's.
10. Highlight **Yes** or **No**, and press **OK**.

Erasing Multiple Events, Call Alarms or To-Do's

To erase old Events, Call Alarms and To-Do's, follow these steps:

1. Follow the previous steps 1-3.
2. Highlight **Erase Memory**.
3. Press **OK**.
4. Highlight **Erase Old**.
 - To erase all Events, Call Alarms and To-Do's, highlight **Erase All**.
5. Press **OK**.
6. Highlight **Yes**.
7. Press **OK**.

Using Voice Memo

Voice Memo allows you to record a caller's voice while talking and your voice in Standby mode, instead of taking notes.

Your Sprint PCS Phone is capable of storing up to 8 memos (including the "Screen Call" which is described on page 115) for 18 seconds each. When the memory is full, a warning message will be displayed, prompting you to erase an old memo.

Recording Memos

1. Press and hold **END** (side key of the phone) while opening the clamshell.

After the beep, starts recording.

To stop recording:

1. Wait for 18 seconds or press **OK** or **END** while recording.

OR

Press **END** and disconnect the call while recording.

It also stops recording when the other party hangs up the call.

Tip:

When your phone is in analog mode, this function is not available.

If you receive a message notification or incoming call while recording or when the service area has changed, recording is stopped automatically.



Tip:

When your phone is in use, playing memos is not available.

Tip:

Voice Memo is stored with the date and time stamp in reverse chronological order except when it's recorded in Analog or No Service areas.

Playing Memos

You will be notified that you have a new Voice Memo by the Memo icon (Main: , Sub: ) displayed on the screen.

1. Press  (side key of the phone) while opening the clamshell.
 2. Highlight one memo from the list.
or
Highlight **All** if you want to play all memos continuously.
 3. Press  .
- ▶ To play the next/previous memo, press  /  of the Navigation key.
 - ▶ Press  or  to stop playing.

Erasing Memos

To erase an individual Voice Memo:

1. Press  .
2. Highlight your desired memo from the list.
3. Press  to display the options.
4. Highlight **Erase Memo**.
5. Press  .
6. Highlight **Yes**.
7. Press  .

To erase all Voice Memos:

1. Press  .
2. Highlight **All**.
3. Press  .
4. Highlight **Erase All Memos**.
5. Press  .
6. Highlight **Yes**.
7. Press  .

Setting Up Screen Call

This feature enables you to answer incoming calls by using pre-recorded announcements, either one that came with the phone or one that you record. You can also record the caller's voice into the Voice Memo list (See "Using Voice Memo"). You can decide whether you answer the call immediately or not during the caller's recording.

Activating Screen Call

To start Screen Call when you have incoming calls:

1. Press and hold .

OR

1. Press  to display the options.

2. Highlight **Screen Call**.

3. Press .

To set auto Screen Call:

1. From the Standby mode, press  to display the main menu.

2. Highlight **Screen Call**.

3. Press .

4. Highlight **Auto**.

5. Press .

6. Highlight **On**.

7. Press .

8. If you want to change the Answer Time, enter your desired number (from 1 to 16 seconds) by using numeric keys or  /  of the Navigation key.

9. Press  or  (left soft key).

- ▶ Pressing and holding  and Auto Screen Call are not applicable when you have roaming calls with Call Guard On.

- ▶  icon is displayed on the Standby display.

Tip:

If new memo is waiting,  appears on the display.

The memos recorded while activating "Screen Call" are shown with "V" or "!" icon in the list.

V: once played

!: not played yet

Personal
Information

12

Tip:

While the caller's recording:

- ▶ Pressing  /  stops recording.
- ▶ Pressing  answers call.

Selecting Announcement for Screen Call

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Screen Call**.
3. Press **OK**.
4. Highlight **Announcement**.
5. Press **OK**.
6. Depending on your preference of setting “already stored” or “user setting” announcement, highlight **Pre-recorded** or **Custom**.
7. Press **OK**.

Playing Announcement

1. Follow the above steps 1-5.
2. Highlight **Pre-recorded** or **Custom**.
3. Press **Menu**.
4. Highlight **Play**.
5. Press **OK**.
Press **OK** again to stop.

Recording your Name

You can add your name to the pre-recorded announcement.

Follow these steps:

1. From the Standby mode, press **Menu**, highlight **Screen Call** and press **OK**.
2. Highlight **Announcement**, and press **OK**.
3. Highlight **Pre-recorded**.
4. Press **Menu**.
5. Highlight **Record Name**.
6. Press **OK**.

7. Press **OK** to start recording.
- ▶ When your name has already been recorded, select **Yes** or **No** for overwriting.
8. After the 1st recording, press **OK** again to start the 2nd recording.
9. To stop recording, wait for 12 seconds or press **OK**. (It's available for both 1st and 2nd recording.)
- ▶ Select **Erase Name** at step 5 above, and then select **Yes** to erase the recorded name.

Recording Custom Announcement

1. From the Standby mode, press **Menu**, highlight **Screen Call** and press **OK**.
2. Highlight **Announcement**, and press **OK**.
3. Highlight **Custom**.
4. Press **Menu**.
5. Highlight **Record**.
6. Press **OK**.
7. Press **OK** to start recording. You can record for up to 12 seconds.
- ▶ When the announcement has already been recorded, select **Yes** or **No** for overwriting.
8. After the 1st recording, press **OK** again to start the 2nd recording.
9. To stop recording, wait for 12 seconds or press **OK**. (It's available for both 1st and 2nd recording.)



Tip:

You should record the announcement twice because the phone needs to adjust to the base station programs.

Erasing Announcement

To erase your own recorded announcement:

1. Follow the previous steps 1-4.
2. Highlight **Erase**.
3. Press **OK**.
4. Highlight **Yes**.
5. Press **OK**.

Using Voice-Activated Dialing

When on the Sprint PCS Network, you can call up to 30 stored entries by speaking the name into the microphone of your Sprint PCS Phone. Using Voice-Activated Dialing requires that you first train the phone to recognize the name of the person you are calling.

Tips on Recording Names

- ▶ Avoid recording similar names phonetically. If you record a similar name to one that is already in memory, the phone requests another name.
- ▶ Avoid recording in a noisy place.
- ▶ Speak clearly and naturally.
- ▶ The person who will use the phone should record the name.
- ▶ Avoid very long or very short names. Names with two to five syllables are recommended.
- ▶ If a Voice-Activated Dialing entry does not properly connect, you may need to record the name and number again.

Programming the Phone for Voice-Activated Dialing

Programming your Sprint PCS Phone for Voice-Activated Dialing is easy. The phone provides voice prompts and screen displays to guide you through the recording process.

To program the phone for Voice-Activated Dialing:

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Voice Dial**.
3. Press **OK**.
4. Highlight **Program**.
5. Press **OK**.
6. The phone will prompt you to say the name you want to program.
7. Wait for the beep and then say the name.
8. Respond to the prompt by repeating the name after the beep.
9. Enter or highlight the entry (name) in the phone book entry list.
10. Press **OK**.
11. Select the labeled category that includes your desired phone number. Then display shows "Voice Dial Recorded".

Tip:

Voice-Activated Dialing cannot be recorded with Car Kit or Headset.

The entry stored by Voice-Activated Dialing will be marked with  icon in the phone book list.



Tip:

Voice-Activated Dialing is only applicable to the Phone Book entries.

Placing a Call Using Voice-Activated Dialing

1. From the Standby mode, press **TALK** shortly.
2. At the prompt, say the name into the phone in four seconds.
 - ▶ The phone places the call if it recognizes the name.
 - ▶ If the phone does not recognize the name, it prompts for the name again.
 - ▶ If the phone is unable to recognize the name after two attempts, the following message is displayed: "Cannot recognize name." The phone returns to Standby mode automatically, and you can try the call again later.
 - ▶ Avoid using Voice-Activated Dialing in noisy places.

Reviewing Voice-Activated Dialing Entries

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Voice Dial**.
3. Press **OK**.
4. Highlight **Review**.
5. Press **OK**.
6. Highlight the desired entry and press **OK**. Recorded names will play audibly.
or
Press **Menu**, highlight **Play** and press **OK**.
7. Press **CLR** to return to the previous display.

Erasing Voice-Activated Dialing Entries

To erase an individual Voice-Activated Dialing entry:

1. Highlight the desired entry (See previous “Reviewing Voice-Activated Dialing Entries”).
2. Press **Menu** to display the menu options.
3. Highlight **Erase**.
4. Press **OK**.
5. Highlight **Yes**.
6. Press **OK**.

To erase all Voice-Activated Dialing entries:

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Voice Dial**.
3. Press **OK**.
4. Highlight **Erase All**.
5. Press **OK**.
6. Highlight **Yes**.
7. Press **OK**.



Playing Game

Crab Catcher Game:

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Game/Tools**.
3. Press **OK**.
4. Highlight **Game**.
5. Press **OK**.
6. Select On or Off for the backlight of the display.
7. Press **OK** or wait a second. High Score display appears. If you want to erase High Score, press **CLR** (right soft key), and highlight **Yes**, and press **OK**.
8. Press **Start** (left soft key) to start.
 - ▶ Press **◀** or **▶** of the Navigation key (or use **Shift *** or **Space #**) to move the crab to left or right to catch apples into the crab's claw.
 - ▶ The game is over when three apples are not caught with the crab's claw.
9. To end the game, press **END/⓪**.

Using the Calculator

Your phone comes with a built-in calculator function. To use this function, follow these easy steps:

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Game/Tools**.
3. Press **OK**.
4. Highlight **Calculator**.
5. Press **OK**.
 - ▶ For addition, press **▲**
 - ▶ For subtraction, press **▼**
 - ▶ For multiplication, press **◀**
 - ▶ For division, press **▶**
 - ▶ For decimal, press left soft key
 - ▶ To clear the numbers, press right soft key
 - ▶ To end calculation, press **END/⓪**



Tip:

See the SANYO Multimedia Master User Guide included in the SCP-5000 for downloading.

Tip:

If you have no downloaded data, "No Data Downloaded" is shown on the display.

Tip:

It's better to erase the downloaded data that you have set to Ringer or Start-up/Power-off tone. See page 126.

Using the Downloaded Data

Setting a Downloaded Melody to the Ringer or Start-up/Power-off Tone

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Game/Tools**.
3. Press **OK**.
4. Highlight **Downloads**.
5. Press **OK**.
6. Highlight your desired downloaded melody title and press **OK**. Then starts to play the selected melody.
7. Press **Menu** or wait for ending of the melody play.
8. Highlight either **Set Ringer**, **Set St-up Tone** or **Set Pw-off Tone**.
9. Press **OK**.
10. Select the space to assign your selected melody.
 - ▶ If your selected space is already assigned, you are prompted whether overwrite it or not.
 - ▶ The maximum file size that you can download is 100 Kilo-Byte.
The file size that is possible to set after downloading by SCP-5000 is as shown below.

Ringer Melody	~ 20 KB	20 files
	~ 100 KB	2 files
Start-up Tone	~ 20 KB	3 files
Power-off Tone	~ 20 KB	3 files

Setting a Downloaded Pictures to the Wallpaper or Incoming Call Display

1. Follow the previous steps 1-5.
2. Highlight your desired downloaded picture name and press **OK**. The selected picture is displayed.
3. Press **Menu** or wait a second.
4. Highlight **Set Wallpaper** or **Set Incom-Call**.
5. Press **OK**.
6. Select the space to assign your selected picture.
 - If your selected space is already assigned, you are prompted whether to overwrite it or not.

Returning the assigned melody or picture data to unassigned:

1. From the Standby mode, press **Menu**.
2. Highlight **Game/Tools** and press **OK**.
3. Highlight **Downloads** and press **OK**.
4. Press **Menu** to display the options.
5. Highlight **Unassign** and press **OK**.
6. Highlight your desired item, and press **OK**.
7. Highlight the data you want to cancel, and press **OK**.
8. Highlight **Yes** and press **OK**.

Tip:

If you have no downloaded data, "No Data Downloaded" is shown on the display.

Tip:

It's better to erase the downloaded data that you have set to Wallpaper or Incoming Call. See page 126.



Erasing Individual or All Downloaded Data

To erase an individual downloaded melody or picture data:

1. Highlight one of the downloaded melody titles or picture names by using the steps as described before. (See page 124.)
2. Press **OK**.
3. Press **Menu** to display the options.
4. Highlight **Erase**.
5. Press **OK**.
6. Highlight **Yes**.
7. Press **OK**.

To erase all downloaded melodies and/or pictures:

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Game/Tools**.
3. Press **OK**.
4. Highlight **Downloads**.
5. Press **OK**.
6. Press **Menu** to display the options.
7. Highlight **Erase Data** and press **OK**.
8. Highlight **Erase All Melod.** or **Erase All Pict.**

If you want to erase all melodies and pictures, highlight **Erase Both**.

9. Press **OK**.
10. Highlight **Yes**.
11. Press **OK**.

Tip:

Erasing downloaded data cannot erase the data that had already been set to Ringer, Wallpaper, etc.

13

Experiencing Sprint PCS Wireless WebSM

In this Section

- ▶ The Sprint PCS Wireless Web Browser
- ▶ Launching the Sprint PCS Wireless Web Browser Session
- ▶ Navigating the Sprint PCS Wireless Web
- ▶ Using Special Features within the Sprint PCS Wireless Web
- ▶ Setting up the Sprint PCS Wireless Web Connection
- ▶ Accessing Sprint PCS Wireless Web Updates

By now you've discovered the great features that come with your Sprint PCS Phone™. Now it's time to experience the Sprint PCS Wireless Web.

Sprint PCS
Wireless Web
13

Note:

Sprint PCS
Wireless Web service
will not work when
roaming off the
Sprint PCS
Nationwide Network
and may not be
available in select
Affiliate areas.

The Sprint PCS Wireless Web Browser

Your phone comes equipped with a MiniBrowser, which allows you to access up-to-the-minute information through the Sprint PCS Wireless Web.

You can view specially-designed text versions of popular Internet sites including Yahoo!®, CNN.comSM, The Weather Channel® and more. Browsing the wireless Internet using your phone is different than using a home computer. Site providers select the most critical aspects of their site and present it in text format.

Whenever you launch the Sprint PCS Wireless Web Browser, your phone automatically connects to the Wireless Internet through the Sprint PCS Wireless Web and a  appears on the display. Service charges vary depending on your service option.

If you have not signed up for the Sprint PCS Wireless Web option and would like to, visit our web site at www.sprintpcs.com or call Customer Care for details.

The Sprint PCS Wireless Web Browser ends a connection after a certain period of network inactivity and automatically reconnects as necessary. For this reason, you may find that you are billed for several network connections within a single session. This is normal and is designed to minimize costs.

Setting Web Guard

When you launch the Sprint PCS Wireless Web Browser, a message on your display screen reminds you that you are billed for the airtime.

To set Web Guard:

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight **Wireless Web**.
3. Press **OK**.
4. Highlight **Web Guard**.
5. Press **OK**.
6. Select one of the options.

Options:

To Start sets the reminder when you launch the Browser.

To Start/Exit sets the reminder both of when you start and exit the Browser.

Tip:

Remember, anytime you see  on your display, your phone is connected to the Sprint PCS Nationwide Network and you are billed accordingly.



Tip:

To send e-mail from your phone, press **Email** (left soft key) in the Standby mode.

Launching the Sprint PCS Wireless Web Browser Session

There is a security setup process that you will go through the first time you launch the Sprint PCS Wireless Web Browser. Please follow the on-screen prompts and wait 3-6 minutes to complete the security setup process.

To launch the Sprint PCS Wireless Web Browser:

1. Press and hold **Web** (or press **Web**).

OR

1. From the Standby mode, press **Menu** to display the main menu.
 2. Highlight **Wireless Web**.
 3. Press **OK**.
 4. Highlight **Launch Browser**.
 5. Press **OK**.
- When a reminder of the charge appears, select “Yes”. After a few moments, you are connected to your Home Page.

Here is an example of a home page:*

WIRELESS WEB
 1 @Sprint PCS
 2 My Wireless Web
 3 AOL
 4 Amazon.com
 5 Yahoo!
 6 MSN Mobile
 7 Fidelity
 OK MENU

* Subject to change

Ending the Sprint PCS Wireless Web Browser Session

To end a Sprint PCS Wireless Web Browser session:

- ▶ **From the home page**, press **END/⓪** to exit the MiniBrowser and return your phone to Standby mode.
OR
- ▶ **From anywhere in the browser**, at any time, press **END/⓪** and your phone exits the MiniBrowser and returns to Standby mode. Exiting this way saves the URL (web site location) that you were using last.

Tip:

If the "To Start/Exit" option is set in the MiniBrowser "Web Guard", you are prompted whether or not you want to end the browser call.

Sprint PCS
Wireless Web
13

Navigating the Sprint PCS Wireless Web

While using the Sprint PCS Wireless Web Browser, you will find that on-screen items may be presented in one of the following ways:

- ▶ Numbered options (some options may not be numbered)
- ▶ Hyperlinks (embedded in content)
- ▶ Text or numeric input
- ▶ Simple text

Use the soft keys on the bottom line of the display to choose the options or links. You can use these keys by pressing the left/right soft key corresponding to the menus displayed on the bottom line of the display.

Knowing your Navigation Keys

The following keys allow you to navigate the Sprint PCS Wireless Web:

- ▶ **Scrolling up/down by item** You can use  to scroll through contents when a page does not fit on one screen and to move the cursor. The selected item is indicated by a > cursor or highlighted on the screen.
- ▶ **Scrolling up/down by page** Use the side volume key  or  to scroll through information a page at a time rather than a line at a time.
- ▶ **Back to previous page** When you're viewing a web page and want to go back to a previous page, press . From the Browser menu, pressing  and selecting "Home" returns you to the Home Page.
- ▶ **Clearing out text/number entered** When you need to clear the last number, letter or symbol entered, press . To completely clear the field, press and hold .
- ▶ **Selecting and activating items using soft keys and/or digits** If the items on a page are numbered, you can use your keypad (number keys) to select an item, or you can select the items by moving the cursor and selecting the appropriate soft key.



Tip:

You can shift the method of entering letters to upper/lower case by pressing  (if available).

Soft keys help you navigate to different screens or select special functions. They appear on the bottom screen of your phone's display. The function of soft keys can change with each page and also depend on each highlighted item.

- ▶ Press  (left)— The left soft key is used primarily for selecting the highlighted item but its function can change.
- ▶ Press  (right)— The right soft key is used primarily for secondary options or a menu of secondary options.

Entering text, numbers or symbols Each time you're prompted to enter text, the current text entry method displays the mostly right soft key as:

- ▶ ALPHA: ALPHABET — Caps Lock
- ▶ + ALPHA: Alphabet — One-character shifted
- ▶ alpha: alphabet — Unshifted
- ▶ SYM 1, SYM 2, SYM 3, SYM 4: Symbol mode
- ▶ NUM: Number mode
- ▶ WORD: T9 WORD — Caps Lock
- ▶ + WORD: T9 Word — One-character shifted
- ▶ word: T9 word — Unshifted

To change the input mode:

1. Press left/right soft key corresponding to your desired input mode.

Using Special Features within the Sprint PCS Wireless Web

Using Links

Links allow you to jump to a different page or a different site. They even allow you to initiate a phone call from some sites. Links are represented by [Link]. You can normally use the left soft key to select a link when it's displayed.

Making a Phone Call from the Sprint PCS Wireless Web Browser

There are some sites that allow you to make a phone call from the Sprint PCS Wireless Web Browser. The phone number may be highlighted and the left soft key appears as "Call." In most cases, press **TALK** to call the number. When making a call from the Sprint PCS Wireless Web Browser, the following takes place:

- ▶ When you first make the call, the Sprint PCS Wireless Web Browser connection is automatically terminated.
- ▶ After you end the call, your phone will return to the screen from which you initiated the call.



Creating a Bookmark

Bookmarks tag individual pages for easy access at a later time. Bookmarks save time by reducing the number of steps it takes to access a desired site.

1. Go to the page you want to mark.
 2. Press **Menu** to be in the Browser Menu.
 3. Select “Mark Site”.
 4. When a page has a title, it is automatically used for the name of the bookmark. If you like, you can change the name.
 5. Select **Save** to save the name and add the page to your list of bookmarks. A message appears confirming the bookmark was added to the list.
 6. Select **OK** to return to the screen that you marked and resume navigation within the Sprint PCS Wireless Web Browser.
- The new bookmark is added to the bottom of your bookmark list.

Finding a Bookmark

1. From the home page, select My Wireless Web then select **Bookmarks**.
2. Choose the bookmark you want. Press the number associated with the bookmark in the bookmark list.

Deleting a Bookmark

1. From the bookmark list, scroll to the bookmark you want to delete.
2. Press **Menu** (right soft key).
3. Select “Delete” from the options. A message displays prompting you to confirm.
4. Select “Yes” to delete the bookmark.



Tip:

You will need to install Sprint PCS Dialer Software by using your CD that is included in the set of SCP-5000. See Sprint PCS Dialer Software User Guide for details.

Tip:

You will not need to install the Sprint PCS Dialer for Palm or HPC/Wince.

Setting up the Sprint PCS Wireless Web Connection

Wireless Modem – Data and Fax Calls

Getting Started

Your wireless Internet-ready Sprint PCS Phone allows you to connect to a laptop PC, handheld or palm-sized computing device to send and receive e-mail, access the Internet or your company's network and more, without searching for a wall-mounted telephone jack. In just three steps, you can use your connectivity:

1. First, you'll need a data cable and Sprint PCS DialerSM software.
2. Connect your laptop PC to your Sprint PCS Phone by using the serial data cable. The cable adapter will connect to a handheld or palm-sized computing device.
3. Finally, take a few minutes to install the Sprint PCS DialerSM software onto your computer using your CD.

For complete details on how to install and use this software, refer to the user guide of this kit.

Placing a Call

To place a call while you're connected to the Sprint PCS Wireless Web:

1. First, make sure the cable is connected properly.
2. Open the Sprint PCS Dialer software or application on your computer and place the call.
 - ▶ The phone displays the number your computer is calling and a "connecting" message is displayed.
 - ▶ Once the call successfully connects, press **OK** to display the status of the data call.

Receiving a Call

To receive a call while you're connected to the Sprint PCS Wireless Web.

1. From the Standby mode, press **Menu**.
2. Highlight **Wireless Web**.
3. Press **OK**.
4. Highlight **Connection**.
5. Press **OK**.
6. Highlight **Data/Fax (In)**.
7. Press **OK**.
8. Highlight **Incoming Fax** or **Incoming Data**, and press **OK**.
 - ▶ Open the Sprint PCS Dialer software to automatically answer incoming calls.
 - ▶ Your phone will display either "Data Call From:" or "Fax Call From:", depending on the type of incoming call.

Tip:

Your phone's display shows you information on the status of the Sprint PCS Wireless Web Connection call.

Tip:

To terminate the data call, use your Sprint PCS Dialer software; fax calls typically terminate automatically.

Don't press **END/0** while sending data, this may cause your data or fax application to temporarily lock up and could cause loss of data.



Tip:

Caller ID is not available on Sprint PCS Wireless Web Browser calls.

Using Special Features During a Sprint PCS Wireless Web Call

Your phone gives you the ability to use special features while you're on a wireless Internet call. They are outlined below:

- ▶ **Caller ID:** Just like your phone stores regular Caller ID numbers, it also stores the numbers of incoming Sprint PCS Wireless Web Connection calls. To distinguish between the two types of calls, "Data" or "Fax" displays along with the number of the caller when you view your Caller ID records.
- ▶ **Call Waiting:** If someone tries to reach you while you're connected to the Sprint PCS Wireless Web, your phone behaves like it is turned OFF. Depending on your service, callers may get your voicemail. Call Waiting is automatically deactivated whenever you place or receive a Sprint PCS Wireless Web Connection call.
- ▶ **Accessing features:** You can still access most of your phone's features while you're connected to a Sprint PCS Wireless Web Connection Call. You can navigate the phone's menu system to change or view your phone's features or Phone Book entries. You can also read messages or view the Caller ID records that you received before placing the call.

Ending a Sprint PCS Wireless Web Call

It's important to note that some of the normal ways to end a call won't work with the Sprint PCS Wireless Web Connection calls. You should always close the connection through the application on your computer. Your phone will then return to Standby mode.

Although you can end a wireless web connection call by disconnecting the data cable or turning off your phone, this may disrupt your computer.

- You should disconnect the data cable immediately after ending a Sprint PCS Wireless Web call because the battery consumption is quite high while connecting the data cable.



Accessing Sprint PCS Wireless Web Updates

With Sprint PCS Wireless Web Updates, you'll automatically receive the information that's important to you. Internet updates are sent at the times you choose with the Sprint PCS Wireless WebSM Messaging capability.

By using personalization options on the My Yahoo! Page, you can decide which updates you want to receive. In addition to stock quotes and news headlines, you'll also have access to weather reports, Yahoo!, sports scores and more.

Every Sprint PCS Phone is capable of receiving updates or other text messages if you have signed up for a messaging plan.

To enroll in Sprint PCS Wireless Web Updates, you must be able to access the Internet from a computer.

To sign up:

1. Visit www.sprintpcs.com to sign up for service.
2. Visit www.sprintpcs.my.yahoo.com to change selections and times after your initial sign-up for the service.

Receiving a Sprint PCS Wireless Web Update Alert (Messages)

If your phone is on and you receive a message alert, your phone's alert may sound/vibrate and an  icon appears. To view the alert (message), follow the steps listed below:

1. From the Standby mode, press **Menu**.
2. Highlight **Wireless Web**.
3. Press **OK**.
4. Highlight **Web Alert**.
5. Press **OK**.
6. Highlight **Yes**, and press **OK**.

OR

When the notification display is shown:

1. Select "View".
 2. Highlight your desired message title, and press **OK**.
- Select "Skip" on the notifying display to return to the Standby mode.



14

Learning the Settings on your Sprint PCS Phone

In this Section

- Viewing the Menus
- Working within the Menu Structure
- Defining the Menu Categories

This section is the road map to using your Sprint PCS Phone™. Every function and feature you've learned can be accessed through a menu. Take a few moments to get to know your way around. You'll find that it makes it easier to use and understand your phone.





Viewing the Menus

Menu Diagram


Menus let you check or change your phone settings. The following illustration shows the menu structure. Later in the section, you'll find out how to use menus and a more detailed description of each feature.

*: Message count





→ Set Mode
↕
↓ Call Guard



→ Call Voicemail
↕
↓ Details
↓ Clear Count



→ Sounds
↕
↓ Display
↓ Security
↓ Others




→ Game
↕
↓ Calculator
↓ World Clock
↓ Downloads



→ Program
↕
↓ Review
↓ Erase All





Working within the Menu Structure

Entering the Menu Structure

To open a menu:

1. From the Standby mode, press **Menu** to display the main menu.
2. Highlight your desired menu by using the Navigation key.
3. Press **OK**.
4. Press **Menu** to see the options. (Some items have no options.)

Backing up within a Menu

To go to the previous menu:

1. Press **CLR** to return to the previous step (display) one by one.

or

Press **END/⓪** to return to the Standby display.

Defining the Menu Categories

The main menu in Standby mode contains 12 primary options, most of which contain sub-menus with context-specific options.

Call History

This feature tracks each 10 outgoing, 10 incoming and 10 missed calls for reference or call back (See Section 6). Pressing **Menu**, you can select options to the entry.

- ▶ **Outgoing Calls** store the numbers you called.
- ▶ **Incoming Calls** store the numbers you received.
- ▶ **Missed Calls** store the numbers of calls that were missed.

Wireless Web

Your phone allows you to receive and send messages. For the Wireless Web, see section 13. For the Messages, see section 8.

- ▶ **Messages(*)** receive the messages. It also allows you to create a folder with your own entered folder name. See “Creating a Folder” on page 69.
- ▶ **Web Alert** lets you access the Wireless Web update message when the alert and an  icon notifies you that you have received it.
- ▶ **Connection** allows you to connect to a laptop PC, handheld or palm-sized computing device to send and receive Data/Fax.

*: Message count

- ▶ **Launch Browser** lets you launch the Wireless Web Browser.
- ▶ **Web Guard** When you launch the Browser, a message on your display screen reminds you that you are billed for the airtime.

Phone Book

A total of 300 names, 500 phone numbers, 300 e-mail addresses and 300 web addresses can be assigned to different Phone Book entries (up to 9 numbers or addresses per entry). See Section 9.

- ▶ **Find Name** searches the entry name with the number.
- ▶ **Add New Entry** lets you store the new entry to the existing Phone Book.
- ▶ **Speed Dial #s** let you store the number as a Speed Dial. You can dial the entry number by pressing only one key (2-9).
- ▶ **Long Phone#s** let you see the long phone number that you entered.
- ▶ **Services** let your phone connect to the Sprint PCS service from the menu. **Customer Care, Dir Assist, Prepaid, Road Assist** and **Account Info.** are available. See “Getting Help” on page 13-17.

Calendar

The calendar menu allows you to track and prioritize some events and important calls you need to make. It is useful to manage your schedules, see “Managing Schedules” on page 105.

Roaming

This menu controls your roaming experience. See Section 3.

- ▶ **Set Mode** allows you to select the Roaming mode from “Sprint PCS”, “Automatic” or “Analog”.
- ▶ **Call Guard** alerts you when roaming charge apply.

Voicemail

This feature allows callers to record voice messages when you cannot answer the call.

- ▶ **Call Voicemail** accesses to the recorded voicemail.
- ▶ **Details** let you know the details of your voicemail.
- ▶ **Clear Count** resets the  icon when the network does not clear it.

Settings

This feature contains four main settings of the phone.

► **Sounds** adjust sound-related features.

The following items can be adjusted (see section 5 for details):

- **Ringer/Key Vol.** adjusts the incoming call ringer, key beep, headset key beep or car kit ringer/key beep. You can choose from:
 - High + Vibrate (Only applicable to “Ringer Volume”.)
 - High
 - Medium High
 - Medium Low
 - Low
 - Vibrate (Only applicable to “Ringer Volume”.)
 - Off
- **Ringer Type** lets you select the ringer types for Voice Calls, Voicemail, Messages or Web Alert. Your Sprint PCS Phone provides you with multiple ringer types including 4 chord melodies, vibration and none. If you have downloaded melody data, you can also select it.
- **Alerts** give you access to the feature listed below.
 - **Service** sounds an audible alert when a network service parameter changes. For instance, if you leave the Sprint PCS Nationwide Network and start roaming, the phone beeps to notify you.

- **Voicemail** sounds an alert once or every two minutes (with reminder) whenever you receive a voicemail.
- **Messages** sounds an alert once or every two minutes when you receive messages.
- **Web Alert** sounds an alert once or every two minutes when you receive wireless web messages.
- **Minute Beep** sounds an alert every 10 seconds before each minute during a call. This helps you track your phone use.
- **Receiver Volume** adjusts the earpiece volume. You can also select headset earpiece volume or car kit speaker volume. You can choose from:
 - High
 - Medium High
 - Medium Low
 - Low
- **Melody Tempo** changes the tempo of the selected melodies for ringer. You can choose from:
 - Fast
 - Medium Fast
 - Normal
 - Medium Slow
 - Slow
- **Others** select following settings:
 - **Tone Length** sets the key beep length and touch-tone playback speed. Short length emits a short beep. Long length emits a beep for as long as you hold down a key.

- **Start-up Tone** selects a tone, which sounds when you turn the phone on (except when Key Beep volume is off). You can choose a tone from 4 preset tones and any downloaded data.
- **Power-off Tone** selects a tone, which sounds when you turn the phone off.
- **Display** lets you customize your phone's screen. See section 10 for details.
 - **Backlight** lets you choose how long the display screen and keypads are backlit after any key press is made. Options include:
 - Always Off
 - 8 Seconds
 - 15 Seconds
 - 30 Seconds
 - **Greeting** lets you customize the 15 characters of text displayed on the first line of your phone's display screen in Standby mode.
 - **Font Size** lets you select a font size of Messages or Browser. Options are:
 - Smallest
 - Small
 - Normal
 - Large
 - **Color** lets you select a color of the phone's display screen. Options are:
 - Forest
 - Sunset
 - Evening
 - Dawn

Tip:

Some of these items will not be shown in Analog mode or No Service areas. See page 92.

■ **Contrast** lets you change the contrast setting of the Main LCD or Sub LCD. You can choose from:

- Highest
- High
- Medium
- Low
- Lowest

■ **Animation** lets you display an animation as a screen saver or a display of outgoing calls.

■ **Incoming Calls** let you set the color or graphic (downloaded data) to be shown on a display of incoming calls. Options are:

- Red
- Yellow
- Black
- Pea Green
- Celadon Green
- Navy Blue
- Claret
- Downloaded Data (If you have)
- Off

■ **Standby Display** lets you display an item on the Standby mode display. You can choose from:

- World Clock
- Time (Large)
- Calendar
- Text
- Count Down
- Wallpaper
- Off

- **Sleep Mode** conserves the battery power by restricting the contents of the display screen shows on Standby, Power Save, Missed Calls, Message Alert, Missed Alarm, etc.
- **Version** displays the version number of the software, hardware, PRL (Preferred Roaming List), PRI (Product Release Instructions) and Browser installed on your Sprint PCS Phone.
- ▶ **Security** Before accessing any items in this menu, you'll need to enter a four-digit lock code. This code is typically the last four digits of your phone number, social security or tax ID Number or 0000. See section 11 for details.
 - **Lock Phone** locks your phone so that you still receive incoming calls but can only make outgoing calls to your emergency numbers.
 - **Erase Phone Book** erases the entire Internal Phone Book.
 - **Reset Phone** lets you restore all the factory defaults, including ringer types, display setting, etc.
 - **Security Setting** lets you select 4 optional settings as shown below.
 - **Lock Code** lets you change the existing lock code to a new four-digit lock code.
 - **Limit Use** limits your outgoing calls or incoming calls. The options on this setting include "Allow All", "Phone Book Only" and "Special #s Only".

- **Special #s** allows you to store three important phone numbers that you would like to access even if your phone is locked.
- **Found Me** resets or locks your phone by sending text messages when the phone is lost or stolen.
- **Others** allows you to set following menus as shown below.
 - **AnyKey Answer** enables you to answer incoming calls by pressing any key (not including the **END/⓪**, **CLR**, **END**, side volume key **▲** / **▼**, Navigation key, and **Menu**).
 - **AutoAns. Car/HS** sets the phone to automatically pick up calls after 5 or 15 seconds.
 - **Open to Answer** enables you to answer incoming calls by opening the clamshell.
 - **Side Key Guard** disables the side keys (**END** and **▲** / **▼**) so that your phone is protected against accidental operation while the clamshell is closed.
 - **Abbrev. Dial** lets you store the prepend number for abbreviated dialing. See page 86 for details.
 - **Language** allows you to choose the language (English or Spanish) used to display your phone's menus and enter special language characters on the display.

Game/Tools

This menu allows you to take time out to enjoy game/tools function as shown below.

- ▶ **Game** lets you play the “Crab Catcher Game”.
- ▶ **Calculator** gives you easy-to-use calculator function.
- ▶ **World Clock** lets you see the world clock (except when your phone is in Analog mode or No Service area).
- ▶ **Downloads** allow you to set the downloaded Melodies for Ringer/Start-up Tone/Power-off Tone and the Pictures for Standby/Incoming call display.

Voice-Activated Dialing

This function enables you to call by speaking a programmed name into the microphone.

- ▶ **Program** allows you to record up to 30 entry names for Voice-Activated Dialing.
- ▶ **Review** displays the Voice-Activated Dialing entry list and has options to play or erase the selected entry.
- ▶ **Erase All** erases the entire Voice-Activated Dialing entry list.

Screen Call

This feature enables you to answer incoming calls by using announcements, and record the caller's voice into the Voice Memo list. For more information on this feature, see page 115.

- ▶ **Auto** lets your phone answer a call and works screen call automatically.
- ▶ **Announcement** lets you select the reply message either pre-recorded or your own-recorded announcement.

My Profile

This phone can store your personal data (see page 104 for details.) Personal data includes:

- ▶ **My Name** displays your own name.
- ▶ **My PCS#** displays your PCS phone number.
- ▶ **Birthday** displays your birthday.
- ▶ **Blood Type** displays your blood type.
- ▶ **Address** displays your address.
- ▶ **H Phone#** displays your home phone number.
- ▶ **H Email** displays your home e-mail address.
- ▶ **W Phone#** displays your office phone number.
- ▶ **W Email** displays your office e-mail address.

PC Sync

Use this menu when you download melody or picture data from your PC to your phone. For that process, data cable and Sanyo Multimedia Master software that are included in the set of SCP-5000 are required. While connecting to PC, your phone cannot answer incoming calls and those calls don't remain as "Missed Call" in the call history list. See SANYO Multimedia Master User Guide.

15

Selecting your Accessories

In this section

- Overview of Available Accessories for this Phone
- How to Order

A variety of accessories is available for your new Sprint PCS Phone™. Choose from chargers, batteries, etc. — all designed to give you more flexibility and convenience.



Overview of Available Accessories for this Phone

Standard Battery

The standard battery provides up to 2 hours of talk time and up to 120 hours of standby time in digital mode. Up to 45 minutes of talk time and 10 hours of standby time in analog mode. The battery charges in 2 hours using any of the charging accessories available with this phone.

Model Number: SPY5BT005

Extended Battery

The extended battery provides up to 5 hours of talk time and up to 12 days of standby time in digital mode. Up to 105 minutes of talk time and 27 hours of standby time in analog mode. The battery charges in 4 hours using any of the charging accessories available with this phone.

Model Number: SPY5BT013

Cigarette Lighter Adapter

You can charge your phone (even during a call) in your vehicle using the cigarette lighter adapter. The cigarette lighter adapter charges the standard battery in approximately 2 hours and the extended battery in 4 hours.

Model Number: SPY5PC001

Desktop Charger (Dual-Slot Charger)

Charges your phone and a standard or extended battery. Two color LEDs indicate when the battery or phone is charging or is fully charged. The front slot of the desktop charger charges the standard battery in approximately 2 hours and the extended battery in 4 hours. The back slot of the desktop charger charges the standard battery in approximately 2 hours and the extended battery in approximately 4 hours.

Model Number: SPY5CH003

Tip:

With this desktop charger you can also connect your PC by using the data cable and charge the battery by using the Travel Charger at the same time.

Selecting your
Accessories
15

Travel Charger

Compact and lightweight, this is a convenient way to charge your phone while on the road. The Travel Charger charges the standard battery in approximately 2 hours and the extended battery in approximately 4 hours.

Model Number: SPY5CH001

How to Order

Most Sprint PCS Accessories found at local Sprint PCS Centers can also be purchased through the Sprint PCS Accessory HotlineSM by calling 1-800-974-ACC1 (2221). Next day delivery is offered in select areas.

16

Knowing Performance and Safety Guidelines

Performance
and Safety

16

In this section

- ▶ **Getting the Most Out of your Reception**
- ▶ **Safety Information: FCC RF Exposure Information**
- ▶ **Maintaining Safe Use of and Access to your Phone**
- ▶ **Caring for the Battery**
- ▶ **Acknowledging Special Precautions and the FCC Notice**

Part of getting the most out of your Sprint PCS Phone™ is knowing where and how it works at optimum efficiency. This section outlines performance and safety guidelines that ensure you experience the full quality your Sprint PCS Phone was designed to give you.

Getting the Most Out of your Reception

Keeping Tabs on Signal Strength

The call quality of your phone is always at its best when the antenna is fully raised. If you're inside a building, being near a window may give you better reception.

The quality of each call you make or receive depends on the signal strength in your area. Your phone informs you of the current strength by displaying a number of bars next to the signal strength icon. The more bars displayed, the stronger the signal.

Understanding Power Save Feature

If you try to use your Sprint PCS Phone in an area where the signal is not available, the Power Save feature automatically activates to conserve battery power if you're unable to pick up a signal for 15 minutes. If your phone is on, it periodically rechecks service availability or you can check yourself by pressing any key. Anytime the Power Save feature is activated, a message displays on the screen.

Understanding How your Phone Operates

Your phone is basically a radio transmitter and receiver. When it's turned on, it receives and transmits radio frequency (RF) signals. When you use your phone, the system handling your call controls the power level. This power can range from 0.006 watts to 0.2 watts in digital mode.

**Safety Information:****FCC RF Exposure Information**

WARNING! Read this information before using your phone

In August 1996 the Federal Communications Commission (FCC) of the United States with its action in Report and Order FCC 96-326 adopted an updated safety standard for human exposure to radio frequency electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies. The design of this phone complies with the FCC guidelines and these international standards.

CAUTION

Use only the supplied or an approved antenna. Unauthorized antennas, modifications, or attachments could impair call quality, damage the phone, or result in violation of FCC regulations.

Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with the skin, a minor burn may result. Please contact your local dealer for replacement antenna.

Body-worn Operation

This device was tested for typical body-worn operations with the back of the phone kept 0.40 inches (1.0 cm) from the body.

To comply with FCC RF exposure requirements, a minimum separation distance of 0.40 inches (1.0 cm) must be maintained between the user's body and the back of the phone, including the antenna, whether extended or retracted. All belt-clips, holsters and similar accessories used by this device must not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with FCC RF exposure limits and should be avoided.

Note: For more information about RF exposure, please visit the FCC website at www.fcc.gov

Specific Absorption Rate (SAR) for Wireless Phones

The SAR is a value that corresponds to the relative amount of RF energy absorbed in the head of a user of a wireless handset.

The SAR value of a phone is the result of an extensive testing, measuring and calculation process. It does not represent how much RF the phone emits. All phone models are tested at their highest value in strict laboratory settings. But when in operation, the SAR of a phone can be substantially less than the level reported to the FCC. This is because of a variety of factors including its proximity to a base station antenna, phone design and other factors. What is important to remember is that each phone meets strict federal guidelines. Variations in SARs do not represent a variation in safety.

All phones must meet the federal standard, which incorporates a substantial margin of safety. As stated above, variations in SAR values between different model phones do not mean variations in safety. SAR values at or below the federal standard of 1.6 W/kg are considered safe for use by the public.

The highest reported SAR values of SCP-5000 are:
AMPS mode (Part 22) - Head: 1.40 W/kg;
Body-worn: 1.35 W/kg
PCS mode (Part 24) - head: 0.66 W/kg;
Body-worn: 1.38 W/kg.

Maintaining your Phone's Peak Performance

There are several simple guidelines to operating your phone properly and maintaining safe, satisfactory service.

- ▶ Extend the antenna fully for best reception.
- ▶ Hold the phone with the antenna up and over your shoulder.
- ▶ Do not hold, bend or twist the phone antenna.
- ▶ Retract the phone antenna when you're not on a call.
- ▶ Don't use the phone if the antenna is damaged.
- ▶ Speak directly into the mouthpiece.
- ▶ Avoid exposing your phone and accessories to rain or liquid spills. If your phone does get wet, immediately turn the power off and remove the battery. If it's inoperable, return it to a Sprint PCS Center or call Sprint PCS Customer Care for service.
- ▶ Keep magnetic cards, magnetic tapes, floppy disks, etc. away from your Sprint PCS Phone, or their memory may be erased by magnetism emitted from the speakers of the phone.

Tip:

For the best care of your phone, only Sprint PCS authorized personnel should service your phone and its accessories. Faulty service may void the warranty.

Maintaining Safe Use of and Access to your Phone

FAILURE TO FOLLOW THE INSTRUCTIONS OUTLINED IN THIS SECTION MAY LEAD TO SERIOUS PERSONAL INJURY AND POSSIBLE PROPERTY DAMAGE

Tip:

If you really need to use your phone while you're driving, use speed dialing.

Using your Phone While Driving

Talking on your phone while driving is illegal in some states. Even where it's not, it can divert your attention from driving. Remember that safety always comes first.

When using your phone in the car:

- ▶ Get to know your phone and its features, such as speed dial and redial.
- ▶ When available, use a hands-free device.
- ▶ Position your phone within easy reach.
- ▶ Let the person you are speaking to know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.
- ▶ Do not take notes or look up phone numbers while driving.
- ▶ Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic.
- ▶ Do not engage in stressful or emotional conversations that may divert your attention from the road.

- ▶ Dial **9 1 1** to report serious emergencies. It's free from your wireless phone.
- ▶ Use your phone to help others in emergencies.
- ▶ Call roadside assistance or a special non-emergency wireless number when necessary.

Following Safety Guidelines

To operate your phone safely and efficiently, always follow any special regulations in a given area. Turn your phone off in areas where use is forbidden or when it may cause interference or danger.

Tip:

Always turn off the phone in healthcare facilities and request permission before using the phone near medical equipment.

Using your Phone Near Other Electronic Devices

Most modern electronic equipment is shielded from radio frequency (RF) signals. However, RF signals from wireless phones may affect inadequately shielded electronic equipment.

RF signals may affect improperly installed or inadequately shielded electronic operating and entertainment systems in motor vehicles. Check with the manufacturer or its representative to determine if these systems are adequately shielded from external RF signals. Also check with the manufacturer regarding any equipment that has been added to your vehicle.

Consult the manufacturer of any personal medical devices, such as pacemakers and hearing aids, to determine if they are adequately shielded from external RF signals.

Turning Off your Phone Before Flying

Turn off your phone before boarding any aircraft. To prevent possible interference with aircraft systems, the U.S. Federal Aviation Administration (FAA) regulations require you to have permission from a crew member to use your phone while the plane is on the ground. To prevent any risk of interference, FCC regulations prohibit using your phone while the plane is in the air.

Turning Off your Phone in Dangerous Areas

To avoid interfering with blasting operations, turn off your phone when in a blasting area or in other areas with signs indicating that two-way radios should be turned off. Construction crews often use remote-control RF devices to set off explosives.

Turn off your phone when you're in any area that has a potentially explosive atmosphere. Although it's rare, your phone or its accessories could generate sparks. Sparks could cause an explosion or a fire resulting in bodily injury or even death. These areas are often, but not always, clearly marked. They include:

- ▶ Fueling areas such as gas stations
- ▶ Below deck on boats
- ▶ Fuel or chemical transfer or storage facilities
- ▶ Areas where the air contains chemicals or particles such as grain, dust or metal powders
- ▶ Any other area where you would normally be advised to turn off your vehicle engine

Restricting Children's Access to your Phone

Your Sprint PCS Phone is not a toy. Children should not be allowed to play with it because they could hurt themselves and others, damage the phone or make calls that increase your phone bill.

Tip:

Never transport or store flammable gas, liquid or explosives in the compartment of your vehicle that contains your phone or accessories.

Caring for the Battery

Protecting your Battery

The guidelines listed below help you get the most out of your battery's performance.

- ▶ Use only Sprint-approved batteries and travel charger, cigarette lighter adapter, and desktop chargers. These chargers are designed to maximize battery life. Using other batteries or chargers voids your warranty and may cause damage.
- ▶ In order to avoid damage, charge the battery only in temperatures that range from 32° F to 104° F (0° C to 40° C).
- ▶ Don't use the battery charger in direct sunlight or in high humidity areas, such as the bathroom.
- ▶ Never dispose of the battery by incineration.
- ▶ Keep the metal contacts on top of the battery clean.
- ▶ Don't attempt to disassemble or short-circuit the battery.
- ▶ The battery may need recharging if it has not been used for a long period of time.
- ▶ It's best to replace the battery when it no longer provides acceptable performance. It can be recharged hundreds of times before it needs replacing.
- ▶ Don't store the battery in high temperature areas for long periods of time. It's best to follow these storage rules:
Less than one month:
-4° F to 131° F (-20° C to 55° C)
More than one month:
-4° F to 95° F (-20° C to 35° C)

Disposal of Lithium Ion (Lilon) Batteries

For safe disposal options of your Lilon batteries, contact your nearest Sanyo authorized service center.

Special note: Be sure to dispose of your battery properly. In some areas, the disposal of batteries in household or business trash may be prohibited.

Tip:

For safety, do not handle a damaged or leaking Lilon battery.

Performance
and Safety

16

Acknowledging Special Precautions and the FCC Notice

FCC Notice

The phone may cause TV or radio interference if used in close proximity to receiving equipment. The FCC can require you to stop using the phone if such interference cannot be eliminated.

Vehicles using liquefied petroleum gas (such as propane or butane) must comply with the National Fire Protection Standard (NFPA-58). For a copy of this standard, contact the National Fire Protection Association, One Batterymarch Park, Quincy, MA 02269, Attn: Publication Sales Division.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ Reorient or relocate the receiving antenna.
- ▶ Increase the separation between the equipment and receiver.
- ▶ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ Consult the dealer or an experienced radio/TV technician for help.

Cautions

Any changes or modifications to your phone not expressly approved in this document could void your warranty for this equipment and void your authority to operate this equipment. Only use approved batteries, antennas and chargers. The use of any unauthorized accessories may be dangerous and voids the phone warranty if said accessories cause damage or a defect to the phone.

Although your phone is quite sturdy, it is a complex piece of equipment and can be broken. Avoid dropping, hitting, bending or sitting on it.

Index

A

Abbreviated Dialing, 86
accessories, 161-164
activation, 10-11
aircraft, phone use prohibited by, 172
Alerts (Sounds menu), 48, 153-154
Alphabet mode, 30-31
analog networks, 35
Animation, 91, 156
answering calls, 40
antenna, 20, 21, 167-168
Any Key Answer, 41, 158
Auto Answer, 42, 158

B

Backlight Setting (Display menu), 88, 155
Banner, 89
battery
 approved, 174
 charge indicator, 22, 23, 27
 charging, 26-27, 162, 163, 164, 174
 disposing of, 174, 175

installing, 26
Protecting, 174
power off caution, 26
removing, 26
beeps
 as low battery indicator, 27
 as message alert, 48, 154
 as minute beep, 48, 154
 as service alert, 48, 153
 as voicemail alert, 48, 154
blasting areas, phone not used in, 173
Browser, 128-137

C

Calculator, 123, 159
Calendar menu, 105-113, 152
Call Alarm (Calendar menu), 108-110, 112-113
Caller ID, 58
Call forwarding, 60
call in progress indicator, 34
Call Guard for Roaming, 37-38
calls
 answering, 40
 disconnecting, 40
 emergency, 43
 making, 40
 outside Sprint PCS Network, 34, 35



- Reviewing your Recent Call History, 52-53, 55
- See also* dialing
- Call waiting, 58
- CDMA networks, other PCS, 34, 35
- charge indicator, 22, 23, 27
- charging battery, 26-27, 162, 163, 164, 174
- charging times, 162-164
- chemical storage areas, phone not used in, 173
- children, protecting phone from, 173
- cigarette lighter adapter, 27, 163, 174
- Contrast Setting, 90, 156
- correcting mistakes, 21, 29, 31, 40
- Crab Catch Game, 122
- cross-talk, 35
- D**
- Data Calls, 138-141
- Data Cable, 138, 139, 141, 164
- defaults
 - lock code, 97, 157
 - passcode, 101-102
- desktop charger, 27, 163, 174
- dialing
 - Abbrev. Dial, 86
 - from phone book, 78-79
 - from recent call history, 53, 55
 - Prepend Dialing, 83
 - redialing, 43
 - speed dial, 44, 85
 - Voice-Activated Dialing, 120
- Directory Assistance, 14
- disconnecting, 40
- display color, 90, 155
- display indicators, 22-23, 34
- Downloads, 124-126, 159
- Driving safe use, 170
- dropped calls, 35
- dual-band feature, 33
- E**
- Earpiece volume, 49, 154
- eavesdropping, analog networks, 35
- editing
 - folder, 70
 - numbers in phone book, 81
 - secret phone book, 81
 - To-Do's, 112
- electronic devices, using phone near other, 172
- emergency phone numbers
 - calling, 43
- erasing
 - characters, 21, 29, 31

folder, 70
 message, 70, 72
 individual/all call history, 56
 multiple events, call alarm or
 To-Do's, 112, 113
 phone book, 80, 100
 Voice-Activated Dialing, 121
 Voice Memo, 114
 events (Calendar menu),
 105-107, 110, 112-113
 explosive atmospheres, phone
 not used in, 173
 extended battery, 162

F

fade-out, 35
 Fax Calls, 138-141
 Federal Aviation Administration
 (FAA), 172
 Federal Communications
 Commission (FCC), 167-168,
 172, 176
 finding numbers, 78-79
 folder, 68-71
 font size, 89, 155
 Found Me (Security menu),
 102, 158
 fueling area, phone not used in,
 173
See also liquefied petroleum
 gas regulations

G

green light, 21
 Greeting, 89, 155

H

hands-free car kit, 42, 163
 hands-free headset, 42
 hearing aids, 172
 help, 13-17
 hotel information, 14
 Hyphen, 82-83

I

icons, 22, 23
 Internal Phone Book
 add entry, 75
 editing an entry, 81
 erase, 80, 100
 find name, 78
 incoming picture, 79
 incoming ringer, 79
 saving a number, 74-75
 secret entries, 81

K

Key Beep (Sounds menu), 46,
 153
 keys
 CLR, 20, 21, 40
 END/POWER, 20, 21, 25, 40

Memo, 20, 21, 113-114, 115

Menu, 20, 21, 149

Navigation, 20, 21, 133

OK, 20, 21

Soft (left/right), 20, 21, 24, 134

TALK, 20, 21, 40

Volume, 20, 21, 133

L

Language, 88, 158

LiIon battery, 26, 175

liquefied petroleum gas regulations, 175

liquid spills, exposure to, 169

local event information, 14

lock code

changing, 98

default, 97, 157

and restricting, 99

See also unlocking phone

Lock side key, 96

Lock Phone (Security menu), 97

long-distance call, 14

Long phone number, 76-77, 151

M

magnetism, 169

Main LCD, 21, 22

medical device, 172

Melody Tempo (Sounds menu), 49, 154

Menu Diagram, 146-148

menus

Calendar, 152

Call History, 150

Game/Tools, 159

My Profile, 160

PC Sync, 160

Phone Book, 151

Roaming, 152

Screen Call, 159

Settings, 153-158

Voice-Activated Dialing, 159

Voicemail, 152

Wireless Web, 150-151

Messages

Clear Count, 65-66

Folder, 68-71

Page/Text, 62, 66-72

Storing, 71

Voice, 62, 64, 65, 66

Wireless Web, 62-63

message indicator, 22-23, 63, 65, 67, 150, 152

Minute Beep (Sounds menu), 48, 154

misdialing, 40

Missed Call Notification, 52

movie listings, 14

Mute, 50
 My PCS#, 44
 My Profile, 104, 160

N

names
 entering, 74-75, 78, 119
 searching for, 78
 National Fire Protection Standard
 (NFPA-58), 175
 networks
 dialing outside Sprint PCS
 Network, 33-38
 See also roaming.
 Number mode, 32
 Numeric page, 62

O

outside service areas indicator,
 22, 34
 Open to Answer, 42, 158

P

pacemaker, 172
 Pause Feature, 82
 storing number with pauses,
 82
 performance, maximizing, 166,
 169
 phone book, *see* Internal Phone
 Book.

phone number
 activating your, 10-11
 for help, 13-17
 for help outside Sprint PCS
 Network, 13
 Sprint PCS Customer Care,
 10-11, 13-14
 storing numbers. *See* Internal
 Phone Book
 Power-off Tone, 50, 155
 powering on/off, 25
 Power Save feature, 25, 166
 Prepaid Calls, 15
 Prepend Dialing, 83

R

radio frequency interference,
 172, 176
 radio frequency range, 166
 radio frequency safety, 167-168,
 172
 Receiver Vol, 49, 154
 receiving calls, 40
 reception, maximizing, 166, 169
 redialing, 43
 red light, 20, 21, 25, 63
 Reset Phone, 101, 157
 Reset/Lock phone through SMS,
 101-102
 Restrict (Security menu), 99

- restricting children's access to phone, 173
- Ringer Type (Sounds menu), 47, 153
- Ringer Vol (Sounds menu), 46, 153
- roaming, 33-38, 152
- roaming indicator, 22, 34
- S**
- safety, 165-176
- saving
 - numbers and addresses to phone book, 74-75, 76, 77
- Schedule, 105-113
- Screen Call, 115-118, 159
- Screen Saver, 91, 156
- searching, 78, 79
- Secret Phone Book Entries, 81
- Security menu, 97-102, 157-158
- security outside Sprint PCS Network, 35
- service areas, 22, 34, 35
- Service (Sounds menu), 48, 153
- Set Analog menu, 36
- setting up your voicemail, 12
- shopping information, 14
- short phone number, 77
- Side key guard, 96, 158
- signal strength, 22, 23, 166
- Sleep Mode, 94, 157
- Soft keys, 21, 24, 134
- Sounds menu, 46-50, 153-155
- Special # (Security menu), 100, 158
- speed dial, 44, 84-85
- Sprint PCS Accessory Hotline, 164
- Sprint PCS Account Information, 16-17
- Sprint PCS Customer Care, 10-11, 13-14
 - outside Sprint PCS Network, 13
- Sprint PCS Directory Assistance, 14
- Sprint PCS Operator Services, 17
- Sprint PCS Roadside Rescue, 16
- Sprint PCS Voice Command, 12
- Sprint PCS Wireless Web Browser, 128-137
- Sprint PCS Wireless Web Connection, 138-141
- Sprint PCS Wireless Web Updates, 142, 143
- Standard battery, 162
- Standby display, 92, 156
 - Calendar, 92
 - Count Down, 92
 - Text, 92
 - Time (Large), 92
 - Wallpaper, 92, 93
 - World Clock, 92

standby mode
 returning to, 149
Start-up Tone (Sounds menu),
 50, 155
Sub LCD, 21, 23
Symbol mode, 32
 clear count, 65-66
 message indicator, 22-23, 63,
 65, 67, 152
 Retrieving, 64
 setting up, 12
Voice Memo, 113-114
volume, 20, 21, 45-50, 153, 154

T

T9 mode, 28-30
technical support. *See* customer
 service
Three-Way Calling, 59
To Do (Calendar menu), 105,
 111, 112, 113
Tone Length (Sounds menu), 50,
 154
Travel Charger, 27, 164
turning phone on/off, 25
TV interference, 175

U

unlocking phone, 10, 97

V

Version (Display menu), 94, 157
Vibration, 153
Voice-Activated Dialing, 118-121,
 159
voicemail
 accessing, 64
 alert, 154

W

Wallpaper, 92, 93, 125
Web Alert, 143, 150
Web Site, 13, 17, 63, 168
World Clock, 92, 156, 159

Index

17

PATENT INFORMATION

Licensed by QUALCOMM Incorporated under one or more of the following United States Patents and/or their counterparts in other nations:

4,901,307	5,490,165	5,056,109	5,504,773	5,101,501
5,506,865	5,109,390	5,511,073	5,228,054	5,535,239
5,267,261	5,544,196	5,267,262	5,568,483	5,337,338
5,600,754	5,414,796	5,657,420	5,416,797	5,659,569
5,710,784	5,778,338			

- “T9 Text Input is covered by U.S. Pat. 5,818,437, U.S. Pat. 5,953,541, U.S. Pat. 6,011,554 and other patents pending.”